



MAINTENANCE AND INSPECTION PROCEDURES MANUAL

FOR SUPER PETREL LS

SCODA Aeronáutica LTDA.
Estrada Municipal IPN 020, Km 0,1
Ipeúna – SP, Brazil
ZIP CODE: 13537-000
(19) 3576-1292
www.scodaeronautica.com.br
engineering@scodaero.com.br

2018

Scoda Aeronáutica Ltda

All Rights Reserved

This technical document and the information embodied therein is property of Scoda Aeronautica Ltda. No part of this manual may be translated, reproduced, copied, disseminated, for any purpose without the consent of Scoda Aeronáutica Ltda.

Scoda Aeronáutica Ltda hereby grants permission to download a copy of this manual and of any revision to this manual onto a hard drive or other electronic storage medium to be viewed and/or to print one copy of this manual or of any revision hereto.

Commercial distribution of this manual or any revision hereto is strictly prohibited.

Revision Control Page

Revision Number	Date	Chapter	Pages
01	06/27/2019	0 5 6 7 12	I, II, III, IV, V, VI, VII, VIII, IX, X 27, 45, 46, 54 2, 3, 9, 30, 53 1, 2, 3, 4, 6, 7 11, 12
02	12/18/2019	0 5 6 12	I, III, IV, V, VI, VII, VIII, IX, X 6, 13, 14, 40 29 35
03	12/23/2020	0 5 6 7 12	I, III, IV, V, VI, VII, VIII, IX, X, XI 6, 7, 25, 28, 43, 44, 45, 46, 65, 72, 73, 76, 77, 98, 99 2, 3, 30, 31, 34 1, 2, 5, 6, 7, 8, 9, 10, 11 5, 6, 7, 8, 9, 10, 11
04	06/15/2021	0 5 6 12	I, III, IV, V, VI, VII, VIII, IX, X, XI, XII, XIII 4, 6, 7, 29, 34, 55, 66, 67, 76, 77, 78, 85, 100, 101, 104 4, 7, 9, 10, 23, 24 5, 7, 13, 38
05	01/12/2022	0 7 12	I, III, VIII 5 12
06	03/14/2022	0 5 6 7 12	I, III, VIII, IX, X, XI, XII, XIII, XIV 6, 46, 70, 76, 78, 81 7, 8, 11, 19 11, 12, 13, 14, 15, 16 5, 6, 7, 8, 9, 10, 11, 12, 14, 17
07	06/27/2022	0 5 12	I, III, IV-IX, X-XIV 6, 70, 71, 72, 73 5, 23
08	11/03/2023	0 5 6 12	I, III, IV-X, XI-XV 6, 78, 89, 90, 102, 105, 106, 109 8, 9, 21, 32, 33 9
09	10/18/2023	0 5 7 12	I, III, IV-X, XI-XV 4, 57 56, 57, 58, 59, 60 9

Revision Number	Date	Chapter	Pages
10	10/16/2025	0	I, III-IV, V-XII, XIII-XVII
		5	21, 22
		6	37
		7	2, 3-5, 6, 20, 21-24, 25
		12	12
11	09/16/2026	0	I, IV, XII
		5	35, 42, 44, 54, 61, 82
		9	1

List of Effective Pages

Revision Number	Chapter	Pages	Description of Revision	Date
00	All	All	New Issue	11/09/2018
01	0	I	• Updated Revision Date	06/27/2019
		II	• Added Notice (All Rights Reserved)	
		III	• Updated Revision	
		IV	• Updated List of Effective Pages	
	5	VI-X	• Updated Table of Contents	
		27	Revised 5.2.4.2 First 25 Hours Inspection	
			• Removed 100 Hours Inspection Form	
			• Added Line Inspection Form	
			Revised 5.2.4.3 100 Hours / Annual Inspection	
			• Removed 100 Hours Inspection Form	
			• Added Line Inspection Form	
		45 -46	Revised 5.3.4.1.3 Landing Gear Retraction System	
			• Updated NOTE of Replacement Interval	
		53	Revised 5.3.5.1.1 Ailerons	
			• Updated NOTE of Replacement Interval	
		54	Revised 5.3.5.1.2 Rudder	
	6		• Added NOTE of Replacement Interval	
		2-3	Revised 6.2.2.1 Coolant Replacement	
			• Updated NOTE of Replacement Interval	
			Revised 6.2.2.2 Lubrication Table	
			• Updated Replacement Interval	
		9	Revised 6.2.3.4 Filling Brake System	
			• Updated NOTE of Replacement Interval	
		30	Revised 6.2.3.17.2 Hoses and Line Replacement	
			• Updated NOTE of Replacement Interval	
			• Added NOTE of Rotax Recommendation for Hoses Replacement Interval	
	7	1	Added 7.2.1 5 Years / 1000 Hours Inspection	
			Added 7.2.1.1 Electrical Fuel Pump Inspection (Applied for 912 ULS)	
			Added 7.2.1.2 Electrical Fuel Pump Replacement (Applied for 912 ULS)	
		2	Added 7.2.1.3 Electric Fuel Pump Specification (Applied for 912 ULS)	
			Added 7.2.1.4 Electric Fuel Pumps Inspection (Main and Auxiliary) (Applied for 914 UL)	
			Added 7.2.1.5 Electric Fuel Pumps Replacement (Main and Auxiliary) (Applied for 914 UL)	
			Added 7.2.1.6 Electric Fuel Pumps (Main and Auxiliary) (Applied for 914 UL)	

01	7	3	Added 7.2.1.7 Electric Fuel Pumps Inspection (Main and Auxiliary) (Applied for 912 iS Sport) Added 7.2.1.8 Electric Fuel Pumps Specification (Main and Auxiliary) (Applied for 912 iS Sport) Added 7.2.1.9 Empennage Assembly Inspection	06/27/2019
		4	Added 7.2.2 Added 10 Years Inspection	
		5	Added 7.2.3 Teleflex Cable Inspection	
		5	Added 7.2.4 Rudder Cables Inspection	
			Added 7.2.5 Wing Assembly Inspection	
			Added 7.2.5.1 Lower Wing Inspection	
		6	Added 7.2.5.2 Upper Wing Inspection	
			Added 7.2.5.3 Struts Inspection	
			Added 7.2.5.4 Wing Assembly Inspection	
			Added 7.2.6 Fabric Covering Inspection	
		7	Added 7.2.7 Composite Structure Inspection	
	12	11-12	Added 12.6 Heavy Maintenance Inspection Form	
02	0	I III IV VI-X	• Updated Revision Date • Updated Revision • Updated List of Effective Pages • Updated Table of Contents	12/18/2019
	5	6	Revised 5.1.3 List of Disposable Replacement Parts	
			• Added Clean or Replace on Air Filters Action	
		13	Revised 5.1.5.3 Revised Loading Method	
			• Updated Sample Loading Chart Maximum Forward CG (1430 lbs)	
		14	Revised 5.1.5.4.1 Weight Definitions	
			• Updated Table (1430 lbs)	
			Revised 5.1.5.4.2 Revised Center of Gravity Forward and Aft Limits	
			• Updated Forward CG Limit information	
		40	Revised 5.3.3.2 Empennage Inspection	
			• Updated Empennage Fixation Bolts Inspection	
	6	29	Revised 6.2.3.15 Muffler Replacement	
			• Added a Caution for Muffler installation	
	12	35	Added 12.9 Exceptions	
			Added 12.9.1 Added Maximum Takeoff Weight Change	
			Added 12.9.2 Canada (Advanced Ultra-Light Aeroplane)	
03	0	I III IV - VI VII - XI	• Updated Revision Date • Updated Revision Control Page • Updated List of Effective Pages • Updated Table of Contents	12/23/2020
	5	6-7 25	Revised 5.1.3 List of Disposable Replacement Parts Revised 5.1.9.2 Cleaning and Care • Added 5.1.9.2.5 Salt Water Care	

		28	Revised 5.2.4 Inspection Schedule	12/23/2020
			• Added Note and Caution	
		43	Revised 5.3.4 Landing Gear	
			• Added Note	
		44	Revised 5.3.4.1.1 Nose Gear	
			• Updated inspection procedure	
			• Added Note	
		45-46	Revised 5.3.4.1.2 Main Gear	
			• Updated inspection procedure	
			• Added Note	
		65	Revised 5.4.2.4 Exhaust System	12/23/2020
			• Updated inspection procedure	
			• Added Note	
		72-73	Revised 5.5.2 Fuel System Inspection	
			• Updated Fuel Filter Inspection	
			• Removed Aux. Fuel Pump Inspection	
		76-77	Revised 5.6.4 Propeller Installation	
			• Updated Pitch Angles Table	
			• Updated RPM Values	
			• Added Note	
		98-99	Revised 5.9.1.3 Schematic Diagrams	12/23/2020
			• Added Figure Feeding Electrical Diagram (G3X – 912iS)	
			• Added Figure Panel Electrical Diagram (G3X – 912iS)	
	6	2-3	Revised 6.2.2 Servicing of Fluids	
			• Added 6.2.2.1 Oil Check and Replenish	
			• Added 6.2.2.2 Oil Change	
		30-31	Revised 6.2.3.12 Exhaust Tension Springs Replacement	
			• Updated Note	
			Revised 6.2.3.12.1 Tension Springs Replacement	
			• Updated Procedure Information	
			• Added Caution	
		34	Revised 6.2.4.1 Fabric Covering Minor Damages	12/23/2020
			• Updated Parts and Material Required	
	7	1-2	Revised 7.2.1.1 Electric Fuel Pumps (Main and Auxiliary)	
			• Updated Note	
			• Added Note	
			• Added Caution	
			• Updated Procedure Information	
		5-11	Added 7.2.8 Structural Repairs – Standards and Practices	
	12	5-11	Revised 12.5 Line Maintenance Inspection Form	
			• Updated and reformatted checklist content	

04	0	I III IV-VIII IX-XIII	• Updated Revision Date • Updated Revision Control Page • Updated List of Effective Pages • Updated Table of Contents	06/15/2021
	5	4 6-7 29 34 55 66-67 75-78 85 100-101 104	Revised 5.1 General • Added Aileron Electric Trim Revised 5.1.3 List of Disposable Replacement Parts • Updated Nose Gear Bearing Information • Updated Main Landing Gear Bearing Information • Added 40mm Shock Absorber Information • Removed Earls Inline Fuel Filter • Added Holley Inline Fuel Filter Revised 5.2.4.1 Daily Inspection • Updated procedure Revised 5.3.2.1 Description (Wings) • Added Aileron Electric Trim (Left Aileron) Revised 5.3.5.1.1 Ailerons • Added Inspection of the Aileron Electric Trim Tab Revised 5.4.2.3 Cooling System Added 5.4.3.2.1 Ventilation Electrical System Inspection Revised 5.5.2 Fuel System Inspection • Added NOTE Earl's Inline Fuel Filter (Discontinued) • Added Holley Inline Fuel Filter Inspection Procedure • Added 5.5.2.1 Electrical Fuel Pumps Inspection • Added CAUTION and WARNING Electric Fuel Pumps • Added Picture Electric Fuel Pumps Revised 5.9.1 Description (Electrical System) • Added Aileron Electric Trim Revised 5.9.1.3 Schematic Diagrams • Added 5-87 Feeding Electrical Diagram (Garmin G3X System – 914 UL) • Added 5-88 Panel Electrical Diagram (Garmin G3X System – 914 UL) Revised 5.9.2.5 Other Components • Added Aileron Electric Trim	
	6	4 7	Revised 6.2.24 Lubrication Table • Added Electric trim Tab Hinges (Aileron) Revised 6.2.3.1 Fuel Filter Replacement (Table) • Added Holley Inline Fuel Filter Part Number • Added Holley Fuel Filter Replacement Elements Part Number • Added Andair Spare O-ring Part Number • Removed Earls Inline Fuel Filter	

04	6	9-10 23 24	Added Holley Fuel Filter Replacement Elements Procedure Revised 6.2.3.9.2 • Added Pressure for 40mm Shock Absorber Revised 6.2.3.9.4 • Added 40mm Shock Absorber	06/15/2021
	12	5 7 13 38	• Revised 12.5 Line Maintenance Inspection Form • Added 1.11; 1.12 Ventilation Electrical System Inspection • Added 4.8 and 4.9 Aileron electric trim inspection step Revised 12.7.1 Wings • Added Note (Fuse Box) – 912 iS Sport Updated 12.9 Exemptions • Removed Item 12.9.2	
05	0	I III VIII	• Updated Revision Date • Updated Revision Control Page • Updated List of Effective Pages	01/12/2022
	7	5	Revised 7.2.7 Composite Structure Inspection • Revised Item 2	
	12	12	Revised 12.6 Heavy Maintenance Inspection Form • Revised Item 6.7	
06	0	I III VIII-IX X-XIV	• Updated Revision Date • Updated Revision Control Page • Updated List of Effective Pages • Updated Table of Contents	03/14/2022
	5	5-6	Revised 5.1.3 List of Disposable Replacement Parts • Removed Air Filter Rotax 825750 • Added Air Filter K&N RC-1624	
		5-47	Revised 5.3.4.1.1 Nose Gear • Updated Item 2. Nose Gear Doors (Replacement)	
		5-71	Added 5.4.3.2 Air Filter Replacement	
	5-79	5-79	Revised 5.5.2 Fuel System Inspection • Added Caution	
		5-81	• Updated Item Fuel System (Fuel Sensor Replacement) • Added Item Placards	
	5-84	5-84	Revised 5.6.2 Propeller Inspection • Added Notes	
	6	6-7 6-11 6-20	Added 6.2.3.1 Windshield and Doors Replacement Added 6.2.3.3 Fuel Sensor Unit Replacement Added 6.2.3.10 Nose Gear Doors Replacement	
	7	7-15 7-16 7-18	Added 7.2.8.10 Fuselage Repair Added 7.2.8.11 Hull Repair Added 7.2.8.12 Leading Edge Repair	

	12	12-5	Revised 12.5 Line Maintenance Inspection Form • Removed Columns “Carried out by” and “Inspected by” • Added Column “Initials”	
		12-11	Revised 12.6 Heavy Maintenance Inspection Form • Removed Columns “Carried out by” and “Inspected by” • Added Column “Initials”	
		12-15	Revised 12.7.1 wings (Assembly Quick Guide) • Added Caution	
		12-18	Revised 12.7.1.1 Upper Wings (Assembly Quick Guide) • Added Note and Image (Airbox Rotax 914 UL)	
07	0	I III IV-IX X-XIV	• Updated Revision Date • Updated Revision Control Page • Updated List of Effective Pages • Updated Table of Contents	06/23/2022
	5	6 70-72 72-73	Revised 5.1.3 List of Disposable Replacement Parts • Removed Air Filter RC-1624 • Added Air Filter RU-0800 (Rotax P/N: 825750) Revised 5.4.3.2 Air Filter Replacement • Added instructions for installing and securing the air filter Added 5.4.3.3 Fine Fuel Filter Replacement (Rotax P/N: 874060)	
	12	5 23	Revised 12.5 Line Maintenance Inspection Form • Added Item 1.7 (Fine Fuel Filter) Revised 12.7.1.3 Lower Wings • Added instructions for Installation of Lower Wing from aircraft serial number S0390	
08	0	I III IV-X XI-XV	• Updated Revision Date • Updated Revision Control Page • Updated List of Effective Pages • Updated Table of Contents	
	5	6 78 89 90 102	Revised 5.1.3 List of Disposable Replacement Parts • Added Inline Fuel Filter Andair FX375-MK (NPT Male Output) Revised 5.5.2 Fuel System Inspection • Added Inline Fuel Filter Andair FX375-MK • Added Note Revised 5.8 Instruments and Avionics Revised 5.8.1 Description • Added ELT Remote Control Localization Description • Added Note Revised 5.8.2 Instruments and Avionics Inspection • Added Item 3. ELT (Emergency Locator Transmitter) • Revised Caution Revised 5.9.1.3 Schematic Diagrams • Added Figure 5-91 Panel Electrical Diagram (Garmin G3X System – 912 iS Sport) – with Warning Lights Dimmer	

09		105	Added Figure 5-94 Panel Electrical Diagram (Garmin G3X System – 912 iS Sport) – New Version without Warning Lights Dimmer	
		106	Added Figure 5-95 Panel Electrical Diagram (Garmin G3X System – 914 UL) – New Version without Warning Lights Dimmer	
		109	Added 5.9.2.5 Warning Lights Inspection (Lane A, Lane B, TCU and Alternator)	
	6	8	Revised 6.2.3.2 Fuel Filter Replacement	
		9	- Revised Parts and Materials Required - Added FX375-MK - Added Note	
		21	Revised 6.2.11.2 Cable Replacement	
		32	Corrected Values of the Nose Gear Cable Length	
		33	Added 6.2.3.15 Warning Lights Replacement (Lane A, Lane B, TCU and Alternator) Added 6.2.3.15.1 Lane A and Lane B Lights (for 912 iS Sport) Added 6.2.3.15.2 TCU and Alternator Lights (for 914 UL)	
	12	9	Revised 12.5 Line Maintenance Inspection Form - Added Item 8.13 (Lane A and Lane B Lights) - Added Item 8.14 (TCU and Alternator Lights) - Revised Item 8.19 (added ELT)	
	0	I III IV-X XI-XV	Updated Revision Date Updated Revision Control Page Updated List of Effective Pages Updated Table of Contents	10/18/2023
10	5	4	Revised 5.1 General (Flight Controls Information) Corrected Rudder Ranges Information Removed Up/Down; Added Left/Right Revised 5.3.5.1.2 Rudder	
	7	40	Revised 7.2.1.2 Empennage Added Note	
		56-57	Added 7.2.8.13 Cabin Floor Repair	
		57-58	Added 7.2.8.14 Seat Fitting Holes Repair	
		59-60	Added 7.2.8.15 Rudder Actuator Stop Repair	
10	12	9	Revised 12.5 Line Maintenance Inspection Form Revised Item 7.10	10/16/2025
	0	I III-IV V-XII XIII-XVII	Updated Revision Date Updated Revision Control Page Updated List of Effective Pages Updated Table of Contents	
	5	21-22	Revised 5.1.9.1.2 Jacking Up Added Landing Gear System Maintenance and Test	

10	6	37	Revised 6.2.3.21.3 Hoses and Lines Specification	
	7	2 3-5 6 20-21 21-24 24-25	• Updated and reformatted table • Added hoses and lines technical specification data • Added new hose SAEJ30R14 Type 2 • Revised 7.2.1.2 Empennage Assembly Inspection • Added 7.2.1.3 Elevator and primary pushrod inspection • Added 7.2.5 Throttle cable inspection • Added 7.2.8.13 Trailing Edge Repair • Added 7.2.8.14 Wing Ribs Repair • Added 7.2.8.15 Rib Cap Strip Repair	
	12	12	• Revised 12.6 Heavy Maintenance Inspection Form • Revised item 4. Empennage • → Added items 4.21 / 4.22 Elevator and primary pushrod inspection (5 years) • Revised item 5. Cables • → Added Throttle cable inspection (10 years)	
11	0	I III-IV V-XII XIII-XVII	Updated Revision Date Updated Revision Control Page Updated List of Effective Pages Updated Table of Contents	09/16/2026
	5	35 42 44 54 61 82	• Revised 5.3.1.3 Fuselage Repairs and Alterations • Revised 5.3.2.3 Wings Repairs and Alterations • Revised 5.3.3.3 Empennage Repairs and Alterations • Revised 5.3.4.2 Landing Gear Repairs and Alterations • Revised 5.3.5.2 Control Surfaces Repairs and Alterations • Revised 5.5.3 Fuel System Repairs and Alterations	
	9	1	• Revised 9 Major Repairs and Alterations	

Table of Contents

REVISION CONTROL PAGE	III
LIST OF EFFECTIVE PAGES	V
TABLE OF CONTENTS	XIII
1 SCOPE	1-1
1.1 AUTHORIZED PERSONNEL	1-1
1.2 SUPER PETREL LS TRAINING COURSES	1-1
1.3 OWNER / OPERATOR RESPONSIBILITIES	1-2
1.4 SAFETY OF FLIGHT AND SERVICE DIFFICULTY REPORTING	1-2
1.5 APPLICATION OF NOTES, CAUTIONS AND WARNINGS	1-3
2 REFERENCE DOCUMENTS	2-1
3 TERMINOLOGY AND ACRONYMS	3-1
4 SIGNIFICANCE AND USE	4-1
5 AIRCRAFT MAINTENANCE MANUAL	5-1
5.1 GENERAL	5-1
5.1.1 <i>Equipment List</i>	5-5
5.1.2 <i>Supply Sources for Parts</i>	5-5
5.1.3 <i>List of Disposable Replacement Parts</i>	5-6
5.1.4 <i>Engine Specifications</i>	5-8
5.1.5 <i>Weight and Balance Information</i>	5-8
5.1.5.1 Weight and Balance Chart	5-9
5.1.5.2 Empty Weight Center of Gravity Location	5-10
5.1.5.3 Loading Method	5-13
5.1.5.4 Operating Weights and Loading	5-15
5.1.5.4.1 Weight Definitions	5-15
5.1.5.4.2 Center of Gravity Forward and Aft Limits	5-15
5.1.5.4.3 Baggage Compartment	5-15
5.1.5.4.4 Ballast Tank	5-15
5.1.5.4.5 Center of Gravity (CG) range	5-16
5.1.6 <i>Tire Inflation Pressures</i>	5-16
5.1.7 <i>Approved Oils and Capacities</i>	5-17
5.1.7.1 Engine	5-17
5.1.7.2 Brake Fluid	5-19
5.1.8 <i>Recommended Fastener Torque Values</i>	5-19
5.1.9 <i>General Safety Information</i>	5-19
5.1.9.1 Ground Handling	5-20
5.1.9.1.1 Towing	5-20
5.1.9.1.2 Jacking Up	5-21
5.1.9.1.3 Parking	5-23
5.1.9.1.4 Tie-Down Instructions	5-24
5.1.9.2 Cleaning and Care	5-24
5.1.9.2.1 Canopy External Part	5-24
5.1.9.2.2 Canopy Internal Part	5-25
5.1.9.2.3 Fuselage External Part (Wings / Tail)	5-25
5.1.9.2.4 Fuselage Internal Part	5-26
5.1.9.2.5 Salt Water Care	5-26
5.1.10 <i>Safety of Flight Report</i>	5-26
5.2 INSPECTIONS	5-27

5.2.1	Condition Inspection Checklist	5-28
5.2.2	Periodic Inspection Tasks	5-28
5.2.3	Level of Certification	5-29
5.2.4	Inspections Schedule	5-29
5.2.4.1	Daily Inspection	5-30
5.2.4.2	First 25 Hours Inspection	5-30
5.2.4.3	Every 100 Hours / Annual Inspection	5-30
5.2.4.4	Every 1000 Hours / Five (5) Years Inspection	5-31
5.2.4.5	Every Ten (10) Years Inspection	5-31
5.3	STRUCTURES	5-31
5.3.1	Fuselage	5-31
5.3.1.1	Description	5-31
5.3.1.2	Fuselage Inspection	5-31
5.3.1.2.1	Covering	5-32
5.3.1.2.2	Deterioration	5-32
5.3.1.2.3	Cracks	5-32
5.3.1.2.4	Impacts or Damages	5-32
5.3.1.2.5	Canopy Inspection	5-33
5.3.1.2.6	Seats Inspection	5-34
5.3.1.2.7	Safety Belts Inspection	5-34
5.3.1.2.8	Fire Extinguisher Inspection	5-34
5.3.1.2.9	Doors Removal	5-34
5.3.1.2.10	Ballast Draining	5-35
5.3.1.3	Fuselage Repair and Alteration	5-35
5.3.2	Wings	5-35
5.3.2.1	Description	5-35
5.3.2.2	Wings Inspection	5-36
5.3.2.2.1	Upper Wings Inspection	5-36
5.3.2.2.2	Lower Wings Inspection	5-38
5.3.2.2.3	Struts Inspection	5-40
5.3.2.3	Wings Repair and Alteration	5-42
5.3.3	Empennage	5-42
5.3.3.1	Description	5-42
5.3.3.2	Empennage Inspection	5-42
5.3.3.3	Empennage Repair and Alterations	5-44
5.3.4	Landing Gear	5-44
5.3.4.1	Landing Gear Inspection	5-45
5.3.4.1.1	Nose Gear	5-46
5.3.4.1.2	Main Gear	5-48
5.3.4.1.3	Landing Gear Retraction System	5-48
5.3.4.1.4	Tires and Brake System	5-52
5.3.4.1.5	Shock Absorber	5-53
5.3.4.2	Landing Gear Repair and Alterations	5-54
5.3.5	Structural Control Surfaces	5-55
5.3.5.1	Control Surfaces Inspection	5-55
5.3.5.1.1	Ailerons	5-55
5.3.5.1.2	Rudder	5-57
5.3.5.1.3	Elevators and Trim Tab	5-59
5.3.5.1.4	Joysticks and Pedals	5-61
5.3.5.2	Control Surfaces Repair and Alterations	5-61
5.4	ENGINE	5-61
5.4.1	Description	5-61
5.4.2	Engine Inspection	5-63
5.4.2.1	Engine Cowlings	5-63
5.4.2.2	Engine Suspension Frame	5-64
5.4.2.3	Cooling System	5-67
5.4.2.3.1	Ventilation Electrical System Inspection (Only for 912 IS Sport)	5-67
5.4.2.4	Exhaust System	5-69

5.4.2.5	Carburetor Heater (If Installed) – Only for 912 ULS.....	5-70
5.4.2.6	Engine Controls	5-70
5.4.3	<i>Engine Maintenance, Repair and Overhaul</i>	<i>5-70</i>
5.4.3.1	Spark Plugs Replacement	5-70
5.4.3.2	Air Filter Replacement	5-71
5.4.3.3	Fine Fuel Filter Replacement (Rotax P/N: 874060) – Applied for Rotax 912 iS Sport	5-73
5.5	FUEL SYSTEM	5-74
5.5.1	<i>Description</i>	<i>5-74</i>
5.5.1.1	SPLS Fuel System Diagram for 912 ULS	5-75
5.5.1.2	SPLS Fuel System Diagram for 914 UL	5-76
5.5.1.3	SPLS Fuel System Diagram for 912 iS Sport	5-77
5.5.1.4	Refueling: Safety Precautions.....	5-78
5.5.1.5	Draining Process.....	5-78
5.5.2	<i>Fuel System Inspection.....</i>	<i>5-79</i>
5.5.2.1	Electrical Fuel Pumps Inspection.....	5-81
5.5.3	<i>Fuel System Repair and Alterations</i>	<i>5-82</i>
5.6	PROPELLER	5-83
5.6.1	<i>Description</i>	<i>5-83</i>
5.6.2	<i>Propeller Inspection</i>	<i>5-83</i>
5.6.3	<i>Propeller Maintenance, Repair and Overhaul.....</i>	<i>5-84</i>
5.6.4	<i>Propeller Installation.....</i>	<i>5-85</i>
5.6.5	<i>Propeller Balancing.....</i>	<i>5-86</i>
5.6.5.1	Propeller Balancing Parameters	5-87
5.7	UTILITY SYSTEMS	5-87
5.7.1	<i>Cabin Heater System.....</i>	<i>5-87</i>
5.7.2	<i>Cabin Heater Inspection.....</i>	<i>5-88</i>
5.7.2.1	Under Cowling Inspection (Engine).....	5-88
5.7.2.2	In Cockpit Inspection.....	5-88
5.7.3	<i>Cabin Heater Maintenance, Repair and Overhaul</i>	<i>5-89</i>
5.8	INSTRUMENTS AND AVIONICS	5-89
5.8.1	<i>Description.....</i>	<i>5-89</i>
5.8.1.1	Instrument Panel and Flight Instruments.....	5-89
5.8.2	<i>Instruments and Avionics Inspection</i>	<i>5-90</i>
5.8.3	<i>Instruments and Avionics Maintenance, Repair and Overhaul</i>	<i>5-90</i>
5.9	ELECTRICAL SYSTEM.....	5-91
5.9.1	<i>Description.....</i>	<i>5-91</i>
5.9.1.1	Engine	5-91
5.9.1.2	Circuit Breakers	5-92
5.9.1.3	Schematic Diagrams	5-88
5.9.1.4	Acceptable Methods, Techniques and Practices for Electrical System Maintenance	5-107
5.9.2	<i>Electrical System Inspection.....</i>	<i>5-107</i>
5.9.2.1	Battery Inspection.....	5-108
5.9.2.2	Wiring Harness Inspection	5-108
5.9.2.3	Bilge Pump Inspection	5-108
5.9.2.4	Fuses and Fuses Holders	5-109
5.9.2.5	Warning Lights Inspection (Lane A, Lane B, TCU and Alternator)	5-109
5.9.2.6	Other Components	5-109
5.9.3	<i>Electrical System Maintenance, Repair and Overhaul</i>	<i>5-109</i>
5.10	STRUCTURAL REPAIR	5-109
5.11	PAINTING AND COATINGS.....	5-110
5.11.1	<i>Paint Code and Specification.....</i>	<i>5-110</i>
5.11.2	<i>Painting Repairs</i>	<i>5-110</i>
5.11.2.1	Puttying.....	5-111
5.11.2.2	Priming.....	5-111
5.11.2.3	Painting.....	5-111
5.11.2.4	Polishing.....	5-112

5.11.2.5	Method of Verification	5-112
5.11.3	<i>Corrosion, Inspection and Protection</i>	5-112
5.12	REVISIONS	5-112
5.13	FEEDBACK FORM	5-113
6	LINE MAINTENANCE, REPAIRS, AND ALTERATIONS.....	6-1
6.1	AUTHORIZATION TO PERFORM LINE MAINTENANCE, REPAIRS AND ALTERATIONS.....	6-1
6.2	LINE MAINTENANCE TASKS.....	6-1
6.2.1	<i>100-h Inspection / Annual Condition Inspection</i>	6-1
6.2.2	<i>Servicing of Fluids</i>	6-1
6.2.2.1	Oil Check and Replenish	6-2
6.2.2.2	Oil Change	6-2
6.2.2.3	Coolant Replacement	6-3
6.2.2.4	Lubrication Table (Line Maintenance)	6-4
6.2.2.5	Lubrication View	6-5
6.2.3	<i>Removal and Replacement of Components</i>	6-7
6.2.3.1	Windshield and Doors Replacement	6-7
6.2.3.2	Fuel Filter Replacement	6-8
6.2.3.3	Fuel Sensor Unit Replacement	6-11
6.2.3.4	Battery Replacement	6-12
6.2.3.5	Instruments	6-12
6.2.3.6	Filling Brake System	6-13
6.2.3.7	Brake Pads Replacement	6-14
6.2.3.8	Brake Discs Replacement	6-16
6.2.3.9	Bearing Replacement	6-16
6.2.3.9.1	Main Wheels	6-16
6.2.3.9.2	Nose Wheel	6-18
6.2.3.10	Nose Gear Doors Replacement	6-20
6.2.3.11	Landing Gear Cable Inspection and Replacement	6-20
6.2.3.11.1	Cable Inspection	6-21
6.2.3.11.2	Cable Replacement	6-21
6.2.3.11.3	Cables Specification	6-24
6.2.3.12	Shock Absorber Calibration and Replacement	6-24
6.2.3.12.1	Shock Absorber Inspection	6-25
6.2.3.12.2	Shock Absorber Calibration	6-25
6.2.3.12.3	Shock Absorber Replacement	6-26
6.2.3.12.4	Shock Absorber Specification	6-27
6.2.3.13	Gas Spring Test and Replacement	6-27
6.2.3.13.1	Gas Spring Test	6-27
6.2.3.13.2	Gas Spring Replacement	6-28
6.2.3.13.3	Gas Spring Specification	6-31
6.2.3.14	Wiring and Connectors Replacement	6-31
6.2.3.15	Warning Lights Replacement (Lane A, Lane B, TCU and Alternator)	6-32
6.2.3.15.1	Lane A and Lane B Lights (for 912 iS Sport)	6-32
6.2.3.15.2	TCU and Alternator Lights (for 914 UL)	6-33
6.2.3.16	Exhaust Tension Springs Replacement	6-33
6.2.3.16.1	Tension Springs Replacement	6-33
6.2.3.16.2	Tension Springs Specification	6-34
6.2.3.17	Exhaust Muffler Inspection and Replacement	6-34
6.2.3.18	Muffler Inspection	6-34
6.2.3.19	Muffler Replacement	6-35
6.2.3.20	Muffler Specification	6-36
6.2.3.21	Hoses and Lines	6-36
6.2.3.21.1	Hose and Line Inspection	6-36
6.2.3.21.2	Hose and Line Replacement	6-36
6.2.3.21.3	Hoses and Lines Specification	6-37
6.2.4	<i>Repairs of Components</i>	6-38
6.2.4.1	Fabric Covering Minor Damages	6-38

6.2.4.2	Repair of Non-Structural Composite Components	6-38
6.2.4.3	Stop Drilling Cracks	6-39
6.2.5	<i>Alterations</i>	6-39
6.2.5.1	Compliance with Manufacturer's Service Directives	6-39
7	HEAVY MAINTENANCE, REPAIRS, AND ALTERATIONS	7-1
7.1	AUTHORIZATION TO PERFORM HEAVY MAINTENANCE, REPAIRS AND ALTERATIONS.....	7-1
7.2	HEAVY MAINTENANCE TASKS.....	7-1
7.2.1	<i>5 Years / 1000 Hours Inspection</i>	7-1
7.2.1.1	Electric Fuel Pumps Replacement (Main and Auxiliary)	7-1
7.2.1.2	Empennage Assembly Inspection	7-2
7.2.1.3	Elevator and primary pushrod inspection	7-3
7.2.2	<i>10 Years Inspection</i>	7-5
7.2.3	<i>Teleflex Cable Inspection</i>	7-5
7.2.4	<i>Throttle Cable Inspection</i>	7-5
7.2.5	<i>Rudder Cables Inspection</i>	7-6
7.2.6	<i>Wings Assembly Inspection</i>	7-6
7.2.6.1	Lower Wings Inspection.....	7-8
7.2.6.2	Upper Wings Inspection.....	7-8
7.2.6.3	Struts Inspection	7-8
7.2.6.4	Wings Assembly Installation	7-8
7.2.7	<i>Fabric Covering Inspection</i>	7-8
7.2.8	<i>Composite Structure Inspection</i>	7-9
7.2.9	<i>Structural Repairs – Standard and Practices</i>	7-9
7.2.9.1	General Safety Information	7-9
7.2.9.2	Level of Certification	7-9
7.2.9.3	Repair Classification	7-10
7.2.9.4	Materials	7-10
7.2.9.5	Repair Preparation	7-11
7.2.9.6	Typical Lay-Up Procedure	7-11
7.2.9.7	Fillers Mixing.....	7-12
7.2.9.8	Repair Tolerances	7-12
7.2.9.9	Repair Procedures	7-13
7.2.9.10	Fuselage Repair	7-15
7.2.9.11	Hull Repair.....	7-16
7.2.9.12	Leading Edge Repair	7-18
7.2.9.13	Trailing Edge Repair	7-21
7.2.9.14	Wing Ribs Repair	7-22
7.2.9.15	Rib Cap Strip Repair	7-25
7.2.9.16	Cabin Floor Repair.....	7-27
7.2.9.17	Seat Fitting Holes Repair	7-29
7.2.9.18	Rudder Actuator Stop Repair	7-31
8	OVERHAUL	8-1
8.1	AUTHORIZATION TO PERFORM OVERHAUL.....	8-1
9	MAJOR REPAIRS AND ALTERATIONS	9-1
10	TASK-SPECIFIC TRAINING.....	10-1
11	SAFETY DIRECTIVES	11-1
12	APPENDIXES.....	12-1
12.1	IMPROVEMENT OR CORRECTIONS	12-1
12.2	AIRCRAFT REGISTRATION FORM.....	12-2
12.3	CONTINUED OPERATIONAL SAFETY REPORTING FORM	12-3
12.4	WARRANTY CLAIM FORM	12-4
12.5	LINE MAINTENANCE INSPECTION FORM.....	12-5

12.6	HEAVY MAINTENANCE INSPECTION FORM	12-11
12.7	ASSEMBLY QUICK GUIDE.....	12-14
12.8	SPRING COMPRESSOR DEVICE DRAWING.....	12-35
12.9	EXCEPTIONS	12-36

1 SCOPE

Scoda Aeronáutica Ltda has prepared this manual in accordance with the latest revision of the ASTM F2483 standard. The manual provides the practices for the servicing and the maintenance of the Super Petrel LS with guidance for the qualifications necessary to perform the various level of maintenance. It provides practices and guidance for servicing, preventive maintenance requirements of a 100-hour and annual condition inspection, and the corrective line maintenance action for the repairs, alterations, and the removal and re-installation of components.

1.1 Authorized Personnel

The Super Petrel LS is a composite biplane amphibious light sport aircraft powered by a compact size Rotax Aircraft Engine installed on pusher configuration. Considering these particularities, Scoda Aeronautica as well as ROTAX BRP-Powertrain authorized training are required to assure equally qualified technicians in the field.

Technicians that will service the Super Petrel LS need to be identifiable as having met a high standard of training, knowledge and experience on Super Petrel LS aircraft as well as Rotax Aircraft Engines. Therefore, every organization or individual should hold a formal instruction from Scoda Aeronautica and ROTAX BRP-Powertrain authorized training facility.

It is a requirement that all organizations or individuals have a recurrent knowledge status for the level of work they intend to perform. Any inspection, repair, and alteration outlined in this Maintenance Manual should be performed if the organization or individual holds the following maintenance rating:

- LSA Repairman Maintenance Certificate
- A&P Certificate
- iRMT Training (at least Service ROTAX® Aircraft Engines Rating)
- Super Petrel LS Maintenance Training (at least Line Maintenance Super Petrel LS Rating)

1.2 Super Petrel LS Training Courses

Scoda Aeronáutica established a globally standardized training guideline covering the different scope of work, target audiences and educational levels which ranges from familiarization to task specific on the Super Petrel LS aircraft. All technical training courses are offered by Scoda Aeronáutica or an authorized training center.

The Super Petrel LS Maintenance Training Pyramid is built on 3 main levels:

1. Line Maintenance

The Line Maintenance course covers and gives the necessary knowledge to perform inspection on Super Petrel LS up to 100 hours inspection or annual inspection.

Certification: Line Maintenance Super Petrel LS Aircraft

Recurrent Training: This course/rating has to be renewed every 3 years, with focus on the Maintenance Manual revisions or changes since the last course.

2. Heavy Maintenance

Additional to Line Maintenance course, the Heavy Maintenance course covers and gives the necessary knowledge to perform 5 years / 1000 hours and 10 years inspection on Super Petrel LS.

Certification: Heavy Maintenance Super Petrel LS Aircraft

Recurrent Training: This course/rating has to be renewed every 3 years, with focus on the Maintenance Manual revisions or changes since the last course.

3. Task Specific Training

This course is available by invite only. Applicants must meet requirements set by Scoda Aeronáutica to be eligible for the applicable training.

1.3 Owner / Operator Responsibilities

The owner / operator is reminded that it is their responsibility to ensure that Scoda Aeronáutica Ltda has the appropriate contact information on file, to allow for flight safety and other important information can be communicated in a timely manner. Please use the FORM_SPLS_001_Aircraft Registration Form on Scoda Aeronáutica's website (www.scodaeronautica.com.br) to register any changes in ownership or address and sent via email to engineering@scodaero.com.br.

Notices of Corrective Actions and the latest version of the Maintenance Manual for this aircraft may be found on Scoda Aeronáutica's website.

NOTE

SCODAAERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Aircraft, Repair and Alterations Acceptable Methods, Techniques, and Practices.

NOTE

This maintenance manual does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this document to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.

1.4 Safety of Flight and Service Difficulty Reporting

Please report any safety of flight or any other service difficulty directly to Scoda Aeronáutica Ltda using the FORM_SPLS_002_Continued Operational Safety Reporting Form on Scoda Aeronáutica's website (http://www.scodaeronautica.com.br/blog_anexos/c667c8609b3e92488fcc075d51070562.pdf) and sent via email to engineering@scodaero.com.br.

1.5 Application of Notes, Cautions and Warnings

NOTES, **CAUTIONS** and **WARNINGS** are used in the Maintenance Manual to emphasize instructions for information considered to be unusual or critical. The conditions that warrant use of **NOTES**, **CAUTIONS** and **WARNINGS** are defined in the following:

NOTE

Maintenance procedures, practices or conditions, which is essential to highlight or explain.

CAUTION

Maintenance procedures, practices or conditions, which, if not strictly observed or corrected, could result in damage or destruction of equipment.

WARNING

MAINTENANCE PROCEDURES, PRACTICES OR CONDITIONS, WHICH, IF NOT STRICTLY OBSERVED OR REMEDIED, COULD RESULT IN SERIOUS PERSONAL INJURY OR LOSS OF LIFE.

2 Reference Documents

ASTM Standards:

- F2245 – Specification for Design and Performance of a Light Sport Airplane.
- F2295 – Practice for Continued Operational Safety Monitoring of a Light Sport Aircraft.
- F2483 – Practice for Maintenance and the Development of Maintenance Manuals for Light Sport Aircraft

Federal Standards:

- 14 CFR Part 21.190 – Issue of a Special Airworthiness Certificate for a Light-Sport Category Aircraft.
- 14 CFR Part 43 – Maintenance, Preventive Maintenance, Rebuilding, and Alteration.
- 14 CFR Part 65 – Certification: Airmen Other Than Flight Crewmembers
- AC 43.13-1B – Acceptable Methods, Techniques, and Practices – Aircraft Inspection and Repair

3 Terminology and Acronyms

(1) DEFINITIONS:

Annual Condition Inspection – detailed inspection accomplished once a year on a LSA in accordance with instructions provided in the maintenance manual supplied with the aircraft. The purpose of the inspection is to look for any wear, corrosion, or damage that would cause an aircraft to not be in a condition for safe operation.

A&P – airframe and powerplant mechanic as defined by 14 CFR Part 65 in the U.S. or equivalent certification in other countries.

FAA – United States Federal Aviation Administration.

Heavy Maintenance – any maintenance, inspection, repair, or alteration a manufacturer has designated that requires specialized training, equipment, or facilities.

Line Maintenance – any repair, maintenance, scheduled checks, servicing, inspections, or alterations not considered heavy maintenance that is approved by the manufacturer and is specified in the manufacturer's maintenance manual.

LSA (Light Sport Aircraft) – aircraft designed in accordance with ASTM standards under the jurisdiction of Committee F37 Light Sport Aircraft, for example, Specification F2244 for powered parachutes, Specification F2245 for airplanes, and Specification F2352 for gyroplanes.

LSA Repairman Inspection – U.S. FAA-certificated repairman (light sport aircraft) with an inspection rating as defined by 14 CFR Part 65, authorized to perform the annual condition inspection on experimental light sport aircraft the holder owns, or an equivalent rating issued by other civil aviation authorities.

LSA Repairman Maintenance – U.S. FAA-certificated repairman (light sport aircraft) with a maintenance rating as defined by 14 CFR Part 65, authorized to perform line maintenance on aircraft certificated as special LSA aircraft. Authorized to perform the annual condition/100-h inspection on an LSA, or an equivalent rating issued by other civil aviation authorities.

Maintenance Manual – manual provided by an LSA manufacturer or supplier that specifies all maintenance, repairs, and alterations authorized by the manufacturer.

Major Repair, Alteration, or Maintenance – any repair, alteration, or maintenance for which instructions to complete the task excluded from the maintenance manual(s) supplied to the consumer are considered major.

Manufacturer – any entity engaged in the production of an LSA or component used on an LSA.

Minor Repair, Alteration, or Maintenance – any repair, alteration, or maintenance for which instructions provided for in the maintenance manual(s) supplied to the consumer of the product are considered minor.

Overhaul – maintenance, inspection, repair, or alterations that are only to be accomplished by the original manufacturer or facility approved by the original manufacturer of the product.

Overhaul Facility – facility specifically authorized by the aircraft or component manufacturer to overhaul the product originally produced by that manufacturer.

Repair Facility – facility specifically authorized by the aircraft or component manufacturer to repair the product originally produced by that manufacturer.

14 CFR – Code of Federal Regulations Title 14 Aeronautics and Space also known as the “FARs” or Federal Aviation Regulations.

100-h Inspection – same as an *annual condition inspection*, except the interval of inspection is 100 h of operation instead of 12 calendar months. This inspection is utilized when the LSA is being used for commercial operations such as flight instruction or rental, or both.

(2) ACRONYMS:

100 LL – 100 Octane Low Lead

AC – Alternating Current

ALT – Altimeter

ASTM – American Society for Testing and Materials

AVGAS – Aviation Gasoline

C – Celsius

CG – Center of Gravity

CHT – Cylinder Heat Temperature

DC – Direct Current

EMS – Engine Monitoring System

F – Fahrenheit

FAA – Federal Aviation Administration

GPS – Global Position System

GYRO – Gyroscopic

HP – Horse Power

hr – Hour

in – inches

Kg – Kilograms

Lbs – Pounds

LH – Left

LSA – Light Sport Aircraft

Min - minutes

ml – milliliters

mm – millimeters

MOGAS – Motor Gasoline

N*m – Newton per meter

N/A – Not Applicable

NAV – Navigation

OHV – Overhead Valve

Pcs - Pieces

Psi – Pounds per square inch

PVC – Polyvinyl Chloride

RH – Right

RPM – Revolutions per Minute

STC – Supplemental Type Certificate

TC – Turn and Coordinator

TCAS – Traffic Collision Avoidance System

US Gal – Gallon

V – Volt

VHF – Very High Frequency

XPDR – Transponder

4 SIGNIFICANCE AND USE

The purpose of this maintenance manual is to provide guidance to owners, mechanics, airports, regulatory officials, and aircraft and components manufacturers who may accomplish maintenance, repairs, and alterations on the Super Petrel LS.

5 Aircraft Maintenance Manual

5.1 General

Scoda Aeronáutica Ltda developed this aircraft maintenance manual, which contains the information needed to maintain the Super Petrel Aircraft in an airworthy condition. The Aircraft Maintenance Manual was prepared to meet the ASTM F2483 – Practice for Maintenance and the Development of Maintenance Manuals for Light Sport Aircraft. Nevertheless, information about the engine, propeller and any other equipment not fabricated by Scoda Aeronáutica Ltda will never prevail over information supplied by their own manufacturer.

The provisions set forth in this manual will assist to apply and establish correct procedures. Any further modifications or variations will be advised through Notice of corrective Actions (Safety Alerts, Service Bulletins or Notifications). For further information or explanation, contact Scoda Aeronáutica Ltda.

As defined, a good operating condition, its reliability and ready to fly, achieved by the completion of maintenance of maintenance tasks in due, and the standards prescribed in this manual, or in a separate component manufacturers documentation. To resolve any discrepancies and non-conformities found during inspections and maintenance, qualified personnel using adequate approved methods, tools, and other necessary equipment and spare parts must carry out all inspections and repair.

Only the aircraft's manufacturer, or the manufacturer of a component on the aircraft, may perform or authorize the performance of repair or modification to that aircraft or component.

Because of the fact, this manual contains information that will be useful to any future owners of this aircraft; it must be considered an integral part of the aircraft.

➤ Manufacturer Data

SCODA Aeronáutica LTDA.

Estrada Municipal IPN 020, Km 0,1

Ipeúna – SP, Brazil

ZIP CODE: 13537-000

(19) 37576-1292

engineering@scodaero.com.br

www.scodaeronautica.com.br

➤ Aircraft Description

1. Three Plane View




Figure 5-1

Configuration

Super Petrel LS is an amphibious seaplane with equilibrium floats attached to its lower wings. The ailerons are located in the upper wings and the tail is conventional, with the horizontal stabilizer built half way up the tail cone.

The two seats are side by side with dual controls and equipped with 4-point seat belt. Both seats may be adjusted into three longitudinal positions.

The engine is a pusher configuration attached to the upper wing pylon. A carbon fiber cowling encloses the engine.

Two big doors give access to the enclosed cockpit. Both can be opened / closed from inside and outside using a single rotating lock. It is possible to fly without the doors that are easily removed by removing the cotter pins to pull the hinge pins.

CAUTION

When operating the aircraft without doors, loose objects in the cabin or baggage compartment can fly into the propeller and cause damage.

2. Airframe

Two parts comprise the fuselage: The main fuselage and tail.

The main fuselage is molded in fiberglass, carbon and Kevlar® reinforced by fiberglass/PVC foam bulkheads.

The tail, the horizontal stabilizer and the elevator are molded in carbon fiber and have internal PVC foam reinforcements. The rudder is built using the same process and is covered with fabric.

The upper wings structure has a carbon fiber "C" channel spar, forming a "D" box when bonded to the carbon fiber and fiberglass/PVC foam leading edge. The wing tips are made of carbon fiber and the wings are covered with fabric.

The lower wings are built in the same way; the difference is that tanks are located in the leading edge. The floats are attached to the lower wing's structure.

The struts are made of 6061-T6 aluminum profile.

3. Landing Gear

The main landing gear is equipped with oil pneumatic shock absorbers, hydraulic disk brakes, aluminum wheels and 11x4.00-5 tires with inner tubes. The nose gear is equipped with 10X3.00-4 tire and inner tube.

The landing gear retraction system is manually operated and the operating load of the system is balanced by a gas spring.

4. Flight Controls

Stainless steel cables operate the rudder, the elevator and ailerons are operated by rigid tubes. Elevator trim is electrically operated.

(From aircraft serial number S0380 left aileron contains an electric trim actuator)

Control Ranges:

- **Ailerons:** 17° up / 10° down ($\pm 2^\circ$)
- **Elevator:** 30° up / 20° down ($\pm 2^\circ$)
- **Rudder:** 30° Left / 30° Right ($\pm 2^\circ$)
- **Elevator Electric Trim:** 15° up / 13° down ($\pm 2^\circ$)
- **Aileron Electric Trim:** 20° up / 18° down ($\pm 2^\circ$)
(From aircraft S0380)

5. Instrument Panel and Flight Instruments

The typical instrument panel contains all flight, navigation and engine instruments that are required for day and night operations. Switches are located as follows:

- **Engine Panel:** Located on the left side of the instrument panel.
- **Lights Panel:** Located in the middle of the instrument panel below the GPS.
- **Miscellaneous Panel:** Located on the center console.
- **Circuit Breaker Panel:** Located on the right side of the instrument panel.

The instrument panel for each aircraft is detailed on the Instrument Panel and Flight Instruments Supplement of the Pilot's Operating Handbook.

6. Engine

The aircraft is powered by Rotax Aircraft Engines. This may be equipped with three versions of engine:

- 912 ULS
- 914 UL
- 912 iS Sport

7. Propeller

The aircraft is equipped with three blade propellers with ground adjustable pitch:

- POWERFIN PROPELLERS Model F 65"
- DUC Three-Blade Inconel FLASH – 2 propeller

5.1.1 Equipment List

Typical Equipment List is divided into Avionics, Emergency Equipment, Miscellaneous, Engine, Propeller, Lights and Others. This includes the following items:

- Description
- Manufacturer Part Number
- Serial Number
- Weight
- Arm

The actual equipment list is detailed on the Equipment List Supplement of the Pilot's Operating Handbook.

5.1.2 Supply Sources for Parts

Spare parts and components can be ordered from their respective manufacturers, except structural parts, which can only be ordered from Scoda Aeronáutica Ltda. or an authorized reseller using the Super Petrel LS Illustrated Parts Catalogue. Follows below a list of sources according to the assembly:

PARTS	SOURCE
General Assemblies	Scoda Aeronáutica Ltda
Materials for Major Repairs	Contact Scoda Aeronáutica Ltda: major repairs are not authorized.
Hardware	Scoda Aeronáutica Ltda / Aircraft Spruce
Instruments / Avionics	Scoda Aeronáutica Ltda / OEM (Original Equipment Manufacturer)
Engine Parts	Scoda Aeronáutica Ltda / Rotax
Propeller Parts	Scoda Aeronáutica Ltda / DUC Hélices

5.1.3 List of Disposable Replacement Parts

The following table shows a list of commonly replaced parts, as well as the components with lifetime limitations.

SYSTEM	ITEM	SPECIFICATION	PART NUMBER	SUPPLIER	INTERVAL	ACTION
ENGINE	Air Filter (912 ULS)	K&N Universal Clamp-On Air Filter	RC – 1820	K&N Scoda Aeronáutica Ltda	100 h	Clean or Replace
	Air Filter (914 UL / 912 iS Sport)	K&N Universal Clamp-On Air Filter	RU-0800 (Rotax P/N: 825750)	K&N Scoda Aeronáutica Ltda Rotax	100 h	Clean or Replace
	Engine Mount (all engines)	Lord Engine Mount	J-3608-1	LORD Corp. Scoda Aeronáutica Ltda	On Condition	Replace
	Tension Spring	N/A	SE-412.002-2	Scoda Aeronáutica Ltda	100 h	Replace
	Exhaust Muffler (912 ULS / 912 iS Sport)	Rotax Muffler Assy. (Altered)	SE-412.005-3	Scoda Aeronáutica Ltda	On Condition	Replace
	Fine Fuel Filter (912 iS Sport)	Rotax Fine Fuel Filter	874060	Rotax Scoda Aeronáutica Ltda	After first 100h and every 200h (max. 2 years)	Replace
FUEL	Inline Fuel Filter (912 ULS / 914 UL)	Inline Fuel Filter 3/8" 100 micron	HLV-162-551	Summit Racing Scoda Aeronáutica Ltda	100 h	Clean or Replace filter elements
	Inline Fuel Filter (912 iS Sport)	Inline Fuel Filter 3/8" Fuel Lines 62 micron	FX375-M	Andair Scoda Aeronáutica Ltda	100 h	Clean or Replace
			FX375-MK (NPT MALE OUTPUT) (an adapter 6AN Male to 1/4 NPT Female should be used)			
	Fuel Selector Valve	1/4" Female Fuel Valve 4-Port	05-01033 PI-530.013	Aircraft Spruce Scoda Aeronáutica Ltda	On Condition	Replace
	Fuel Shut Off Valve	1/4" Female Fuel Valve 4-Port	05-01033 PI-530.013	Aircraft Spruce Scoda Aeronáutica Ltda	On Condition	Replace

SYSTEM	ITEM	SPECIFICATION	PART NUMBER	SUPPLIER	INTERVAL	ACTION
NOSE GEAR	Nose Landing Gear Tire	10x3.00-4 – 4 Ply	TIRT 3.00-4 PI-312.003	MATCO Mfg or Similar Scoda Aeronáutica Ltda	On Condition	Replace
	Nose Landing Gear Tire Inner Tubes	Leak-Guard Tube 410/350-4 TR-87	06-00761 PI-312.004	Aircraft Spruce Scoda Aeronáutica Ltda	On Condition	Replace
	Nose Landing Gear Wheel	N/A	SE-311.026	Scoda Aeronáutica Ltda	On Condition	Replace
	Nose Gear Bearing	Radial Ball Bearing SS6302-2RS	SS6302 2RS PI-312.040	Tritan or similar Scoda Aeronáutica Ltda	On Condition	Replace
	Nose Gear Covering Plates - Left	N/A	SE-312.005-1	Scoda Aeronáutica Ltda	On Condition	Replace
	Nose Gear Covering Plates - Right	N/A	SE-312.002-1	Scoda Aeronáutica Ltda	On Condition	Replace
MAIN GEAR	Main Landing Gear Tires	11x4.00-5 – 8 Ply	06-01573 PI-311.025	Aircraft Spruce Scoda Aeronáutica Ltda	On Condition	Replace
	Main Landing Gear Tire Inner Tubes	11 X 400 X 5 Tube	15-04651 PI-311.027	Aircraft Spruce Scoda Aeronáutica Ltda	On Condition	Replace
	Main Landing Gear Wheel	N/A	SE-311.015-1	Scoda Aeronáutica Ltda	On Condition	Replace
	Main Landing Gear Bearings	Radial Ball Bearing SS6004-2RS	SS6004-2RS PB-311.076	Tritan or similar Scoda Aeronáutica Ltda	On Condition	Replace
	Gas Spring	N/A	SE-323.050	Scoda Aeronáutica Ltda	On Condition	Replace
	Shock Absorber	N/A	SE-323.120	Scoda Aeronáutica Ltda	On Condition	Replace
	Shock Absorber 40mm (MTOW – 1430 lb / 650 kg)	N/A	SE-323.120-1	Scoda Aeronáutica Ltda	On Condition	Replace
CONTROLS	Control Cable	Xtreme Control Cable 9' length / 10' length	CCX633-09 CCX633-10	SeaStar Solutions Scoda Aeronáutica Ltda	On Condition	Replace
BRAKES	Brake Pads + Caliper Set	N/A	SE-520.022	Scoda Aeronáutica Ltda	On Condition	Replace
	Brake Discs	N/A	PB-520.023	Scoda Aeronáutica Ltda	On Condition	Replace
BATTERY	Battery	12-Volt / 18AH Sealed Lead Acid or Gel Battery	N/A	Aircraft Spruce	On Condition	Replace

5.1.4 Engine Specifications

The Super Petrel LS is powered by Rotax Aircraft Engines. This may be equipped with three versions of engine:

- 912 ULS
- 914 UL
- 912 iS Sport

NOTE

For engine parameters information please refer to the latest revision of the Operator's Manual for the applicable ROTAX engine or the Pilot's Operating Handbook supplied with the aircraft.

5.1.5 Weight and Balance Information

Super Petrel LS is structurally and aerodynamically engineered for certain load conditions which result from specific weights and forces anticipated to occur in normal operations within the specified flight envelope.

WARNING

**AIRCRAFT'S HANDLING QUALITIES AND STRUCTURAL INTEGRITY MAY BE SERIOUSLY COMPROMISED
IF THE WEIGHT AND BALANCE LIMITS ARE EXCEEDED.**

For further information regarding Weight and Balance Practices, refer to the Chapter 10. Weight and Balance of the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – AIRCRAFT INSPECTION, REPAIR AND ALTERATION ACCEPTABLE METHODS, TECHNIQUES, AND PRACTICES

Definitions:

ARM: The horizontal distance from the reference datum to the center of gravity (CG) of an item.

BASIC EMPTY WEIGHT: Standard empty weight plus optional equipment.

CENTER OF GRAVITY (CG): The point at which an airplane would balance if suspended. Its distance from the reference datum is determined by dividing the total moment by the total weight of the airplane.

CG ARM: The arm obtained by adding the airplane's individual moments and dividing the sum by the total weight.

CG LIMITS: The extreme center of gravity locations within which the aircraft must be operated at a given weight.

DATUM: An imaginary vertical plane from all horizontal distances are measured for balance purposes.

MOMENT: The product of the weight of an item multiplied by its arm.

MAXIMUM LANDING WEIGHT: Maximum weight approved for the landing touchdown.

MAXIMUM TAKEOFF WEIGHT: Maximum weight approved for the start of the takeoff run.

PAYLOAD: Weight of occupants, cargo, and baggage.

STANDARD EMPTY WEIGHT: Weight of a standard airplane including unusable fuel, full operating fluids, and full oil.

UNUSABLE FUEL: Fuel remaining after a runout test has been completed in accordance with governmental regulations.


USABLE FUEL: Fuel available for flight planning.

USEFUL LOAD: Difference between takeoff weight and basic empty weight.

5.1.5.1 Weight and Balance Chart

The aircraft total weight and the aircraft empty weight center of gravity location should be checked:

- After Major repairs.
- After repainting.
- After fitting the airplane with additional equipment apart from its manufacturing configuration.



Nº	Equipment	Arm
1	Propeller	-32 in (-82 cm)
2	Fuel	12 in (31 cm)
3	Baggage	13 in (32 cm)
4	Pilot / Passenger	33 in (85 cm)
5	Instruments	53 in (135 cm)
6	Nose Wheel	81 in (205 cm)
7	Battery	82 in (208 cm)
8	Ballast	82.5 in (210 cm)

Figure 5-2

5.1.5.2 Empty Weight Center of Gravity Location

Weighing Procedure

The center of gravity must be determined with the airplane fully equipped according to the Equipment List of the corresponding aircraft.

Be sure to remove any items not listed in the Equipment List (such as rags, charts, tools, etc.) from the aircraft prior to weighing.

NOTE

Weighing the aircraft in a hangar with doors closed where the wind will not affect the readings of the scales.

1. Clean the aircraft in order to remove dirt and grease.
2. The fuel tanks should be empty except for unusable fuel.
3. Oil, coolant and reservoir tanks must be properly filled before weighing.
4. Put the airplane on three scales (one under each wheel) or one scale with leveling blocks. The scales must be calibrated correctly. All the scales must be set on level ground.



Figure 5-3

5. The aircraft must be weighed in a level flight attitude, both laterally and longitudinally (front to back).

Laterally: Put a digital level in the stainless steel triangle located behind the seats, which is connected to the main struts in order to obtain 0°.

Longitudinally: Put a digital level on the Tail cone insertion part in the fuselage. Put a chock under the nose wheel in order to obtain 12°.




Figure 5-4

6. Put a load of 20 lbs (10 kg) on the aircraft nose. That load must be aligned with nose gear axis.
7. After recorded the data (Nose, LH and RH weights), it should be subtracted the load of 20 lbs (10 kg) from the nose weight. Example: On the display is reading 11 lbs (5 kg), so the total weight of the nose is -9 lbs (-5 kg).
8. The mechanic or repairman who conducts a weight and balance procedure must ensure that the weight and balance data in the aircraft records is updated and accurate.

NOTE

It is the pilot's responsibility to use the most updated weight and balance data when operating the aircraft.

WARNING

THE TOTAL WEIGHT OF THE AIRCRAFT MUST BE NO GREATER THAN THE MAXIMUM WEIGHT ALLOWED AND THE CENTER OF GRAVITY MUST BE MAINTAINED WITHIN THE ALLOWABLE LIMITS.


5.1.5.3 Loading Method

LOADING CHART

Aircraft Serial Number: S0_____ Date: _____

Registration Number: _____ Owner: _____

Item		Weight Lbs (Kg)	x	Arm	=	Moment lbs x in (kg x cm)
	Empty Weight		x		=	
	Pilot		x	33 in (85 cm)	=	
	Pax		x	33 in (85 cm)	=	
	Baggage		x	13 in (32 cm)	=	
	Ballast		x	82.5 in (210 cm)	=	
Fuel Left Tank	10 US GAL/38 LTR		x	12 in (31 cm)	=	
Fuel Right Tank	10 US GAL/38 LTR		x			
Header Tank	4 US GAL/17 LTR		x			
Total Weight =			Total Moment =			
Center of Gravity		Total Moment	/	Total Weight	=	CG:_____ in (cm)
THE VALUE OF CG MUST BE HIGHER THAN 7.5 in (19 cm) AND LOWER THAN 11.8 in (30 cm)						



1. Multiply each item's weight times its arm to find the moment. Record each on its respective line.
2. Add all the weights and moments and record each on its respective total line.
3. Divide the total moment by the total weight and the result is the CG.
4. Determine that the airplane's Loaded CG. falls within the applicable limits (Forward and Aft CG. Limits).

SAMPLE LOADING CHART (Maximum Forward CG)

Item		Weight Lb (Kg)	x	Arm	=	Moment lb x in (kg x cm)
	Empty Weight	784 Lbs	x	0	=	0
	Pilot	250 Lbs	x	33 in (85 cm)	=	8250 Lb.in
	Pax	182 Lbs	x	33 in (85 cm)	=	6006 Lb.in
	Baggage	60 Lbs	x	13 in (32 cm)	=	0
	Ballast	0	x	82.5 in (210 cm)	=	0
Fuel Left Tank	6.6 US Gallons	60 Lbs	x	12 in (31 cm)	=	720 Lb.in
Fuel Right Tank	6.6 US Gallons	60 Lbs	x			720 Lb.in
Header Tank	4 US Gallons	24 Lbs	x			288 Lb.in
Total Weight =		1430	Total Moment =			16674 Lb.in
Center of Gravity		Total Moment	/	Total Weight	=	CG: 11.723 in
THE VALUE OF CG MUST BE HIGHER THAN 7.5 in (19 cm) AND LOWER THAN 11.8 in (30cm)						

SAMPLE LOADING CHART (Maximum AFT C.G)

Item		Weight Lb (Kg)	x	Arm	=	Moment lb x in (kg x cm)
	Empty Weight	784 lbs	x	0	=	0
	Pilot	110 lbs	x	33 in (85 cm)	=	3630 Lb.in
	Pax	0 lbs	x	33 in (85 cm)	=	0
	Baggage	0 lbs	x	13 in (32 cm)	=	0
	Ballast	44 lbs	x	82.5 in (210 cm)	=	3630 Lb.in
Fuel Left Tank	0 US Gallons	0 lbs	x	12 in (31 cm)	=	0
Fuel Right Tank	0 US Gallons	0 lbs	x			0
Header Tank	2.5 US Gallons	15 lbs	x			180 Lb.in
Total Weight =		953	Total Moment =			7440 Lb.in
Center of Gravity		Total Moment	/	Total Weight	=	CG: 7.8 in
THE VALUE OF CG MUST BE HIGHER THAN 7.5 in (19 cm) AND LOWER THAN 11.8 in (30 cm)						

5.1.5.4 Operating Weights and Loading

5.1.5.4.1 Weight Definitions

Maximum Takeoff Weight	1430 lbs (650 kg)
Maximum Landing Weight	Maximum Takeoff Weight
Maximum Empty Weight	1010 lbs (459 kg)
Typical Empty Weight	810 lbs (368 kg)
Basic Empty Weight	788 lbs (358 kg)
Minimum Useful Load	420 lbs (191 kg)

NOTE

The limits of CG range are measured forward of Datum.

5.1.5.4.2 Center of Gravity Forward and Aft Limits

Forward C.G. Limit	Maximum Takeoff Weight with heavy passenger and pilot, full fuel tank and 90% of the baggage capacity (Approx. 60 lbs). <i>SEE SAMPLE LOADING CHART (Maximum Forward CG.)</i>
Aft C.G. Limit	With a very light pilot only and reserve fuel. <i>SEE SAMPLE LOADING CHART (Maximum AFT CG.)</i>

5.1.5.4.3 Baggage Compartment

The baggage compartment is located next to the CG, therefore has little effect on the balance. The baggage area is located behind the seats, above the main landing gear.

The baggage area limit is 66 lbs (30 kg)

NOTE

The maximum baggage load will be limited by the MTOW.

5.1.5.4.4 Ballast Tank

NOTE

The aircraft is equipped with a ballast tank, located next to the nose gearbox. When the occupants' total weight (Pilot and Passenger) is less than 290 lbs (132 kg), additional ballast will be necessary. The minimum required ballast added is located in the following table:

Weight (PILOT+ PASSENGER)		MINIMUM BALLAST WEIGHT	BALLAST
120 – 210 lbs	54,4 – 95 kg	44 lbs (20 kg)	1/1
210 – 290 lbs	95 – 132 kg	22 lbs (10 kg)	1/2
above 290 lbs	above 132 kg	0 lbs (0 kg)	0

5.1.5.4.5 Center of Gravity (CG) range

Longitudinal Limits

DATUM	Main Landing Gear Shaft
Forward Limit	11.8 in (30 cm)
Aft Limit	7.5 in (19 cm)

Procedure

Chart above (in order to calculate the final position of the CG).

NOTE

It is the pilot's responsibility to use the most updated weight and balance data when operating the aircraft.

WARNING

THE TOTAL WEIGHT OF THE AIRCRAFT MUST BE NO GREATER THAN THE MAXIMUM WEIGHT ALLOWED 1430 LBS (650 KG) AND THE CENTER OF GRAVITY MUST BE MAINTAINED WITHIN THE ALLOWABLE LIMITS 11.8 in (30 cm) and 7.5 in (19 cm)

5.1.6 Tire Inflation Pressures

The recommended tire inflation pressures are:

TIRES	MINIMUM PRESSURE	MAXIMUM PRESSURE
Nose Wheel Tire	20 PSI	28 PSI
Main Wheel Tires	32 PSI	40 PSI

AIRCRAFT TIRE CARE RECOMMENDATIONS

(Reference: FAA ADVISORY CIRCULAR 65-15A – AIRFRAME OF POWERPLANT MECHANICS)

Tires are as vital to the Operation of aircraft as they are to the Operation of an automobile. During ground operation tires can be considered as ground control surfaces. Contrary to what most people think including many beginning pilots, the toughest demand on aircraft tires is rapid heat buildup during lengthy ground operation, not the impact of hard landings.

The best safeguards against heat buildup in aircraft tires are short ground rolls, slow taxi speeds, minimum braking, and proper tire inflation. Proper inflation assures the correct amount of flexing and keeps heat buildup to a minimum, increasing tire life and preventing excessive tread wear. Inflation pressure should always be maintained as specified in the aircraft maintenance manual.

Even though using a tire gage is the only accurate way to spot-check inflation, a quick visual inspection of the

thread can reveal if air pressure has been consistently high or low. Excessive wear in the shoulder area of the tire is an indication of under inflation. Excessive wear in the center of the tire suggests over inflation.

Tire pressures should be checked with an accurate gage at least once a week or oftener, and it is recommended that they be checked before each flight. Otherwise, if a slow leak should develop, it could cause severe loss of air within two or three days, with resulting damage to the tire and tube. Air pressures should be only checked when tires are cool. Wait at least two hours after a flight before checking pressures (three hours in hot weather).

SUMMARIZING THE PROPER INFLATION PRESSURE IS ONE OF THE MOST IMPORTANT MAINTENANCE PROCEDURES TO ACHIEVE LONG TIRE LIFE:

- Inflation pressure practices are essential for balanced wear and durability.
- Perform weekly inflation checks with a calibrated pressure gauge.
- Inflation pressures can be obtained from the POH and Maintenance Manual of the Super Petrel LS.
- Underinflation can:
 - Reduce casing life
 - Cause fast wear
 - Cause irregular wear
 - Reduce fuel economy
 - Cause sudden tire destruction
- Over inflation can:
 - Decrease resistance to punctures and impacts
 - Reduce tire footprint size
 - Cause irregular shoulder wear
 - Cause improper handling
 - Cause ride and handling disturbances
 - Cause reduced traction

NOTE

In addition, it is recommended to consult the latest edition of the **FAA ADVISORY CIRCULAR AC 20-97B – AIRCRAFT TIRE MAINTENANCE AND OPERATIONAL PRACTICES.**

5.1.7 Approved Oils and Capacities

5.1.7.1 Engine

For selection of suitable operating fluids for ROTAX Engine type 912 i, 912 and 914 (Series), refer to the latest edition of the Rotax Service Instruction SI-912 i-004 / SI-912-016 / SI-914-019.

- **Engine Oil:** Perform maintenance checks according to the latest Rotax Maintenance Manual. In accordance to the latest edition of the Rotax Service Instruction SI-912 i-004 / SI-912-016 / SI-914-019 the frequency of oil changes must be increased regardless off the type of fuel mainly used (MOGAS or AVGAS).

- **Oil Specification:** Motor oils tested and released by BRP-Rotax (for use MOGAS or AVGAS), which Rotax recommended for use with their ROTAX engine types 912 i, 912 and 914 Series: **SHELL® AeroShell Oil Sport Plus 4 (SAE 10 W-40)**

Oil Level: It should be in the middle of the dipstick:




Figure 5-5

- **Engine Coolant:** Remember that different coolants **cannot be mixed**. In accordance to the latest edition of the Rotax Service Instruction SI-912 i-004 / SI-912-016 / SI-914-019, in principle 2 different types of coolant are permitted:
 - Conventional coolant based on ethylene glycol with 50% water (50 / 50).
 - Waterless coolant based on propylene glycol.
- **Coolant Specification:** Aircraft manufacturer recommends the use **Honda Genuine Coolant Type 2 – All season antifreeze or similar**
- **Coolant Level:** It should be in the middle of the overflow bottle:




Figure 5-6

5.1.7.2 Brake Fluid

Super Petrel LS uses ATF (Automatic Transmission Fluid) Type A Suffix A in the lines of the brake system.

Brake Fluid Specification: The aircraft manufacturer recommends the use of **Shell ATF Type A Suffix A** or **AeroShell Fluid 41**

CAUTION

It is not allowed the use of DOT type brake fluid.

5.1.8 Recommended Fastener Torque Values

DESCRIPTION	TORQUE VALUE
Firewall Bolts M10 (912 ULS, 912 iS Sport)	350 lb.in (40 N.m)
Firewall Bolts M8 (914 UL)	180 lb.in (20 N.m)
Engine Suspension Frame Bolts M10 (912 ULS, 914 UL, 912 iS Sport)	350 lb.in (40 N.m)
Hub Bolts M8 (DUC Propeller)	220 lb.in (25 N.m)
Blades Bolts M8 (DUC Propeller)	220 lb.in (25 N.m)
Horizontal Stabilizer Bolts M8 (Empennage)	70 lb.in (8 N.m)
Front and Rear Fixation Bolts M8 (Upper Wings)	130 lb.in (15 N.m)
Rear Fixation Bolt M8 (Lower Wings)	130 lb.in (15 N.m)

CAUTION

Struts bolts torque values are not specified. These locknuts should be tightened until they are secure with at least one (1) thread protruding passed the nut.

For general information regarding aircraft hardware torque values and practices, refer also to the latest edition of **FAA ADVISORY CIRCULAR AC 43.13-1B Chapter 7**.

5.1.9 General Safety Information

There are many hazards inherently present when performing any maintenance task on this aircraft. To minimize the risk to owner, mechanic and others, begin by thinking through each task that is to be performed before starting any work. Use common sense, think of ways to avoid these hazards. Remember also that many accidents happen because of carelessness. Be sure to also use the right tool for the task at hand to use the proper personal protective equipment. Such equipment may include, but is not limited to:

- Eye protection
- Gloves
- Hearing protection – ear plugs or muffs
- Protective footwear with non-slip soles

You should also keep on hand a suitable fire extinguisher, absorbent material to contain spills, an eyewash bottle, and a general-purpose first aid kit. It is also advisable to have on hand the material safety data sheet (MSDS) for all products and chemicals that will be used during the servicing of the aircraft.

While carrying out tasks on the airplane, strictly observe some safety precautions:

- Avoid exposing the main fuselage to temperatures above 140° F (60° C).
- Never move the aircraft by pushing it by the wings, specially the trailing edges.
- Do not step on the wings, tail cone or horizontal stabilizer.
- Do not rest machines or containers on the airplane skin.
- Never leave the ignition switch or the master switch turned on when the engine is not running.
- Never operate the engine with untrained personnel around.
- Remove any loose clothing, such as hats, neckties and scarves. Tuck in your shirt and secure any long hair to prevent them from becoming tangled in power tools.
- Remove all jewelry. Not only can items such as rings, watches, and necklaces become caught in rotating tools, they can also conduct electricity and may cause a short circuit. This could result in burns or damage to electrical circuits.
- Disconnect the negative lead from the battery when doing any electrical work that does not involve trouble shooting the electrical systems. This will reduce the risk of a short circuit or even a fire.
- Aviation gasoline is also highly flammable. When working with the fuel system, always work in a well-ventilated environment. Any nearby source of ignition such as sparks or an open flame can result in a fire or explosion. Keep all ignition sources away. Always ground the airframe to a suitable earth ground during fueling/defueling operations to reduce the risk of a static discharge ignition source.
- When working with dangerous chemical substances (adhesives, thinners), use adequate protective equipment such as goggles, gloves, etc.
- When working with the landing gear, always support the aircraft properly with jacks. Do not work underneath the aircraft unless it is properly supported.
- For engine's assembling or disassembling, use only adequate and tested lifting equipment.
- While running the engine on the ground, keep away from the propeller.
- Upon completion of work, carefully check to remove tools and unwanted objects from the airplane.

5.1.9.1 Ground Handling

5.1.9.1.1 Towing

The aircraft can be moved manually, this can be executed by pushing or pulling the wing struts. Also, the nose of the aircraft can be pushed, to turn the aircraft, lift the nose and spin it around the main wheels. Refer to Figure 5-2.

To tow the aircraft, one person is required:

1. Make sure the space near the aircraft is clear of obstacles and people.

2. Pull the nose of the aircraft up using the front wheel opening in the hull as a handle.
3. Push the aircraft in the needed direction.





Figure 5-7

5.1.9.1.2 Jacking Up

This process is only used to change the wheels or to make the operational test of the landing gear system. One person is required to lift the nose of the aircraft and put a support under the keel located under the fuselage. Then put a jack under each point of the main gear as shown below.

NOTE

Raise the aircraft no more than required for maintenance being performed.

CAUTION

Use protective foam among the support – keel and jack – fuselage

CAUTION

Lift the aircraft simultaneously with the jack placed in each point of the main gear, do not lift too high, just enough to let the wheels turn freely.

CAUTION

In order to prevent accidents, injuries or damage to the aircraft structure, the block or adapter using for jacking the aircraft up need to have a minimum area of 36 square inches.

CAUTION

Do not jack the airplane outside or in open hangar with winds in excess.

Landing Gear System Maintenance and Test

This process is only used to make the operational test of the landing gear system. One person is required to lift the nose of the aircraft and put a support under the keel located under the fuselage. Then put a jack under each point of the main gear.

CAUTION

Preferably, put protective foam among the support – keel and jack – fuselage. Lift the aircraft simultaneously with the jack placed in each point of the main gear, do not lift too high, just enough to let the wheels turn freely.

Nose Tire Replacement

- Activate the parking brake.
- Lift the nose of the aircraft up until the fuselage rear part support on the floor.
- Place chocks in the main gear wheels.

Main Gear Tires Replacement

- Activate the parking brake.
- Place a chock under the opposite main gear wheel and nose gear.
- Place a jack under the main gear leg and lift enough to let the wheel turn freely.

CAUTION

Preferably, put protective foam among the support and jack.



(a) Support under the keel



(b) Jack under the main gear



(c) Aircraft lifted

Figure 5-8

5.1.9.1.3 Parking

To accomplish this process it is good to know the local conditions. It is advisable to place chocks in each wheel of the main gear (as shown below) to avoid any displacement of the aircraft during the inspection. There is no need to place a chock in the nose wheel.



Figure 5-9

5.1.9.1.4 Tie-Down Instructions

To tie the aircraft down, one person is required:

1. Make sure the plane is set on the wheel chocks.
2. Attach the tie down lines to the support of the wing struts and nose gear.
3. Attach the lines to the mooring arrangements on the ground. Make sure the lines are taught.



Figure 5-10

CAUTION

If the aircraft is left in the sunlight, do not use dark covers. Preferably, use a white light cover.

5.1.9.2 Cleaning and Care

The washing and cleaning of the aircraft can be made according to the criteria of the owner; it is not obligatory for each inspection. When washing and cleaning the aircraft the following steps are recommended:

5.1.9.2.1 Canopy External Part

CAUTION

Only recommended cleaning products should be used to clean the aircraft's canopy.

1. Spray enough water on the surfaces.
2. Spread generously with a good quality neutral soap over the entire surface of the aircraft.
3. Pass the palm of your hand and fingers softly, spreading the soap forward and backward (lengthwise).

CAUTION

Do not make circular moves.

4. Remove insects and dirt which can eventually cause staining. Do it with your fingernail. **(Slightly)**.
5. Wash and remove remaining dirt, repeating the process only on that spot.
6. Apply a specific product for Plexiglass cleaning and gently dry with a clean and new soft cloth.
7. If polishing is needed it must be done at the moment in order to complete the surface cleaning as following:
 - Use specific product for Plexiglass polishing.
 - Open it carefully in order to not spill dust into the recipient.
 - Remove a thin layer of polish and throw it away.
 - Use only a clean piece of cotton.
 - Complete the polishing moving the piece of cotton forward and backward.

5.1.9.2.2 Canopy Internal Part

1. Sprinkle specific product for Plexiglass cleaning generously.
2. Clean softly with a clean and new piece of cotton.

5.1.9.2.3 Fuselage External Part (Wings / Tail)

CAUTION

When washing the aircraft with high-pressure water spray, careful must be taken with avionics, connectors and sensors.

1. Seal the Pitot tube, vents, etc., with masking tape.
2. Seal the possible water intakes in the aircraft with masking tape.
3. Use a good quality neutral soap.
4. Soap the surface with a clean and soft cloth.
5. Wash the surface generously.
6. Wipe clean all surfaces with a clean cloth.
7. If necessary polish the entire surface with a specific product for polishing.

WARNING

IN THE END OF WASHING REMOVE ALL SEALS FROM COVERED COMPONENTS.

5.1.9.2.4 Fuselage Internal Part

1. Clean the seats with a neutral soap with a clean and new cloth.
2. Hydrate the skin of the seats with liquid Vaseline if necessary.

5.1.9.2.5 Salt Water Care

CAUTION

After every flight when aircraft has been in contact with salt water, remove all traces and residue of salt water by thoroughly washing the aircraft with fresh water.

- Aircraft external structure should be kept clean, and painted surfaces should be kept waxed and polished. Rinsing the salt off the aircraft with large volumes of water is imperative. All drain holes should be kept free.
- Aircraft interior should be washed out regularly, specifically the floor should be flushed and washed out to prevent salt water from accumulative inside the aircraft structure.
- Aircraft landing gear components should be washed out and lubricate regularly to prevent salt water and moisture accumulation.

5.1.10 Safety of Flight Report

Instructions for reporting possible safety of flight concerns found during inspection / maintenance

According to the latest edition of the ASTM F2295 – Continued Operational Safety Monitoring, owner / operator shall be responsible for notifying the manufacturer of any safety of flight issue or significant service difficulty upon discovery.

Please report any service difficulties or any other issue relating to flight safety directly to Scoda Aeronáutica Ltda using the FORM_SPLS_002_Continued Operational Safety Reporting Form on Scoda Aeronáutica's website and sent via email to engineering@scodaero.com.br.

5.2 Inspections

This section is intended to serve as a guide for an Owner, LSA Repairman Maintenance (LSRM) and A&P to perform routine maintenance on the aircraft. It is the responsibility of the owner / operator to maintain the aircraft in an airworthy condition and ensure that all applicable Notice of Corrective Actions have been complied with. This inspection guide is not intended to replace the good judgment of an Owner, LSRM and A&P.

The guide will make reference to service information provided by other OEM (Original Equipment Manufacturer), such as the engine, propeller and avionics manufacturer. The latest editions of the OEM publications should be consulted prior to inspections / repairs; this guide will not make reference to revision levels of these publications.

NOTE

Inspection Form Checklist can be found in the Appendix Section of this Manual

Inspections Groups and Criteria

(1) VISUAL INSPECTION

Visual inspection will normally apply to those areas, surfaces, and/or items that become visible by the removal or opening of access doors, panels, fairings, or cowlings. Visual inspection criteria will normally consist of, but are not limited to the following criteria:

(A) Moving Parts

Proper operation, correct alignment, security, sealing, cleanliness, lubrication, adjustment, tension, travel, condition, binding, excessive wear, cracking, corrosion, deformation, and any other apparent damage.

(B) Fabric Covered Parts

Security, condition, cleanliness, wear, cracking, obstruction of drainage or vent holes, deformation, heat deterioration, fluid saturation, and any other apparent damage.

(C) Metal Parts

Security, condition, cleanliness, wear, cracking, obstruction of drainage or vent holes, deformation, heat deterioration, fluid saturation, and any other apparent damage.

(D) Fuel and Hydraulic Oil Lines and Hoses

Cracks, dents, kinks, loss of flexibility, deterioration, obstruction, chaffing, improper bend radius, cleanliness, security, and any other apparent damage.

(E) Electrical Wiring

Cleanliness, loose, corroded, or broken terminals; chaffed, broken, or worn insulation; security, heat deterioration, and any other apparent damage.

(F) Bolts and Nuts

Fretting, wear, damage, stretch, proper torque and safety wiring.

(G) Filters and Screens

Filters and screens shall be removed, cleaned, inspected for contamination, or replaced as applicable.

(H) Fuel Tank Areas

Evidence of leaks.

NOTE

Inspection forms in the Appendix Section may be used as a guidance to perform the visual inspection.

(2) OPERATIONAL INSPECTION

An operational inspection is a check intended to determine that a component or system is fulfilling its intended purpose. The operational inspection does not require quantitative tolerances.

(3) FUNCTIONAL INSPECTION

When called for by an inspection task, a functional inspection is a quantitative check to determine if one or more functions of a component perform within specified limits. The functional inspection is a comparative examination of a component or system against a specific standard.

5.2.1 Condition Inspection Checklist

According to the latest revision of the ASTM F2483 standard, all LSA category airplanes must undergo a complete inspection at least once every 12 calendar months. An authorized maintenance person, as described in the latest revision of ASTM F2483 standard, must perform this inspection. A signed and dated record must be maintained as each inspection task is completed. When the last task of the inspection has been completed, the Inspection Report is to be signed off in the logbook / maintenance record. The inspection items to be covered in the condition inspection are identical to the 100-hour Inspection items. The inspection interval to the next condition inspection may not exceed twelve calendar months.

5.2.2 Periodic Inspection Tasks

If the aircraft is operated commercially (for hire), it must also have an inspection every 100 flight hours. The 100-hour interval between inspections should never be exceeded by more than 10 hours, and then only if additional time is required to reach a place where the inspection can be satisfactorily accomplished. Additionally, the time or interval that was exceeded must be included as flight hours in the next 100-hour interval. Inspection tolerances cannot be accumulated.

NOTE

Scoda Aeronáutica Ltda considers the inspections described in the following chapters as mandatory / obligatory to ensure the safe operation of the Super Petrel LS. Therefore, strictly follow the instructions as hereunder.

5.2.3 Level of Certification

Owner	Items that can be expected to be completed by a responsible owner who <u>holds a pilot certificate</u> (at least a sport pilot certificate) but who has not received any specific authorized training.
LSA Repairman Maintenance (LSRM)	Items that can be expected to be completed on a SLSA by a responsible individual who holds a FAA repairman certificate (light sport aircraft), with a maintenance rating or equivalent.
A&P	Items that can be expected to be completed by a responsible individual who holds a mechanic certificate with airframe or powerplant ratings, or both, or equivalent.
Task Specific	Items that can be expected to be completed by a responsible individual who holds either a mechanic certificate or a repairman certificate and has received task specific training to perform the task.

5.2.4 Inspections Schedule

The interval periods for the inspections noted in this schedule are based on normal usage under average environmental conditions. Airplanes operated in humid tropics, cold damp climates, etc. may need more frequent inspections for wear, corrosion, lubrication, and / or lack of maintenance. Under these adverse conditions, perform periodic inspections in compliance with this guide at more frequent intervals may be necessary.

CAUTION

Inspection schedule of this Maintenance Manual was made for aircraft which operate on normal environmental conditions. Aircraft which operate on salt water environment may need shorter intervals in the inspections schedule, as necessary.

NOTE

Refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43-4B, CORROSION CONTROL FOR AIRCRAFT.

The recommended periods do not constitute a guarantee that the item will reach the period without malfunction, as in-service factors cannot be controlled by the manufacturer. Any item on the aircraft should be repaired, overhauled, or replaced when inspection or performances of these items reveal a potentially unserviceable or unsafe condition.

NOTE

SCODA AERONAUTICA cannot accept any responsibility for the quality of work performed in the inspections. Please refer to the last revision of the Advisory Circular 43.13 – 1B Aircraft Inspection, repair and Alterations Acceptable Methods, Techniques, and Practices.

5.2.4.1 Daily Inspection

The daily inspection should be performed after assembling, maintenance scheduled or before every flight day of the aircraft. Special attention must be devoted to the parts, which are affected by the high vibrations and high temperatures from the powerplant.

The scope of this inspection is specified in the preflight inspection Section of the Pilot's Operating Handbook. Besides the preflight inspection, the following items should be inspected:

- All control surfaces for full and free movement.
- Aircraft structure surfaces.
- Wings fabric covering.
- Powerplant and propeller.
- Service fluids.
- Electrical Fans (Cooling System) **(912 iS Sport only)**
- ELT (Armed position)
- Vents for obstruction

Level of Certification: OWNER

5.2.4.2 First 25 Hours Inspection

Detailed inspection accomplished after the first 25 hours of flight. This inspection should never be exceeded by more than 5 hours. The purpose of this inspection is to look for any wear, corrosion, or damage that would cause the aircraft to not be in a condition for safe operation. The scope of this inspection is specified in the Appendix Section of this Manual (**Line Maintenance Inspection Form**).

Level of Certification: LSA Repairman Maintenance or A&P, with iRMT Training (at least Service ROTAX® Aircraft Engines Rating) and Super Petrel LS Line Maintenance Rating.

5.2.4.3 Every 100 Hours / Annual Inspection

Detailed inspection accomplished every 100 hours of flight or at least once every 12 calendar months. This inspection should never be exceeded by more than 10 hours. The purpose of this inspection is to look for any wear, corrosion, or damage that would cause the aircraft to not be in a condition for safe operation. The scope of this inspection is specified in the Appendix Section of this Manual (**Line Maintenance Inspection Form**).

Level of Certification: LSA Repairman Maintenance or A&P, with iRMT Training (at least Service ROTAX® Aircraft Engines Rating) and Super Petrel LS Line Maintenance Rating.

5.2.4.4 Every 1000 Hours / Five (5) Years Inspection

Detailed inspection accomplished every 1000 hours of flight or five (5) years. This inspection must be made by the Aircraft Manufacturer or a Mechanic / Repairman, which has received a **Heavy Maintenance Super Petrel Training** to perform this inspection.

Level of Certification: LSA Repairman Maintenance or A&P, with iRMT Training (at least Maintenance ROTAX® Aircraft Engines Rating) and Super Petrel LS Heavy Maintenance Rating.

5.2.4.5 Every Ten (10) Years Inspection

Detailed inspection accomplished every ten (10) years. This inspection must be made by the Aircraft Manufacturer or a Mechanic / Repairman, which has received a **Heavy Maintenance Super Petrel Training** to perform this inspection.

Level of Certification: LSA Repairman Maintenance or A&P, with iRMT Training (at least Maintenance ROTAX® Aircraft Engines Rating) and Super Petrel LS Heavy Maintenance Rating.

5.3 Structures

5.3.1 Fuselage

5.3.1.1 Description

The fuselage is composed by two parts: main fuselage and empennage.

The main fuselage is molded in carbon and Kevlar® reinforced by fiberglass/PVC foam bulkheads. The tail cone is molded in carbon fiber and has internal PVC foam reinforcements. The integrated vertical stabilizer is made of composite shell and two carbon fiber spars. The detachable horizontal stabilizer is made of composite shell, two carbon fiber spars and PVC foam ribs.

5.3.1.2 Fuselage Inspection

Required Tools:	Allen Wrench 6 mm (1 pc)
	Flashlight
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

In this section, the fuselage will be completely inspected. Check before every flight the correct assembling. Do not take off if you suspect any kind of abnormal behavior.

To avoid any future problems, the instructions listed below should be accurately followed to ensure that all parts of the fuselage are within condition. These should be carried out after 25 flight hours, 100 flight hours or annually.

All the inspections must be made visually, it is not necessary to disassemble to check the general condition of the components.

NOTE

Remove or open all cowlings, inspection windows, access doors and baggage compartment, before starting the inspection.

5.3.1.2.1 Covering

The fuselage covering consists of the surface of one big assembly, but here it is divided into two parts, namely as the Upper Fuselage Assembly and the Hull Assembly. No disassembling is necessary.

5.3.1.2.2 Deterioration

Inspect the whole covering for deterioration. If it occurs, the high temperature area around the engine is most likely to show the first signs of deterioration, it will probably occur as deformation “waves” in the engine cowling. If this is the case, contact Scoda Aeronáutica Ltda.

5.3.1.2.3 Cracks

Cracks can be occasioned by excessive or heavy impacts. Therefore, all cracks in the fuselage covering will appear as cracks in the paint.

Thus, start inspecting carefully for cracks on the whole covering of the fuselage and make sure to not forget any area. Pay special attention to edges, sharp corners, connection points and other critical areas where loads are higher and cracks are more likely to occur. If you find any cracks out, carefully inspect if it is only the paint that is damaged or also the structure. If you find any cracks out in the fuselage contact Scoda Aeronáutica Ltda.



Figure 5-11

5.3.1.2.4 Impacts or Damages

There is only a slight chance that delamination will occur. Generally, delamination is caused by significant impacts. Use a flashlight if necessary.

1. Impacts or Damages: on the fuselage outside and inside part (connection between Hull and Upper Fuselage) should be inspect for impacts and general damage, as this may be an indication for possible leakages.
2. Canopy: Inspect for any looseness at the bonding of the canopy's structure to the fuselage.
3. Windshield and Doors: inspect for any looseness at the bonding. Detachment can occur due to frequent washing, weather influence and alternate loads on the windshield.



Figure 5-12

5.3.1.2.5 Canopy Inspection

1. General Condition: check for cracks, scratches or considerable damages.
2. Doors Hinges: check the correct position of the pins and general condition of the circular pins.
3. Windows Vents: check for correct operation. Opening and closing them.



Figure 5-13

4. Doors Lock: check the correct operation (move the locking mechanism) inside and outside the fuselage. Check using one (1) Allen wrench 6 mm if the bolt has lessened in the external mechanism.



Figure 5-14

5.3.1.2.6 Seats Inspection

1. Upholstery: Check for general condition.
2. Pins: Check for general condition. Replace if necessary.

5.3.1.2.7 Safety Belts Inspection

1. General Condition: Check the lap belt for cuts, fraying, extreme or unusual wear. Check the buckle for corrosion.
2. Attachment and Security: Check the safety belts for proper operation. Insert the latch and listening for an audible click.

5.3.1.2.8 Fire Extinguisher Inspection

NOTE

Fire extinguisher should be inspected according to the manufacturer maintenance instructions.

5.3.1.2.9 Doors Removal

CAUTION

When operating the aircraft without doors, loose objects in the cabin or baggage compartment can fly towards the propeller and cause damage.

1. Remove the circular pin located at the two door hinges and then remove the pins.
2. Remove the door.



Figure 5-15

5.3.1.2.10 Ballast Draining

The ballast tank is located inside the fuselage front part. To accomplish this process the following steps must be completed:

1. Open the drain valve located below the passenger seat.
2. The water will begin entering into the hull; therefore, the bilge pump is activated automatically to drain the water.

NOTE

The bilge pump can be activated manually as well.

3. After completing the draining process, activate the bilge pump manually for any remaining presence of water in the hull.

5.3.1.3 Fuselage Repair and Alteration

Repairs or alterations on the fuselage, windshield, windows and doors that are not described in the section 7 of this Manual are not authorized at this time. To obtain engineering approvals, please contact Scoda Aeronáutica at engineering@scodaero.com.br

5.3.2 Wings

5.3.2.1 Description

The upper wings structure consists of a C channel carbon front spar and PVC foam ribs. The ribs, which carry loads (root rib, and ribs where the struts are attached), are reinforced. A C channel composite rear spar supports the aileron and the rest of the wing has a thin rear spar, which connects the ribs at the trailing edge. The leading edge, made of fiberglass composite, forms a “D” box when bonded to the front spar. The covering consists of fabric.

(From aircraft serial number S0380 left aileron contains an electric trim actuator)

The lower wings structure, as the upper wings, consists of a C channel carbon front spar, a thin trailing edge and foam ribs. The leading edge is also made in fiberglass composite and forms a “D” box when bonded to the front spar. The principal difference between upper and lower wings is that the leading edge of lower wings shelters the integrated wing fuel tanks. The covering also consists of fabric.

The struts are made of aluminum profile and the wings are attached to the fuselage by means of fasteners located on the root ribs. The floaters are attached to lower wings.

5.3.2.2 Wings Inspection

Required Tools:	Combined Wrench 13 mm (2 pcs)
	Combined Wrench 10 mm (2 pcs)
	Combined Wrench 8 mm (2 pcs)
	Allen Wrench 6 mm (1 pcs)
	Socket Wrench 10 mm (1 pcs)
	Ladder Support
	Flashlight
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

In this section, the wings and struts will be completely inspected. Check before every flight the correct assembling of each wing and strut and the correct functionality of the aileron system as described in the pre-flight checklist. Do not take off if you suspect any kind of abnormal behavior.

To avoid any future problems, the instructions listed below should be accurately followed to ensure that all parts of the wings and struts are in within condition. These should be carried out after 25 flight hours, 100 flight hours or annually.

All the inspections must be visually made. It is not necessary to disassemble the wings surface or components, just check the attachment condition.


NOTE

Remove or open all cowlings, inspection windows, access doors and baggage compartment, before starting the inspection.


5.3.2.2.1 Upper Wings Inspection

1. Wings Attachment: check the wings attachment with the fuselage.

- Torque the rear fixation bolt using two (2) combined wrenches 13 mm. **Tightening torque: 130 lb.in (15 N.m).**
- Torque the front fixation bolt using one (1) combined wrench 13 mm and one (1) Allen wrench 6 mm. **Tightening torque: 130 lb.in (15 N.m).**
- Check for looseness. Move the wings tips upward-downward, frontward-backward.



(a) Wing Front Part bolts and nuts



(b) Wing Rear Part Bolts and nuts

Figure 5-16

2. General Condition: Use a flashlight if necessary.
 - Check visually the wings surface, leading and trailing edge for general condition (paint, damages, cracks, dents, etc.).
 - Check visually the coating (fabric condition).
3. Ailerons: Use a flashlight if necessary.
 - Check visually the ailerons for general condition (paint, cracks and dent).
 - Check visually the ventilation holes of the ailerons for obstruction.
4. Winglets: use a flashlight if necessary.
 - Check visually the winglet condition (paint, cracks and dent).

5.3.2.2.2 Lower Wings Inspection

1. Wings Attachment: check the wings attachment with fuselage (lower wing root).
 - Check if the circular pin in the front attachment is in the correct position and good condition.
 - Torque the rear fixation bolt using one (1) combined wrench 13 mm and one (1) Allen wrench 6 mm. **Tightening torque: 130 lb.in (15 N.m).**
 - Check for looseness. Move the wings tips upward-downward, frontward-backward.



Figure 5-17

2. General Condition: use a flashlight if necessary.
 - Check visually the wings general condition (damages, denting, etc).
 - Check the coating (fabric condition).
3. Fuel Tanks: use a flashlight if necessary.
 - Check visually the fuel tanks condition (cracks, leakage) located in leading edge of the lower wings.
 - Check the correct operation of the fuel caps and their general condition (O-ring).
 - Check the closing pressure and if necessary adjust the nut using one (1) socket wrench 10 mm.

- Check the header tank for leakage, connections and general condition (Header Tank is located inside the fuselage, behind the passenger's seat).



(a) Fuel Tank



(b) Fuel Cap

Figure 5-18

4. Fuel Tanks Vent: check for obstructions.

- Check visually the vent hoses and connections located inside of the inner struts, inside and outside of the upper part of the fuselage.
- With the help of two people, check the correct airflow through the hoses. One person blowing through the hoses located outside of the upper part of the fuselage and the other person listening to the airflow through the filler tank.







Figure 5-19

5. Winglets: use a flashlight if necessary.
 - Check visually the winglet's condition (attachment, cracks and dent).
6. Floaters: use a flashlight if necessary.
 - Check the attachment using two (2) combined wrenches 10 mm in the floater's front and rear sides.
 - Check visually for general condition (cracks, dent).
7. Landing Gear Leg Housing: use a flashlight if necessary.
 - Check visually the landing gear leg housing for general condition.

5.3.2.2.3 Struts Inspection

1. Struts Attachment: check the attachment of the struts.
 - Check the main strut attachment with the upper wing and fuselage using two (2) combined wrenches 13 mm.
 - Check the attachment of the inner strut (N-Strut) with the upper and lower wing using two (2) combined wrenches 10 mm.
 - Check the attachment of the jury strut with the upper wing and main strut using two (2) combined wrenches 8 mm.




a) Main strut attachment with fuselage



b) Main strut attachment with upper wing



c) Inner strut attachment with upper wing



d) Inner strut attachment with lower wing



e) Jury strut

Figure 5-20

2. General Condition:

3. Check visually the strut, inner strut (N-Strut) and jury strut for corrosion and looseness.

4. Pitot Tube:

- Check the attachment of the Pitot tube located on the left inner strut wing.
- Check the general condition and correct operation.

5.3.2.3 Wings Repair and Alteration

Repairs or alterations in the internal wings structure and wings surface that are not described in the section 7 of this Manual are not authorized at this time. To obtain engineering approvals, please contact Scoda Aeronáutica at engineering@scodaero.com.br.

5.3.3 Empennage

5.3.3.1 Description

The tail cone (fin), horizontal stabilizers (left and right), elevators (left and right), rudder and their components compose the empennage. The gluing of the tail cone with the fuselage is made with mixture of resin epoxy with cotton flocks, resulting in only one set.

- **Horizontal Stabilizer:** The structure of the horizontal stabilizer consists of a circular carbon front spar, a “C” channel carbon rear spar and reinforced foam ribs. The skin consists of a composite shell. These parts are all integrally assembled as the right and left horizontal stabilizers.
- **Vertical Stabilizer:** The structure of the vertical stabilizer consists of reinforced foam ribs, fiberglass/PVC foam bulkheads and its skin consists of a composite shell. These parts are all integrally assembled as the vertical stabilizer.

5.3.3.2 Empennage Inspection

Required Tools:	Ladder support
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

In this section, the empennage will be completely inspected. Check before every flight the correct assembling. Do not take off if you suspect any kind of abnormal behavior.

To avoid any future problems, the instructions listed below should be accurately followed to ensure that all parts of the empennage are in within condition. These should be carried out after 25 flight hours, 100 flight hours or annually.

All the inspections must be visually made. It is not necessary to disassemble, just check the general condition of the components.

The inspection of the empennage control surfaces (rudder, elevators and electric trim tab) are describe in the Structural Control Surfaces of this manual.

NOTE

Remove or open all cowlings, inspection windows, access doors and baggage compartment before starting the inspection.

- General Condition: Check visually the tail cone, horizontal stabilizer leading edges for general condition. Inspect visually cracks, impacts, denting or some considerable damages on the surface.



Figure 5-21

- Attachment: Check the condition of the horizontal stabilizer attachment with the vertical stabilizer. Move the tips upward-downward and frontward-rearward. It cannot have looseness.




Figure 5-22

- Empennage Fixation Bolts (*it should be performed every 200 hours*):
 - Remove rudder.
 - Remove the safety wire.
 - Remove the empennage fixation bolts, inspect for general condition and corrosion.
 - Lubricate the body and threaded part of the empennage fixation bolts with nautical grease before installation.

- Torque the empennage bolts using one (1) Allen wrench 6 mm. **Tightening torque: 70 lb.in (8 N.m)**
- Reinstall the safety wire.
- Reinstall rudder.




Figure 5-23

5.3.3.3 Empennage Repair and Alterations

Repairs or alterations in the internal empennage structure and empennage surface that are not described in the section 7 of this Manual are not authorized at this time. To obtain engineering approvals, please contact Scoda Aeronáutica at engineering@scodaero.com.br.

5.3.4 Landing Gear

The Super Petrel LS is equipped with a retractable tricycle landing gear with mechanical actuation. The nose gear is free swivel and the main landing gear legs are manufactured in fiberglass composite and equipped with oil pneumatic shock absorbers and aluminum wheels.

Main wheels are fitted with disk brakes, hydraulic operated and controlled by pedals.

	USABLE TIRES
MAIN LANDING GEAR	11x4.00-5 – 8 Ply
NOSE LANDING GEAR	10x3.00-4 – 4 Ply

NOTE

Aircraft manufacturer recommends to use MATCO mfg Tires or similar.

5.3.4.1 Landing Gear Inspection

Required Tools:	Slotted Screwdriver
	Phillips Screwdriver
	Cutter Pliers
	Combined Wrench 13 mm (1 pcs)
	Allen Wrench 6 mm (1 pcs)
	Parallel Pin Punch 8 mm (1 pcs)
	Steel Hammer
	Nylon Head Hammer
	Combined Wrench 15/16 " (1 pcs)
Parts and Materials Required:	Refer to Illustrated Parts Catalog
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

In this paragraph the landing gear system will be completely inspected. Check before every flight the correct functionality of the landing gear system, as described in the pre-flight checklist. Do not take off if you suspect any kind of abnormal behavior of the landing gear system.

To avoid any future problems, the instructions listed below should be accurately followed to ensure that all parts of the landing gear system are and remain in within condition. These should be carried out after 25 flight hours, 50 flight hours, 100 flight hours or annually.

Because the landing gear system contains many parts, for sake of clarity, the inspection of the complete landing gear system is divided into 5 different subassemblies:

- Nose Gear
- Main Gear
- Landing Gear Retraction System
- Wheels and Brake System
- Shock Absorber

Most of the inspections must be made visually; it is not necessary to disassemble, just check the general condition of some components. Some components must be replaced in the 100 hours inspection or just if necessary as explained below.

NOTE

Remove or open all cowlings, inspection windows, access doors and baggage compartment before starting the inspection.

NOTE

Lift the aircraft if necessary. See **5.1.9.1 Ground Handling** for instructions.

5.3.4.1.1 Nose Gear

1. General Condition: lift the nose of the aircraft up and use a flashlight.



Figure 5-24

- Check the condition of the bolts and attachment.
- Check the condition and attachment of the rubbers.
- Check the springs for attachment, wear and looseness.
- Check the nose gear for looseness, bending, cracks and wear.
- Check the condition of the wheel (cracks, corrosion, free rotation).
- Check the plates which cover the nose gear fork for general condition, cracks, wear and looseness. Replace them if necessary.
- Check the bearings condition, free rotation of the wheel and looseness.

NOTE

Nose Gear bearings should be replaced on condition, however, it is recommended to replace every 100 hours operation (**See Section 6.2.3.9 Bearing Replacement**).





Figure 5-25

2. Nose Gear Doors: put the nose of the aircraft up and use the flashlight.

- Check for attachment, condition of the hinges and springs, correct operation and general condition. If necessary replace the nose gear doors (See 6.2.3.10 Nose Gear Doors Replacement).



a) Inner and outer parts of the nose gear door.



b) Springs inside the nose gear doors.

Figure 5-26

5.3.4.1.2 Main Gear

1. General Condition: lift the aircraft if necessary and use a flashlight.

- Check the condition of the bolts (loose and damaged).
- Check for cracks, excessive looseness, attachment and general condition of the main gear legs. Check the rubber foam for general condition and detachment.
- Check the condition of the wheel (cracks, corrosion, and free rotation).
- Check the bearings condition, free rotation of the wheel and looseness.

NOTE

Main Gear bearings should be replaced on condition, however, it is recommended to replace every 100 hours operation (See Section 6.2.3.9 Bearing Replacement).



Figure 5-27

5.3.4.1.3 Landing Gear Retraction System

CAUTION

Lift the aircraft to carry out this inspection.

1. Main Gear: use a flashlight if necessary.

- Remove the bottom and the back of the seats.
- Remove the baggage compartment floor with a Phillips screwdriver.



Figure 5-28

- Gas spring: Check for wear, looseness, leakage, attachment and correct operation. If landing gear retraction system is heavy to operate, a gas spring test should be performed (**See Section 6.2.3.13.1 Gas Spring Test**).



Figure 5-29

NOTE

Gas spring should be replaced on condition, however, it is recommended to replace every 500 hours operation or every 5 years (**See Section 6.2.3.13.2 Gas Spring Replacement**).

- Check the tension cable of the main landing gear and the safety wires condition of the turnbuckles.

NOTE

Landing Gear Cables should be replaced on condition, however, it is recommended to replace them every 10 years (**See Section 6.2.3.10 for Landing Gear Cable Inspection and Replacement**).




Figure 5-30

- Lift the aircraft up for accomplishing this process. Check the landing gear actuation, retract and lower several times verifying the correct operation.



Figure 5-31

- The rubber band should be checked. Retract the landing gear and place the rubber band onto the lever. The rubber band should be partially tensioned. If the rubber band loses its elastic property, it should be replaced.

Specification: Bungee Cord, diameter 3/16 (5 mm), size 16 inches (0.4 m)



Figure 5-32

- Check the correct operation of the landing gear sensor. Lower and retract it, verify in the instrument panel the position.
- Check electrical terminals (connectors) for corrosion and general condition. Replace them if necessary.



Figure 5-33

- Rear pulley, lubricate the rear pulley pin with liquid grease, back and front of the bulkhead of the fuselage (See 1.1.1.1 Lubrication Table).



Figure 5-34

2. Nose Gear: use a flashlight if necessary.

- Open the inspection window located in the fuselage nose. Check the tension cables and the pulley of the nose gear.



Figure 5-35

- Check the attachment of the safety wire located in the back of the nose gear box.

5.3.4.1.4 Tires and Brake System

1. Tires Condition: replace them if necessary.
 - Check for cuts, excessive wear and/or uneven and slippage on the wheels.
2. Tire Pressure: consult the POH (Pilot Operating Handbook).
 - Calibrate with recommended pressure.
 -



a) Main Tire



b) Nose Tire

Figure 5-36

3. Brake System Hoses: use the flashlight if necessary.
 - Open the inspection window located on the fuselage nose.
 - Check the connection of the hoses located on the pedals, check for leakage and general condition.




Figure 5-37

- Check the connection of the hoses located in the main gear legs, check for leakage and general condition.



Figure 5-38

4. Hydraulic Fluid: use the flashlight if necessary

- Open the inspection window located on the fuselage nose.
- Check the attachment of the hydraulic fluid reservoir.
- Change the hydraulic fluid (**See 6.2.3.6 Filling Brake System**).



Figure 5-39

5. Brake Pads:

- Check the condition of brake pads, equal pad wearing.
- Replace the brake pads if necessary (**See 6.2.3.7 Brake Pads Replacement**).

6. Brake Discs:

- Check the brake discs for cracks, deformation and attachment.
- Replace the brake discs if necessary (**See 6.2.3.8 Brake Discs Replacement**).

5.3.4.1.5 Shock Absorber

1. General Condition:

- Check the shock absorber for corrosion, wear and leakage.
- Clean the shock absorber.
- Calibration and replacement procedures can be found in the **Section 6.2.3.12 Shock Absorber Calibration and Replacement**.

NOTE

Shock absorber should be replaced on condition.




Figure 5-40

2. Attachment: use the flashlight if necessary

- Check the shock absorber attachment with the main gear leg and inside fuselage.



a) Attachment with the main gear leg



b) Attachment inside the fuselage

Figure 5-41

5.3.4.2 Landing Gear Repair and Alterations

Repairs or alterations in landing gear structure (composite parts) that are not described in the section 7 of this Manual are not authorized in this time. To obtain engineering approvals, please contact Scoda Aeronáutica at engineering@scodaero.com.br.

5.3.5 Structural Control Surfaces

The controls are the most sensitive and important parts of the aircraft and their conditions must be checked before every flight.

WARNING

NEVER TAKE-OFF IF THERE IS ANY ABNORMAL LOOSENESS IN THE SYSTEM, IT MIGHT LEAD TO A VERY DANGEROUS ANOMALY.

5.3.5.1 Control Surfaces Inspection

Required Tools:	Flashlight.
	Ladder Support
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

The ailerons, elevators, rudder and their hinges will be inspected in this paragraph. Check before every flight the correct functionality of the control surfaces, as described in the pre-flight checklist. Do not take off if you suspect any kind of abnormal behavior of the control surfaces.

To avoid any future problems, the instructions listed below should be accurately followed to ensure that all parts of the structural control surfaces are and remain in within condition. These should be carried out after 25 flight hours, 100 flight hours and annually.

All the inspections must be visually made. It is not necessary to disassemble; just check the attachment condition and movement of the control surfaces.

NOTE

Remove or open all cowlings, inspection windows, access doors and baggage compartment before starting the inspection.

5.3.5.1.1 Ailerons

The construction of the aileron is very simple. It is a carbon front spar, foam ribs, a fiberglass trailing edge and foam/carbon-Kevlar sandwich covering. The covering is also totally constructed of derakane.

1. General Condition: use a flashlight and a ladder support if necessary.
 - Check the surface condition (damages and paint damages) and trailing edge.
 - Check the attachment of the aileron trim tab.



Figure 5-42

- Check the attachment of the aileron electric trim tab (hinges, pins, and rod). Turn on the battery master switch and check the correct operation on the instrument panel and electric trim tab. **(From aircraft serial number S0380)**



Figure 5-43

2. Drain Holes: use the flashlight if necessary.

- Check the drain holes of each aileron for obstruction. Lower the aileron and check the holes located in each aileron extremity.



Figure 5-44

3. Operation: use a flashlight and a Ladder Support if necessary.

- Check for free operation (condition of hinges and looseness). Move the aileron up and down, check for full free movement and sufficient space between the wing and the aileron.
- Check the correct operation of the aileron tie rod. Check the support, bolt and nut.



Figure 5-45

- Check the aileron bell-crank located inside of the upper part of fuselage. Move the aileron up and down, check attachment of the bell-crank and free movement.
- Check the Teleflex cable for wearing, looseness and correct operation.




Figure 5-46

NOTE

Teleflex cable should be replaced on condition, however, it is recommended to replace every 10 years.

5.3.5.1.2 Rudder

The construction of the rudder is a carbon front spar, foam ribs, and a fiberglass trailing edge. It is covered with fabric.

1. General Condition: use a flashlight and a ladder support.

- Check the general condition of the rudder surface (damages and rips in the fabric).
- Check the trim tab attachment.




Figure 5-47

2. Drain Hole: use flashlight if necessary.

- Check the drain hole of the rudder for obstruction located on the bottom.



Figure 5-48

3. Operation: use a flashlight and a ladder support if necessary.

- Check for free operation and looseness. Move the rudder to the left and right and check for full free movement. If the rudder is making contact with the stabilizer proceed to the repair of rudder actuator stop (**See Section 7.2.9.18 Rudder Actuator Stop Repair**).
- Check the rudder control cables, attachment bolts and correct operation.

NOTE

Rudder control cables should be replaced on condition, however, it is recommended to replace every 10 years.



Figure 5-49

- Check the attachment of the rudder castle nut and the cotter pin condition.



Figure 5-50

5.3.5.1.3 Elevators and Trim Tab

As the ailerons, the construction of the elevators is also very simple. It is a carbon front spar, foam ribs, a fiberglass trailing edge and foam/carbon-Kevlar sandwich covering.

1. General Condition: use a flashlight and a ladder support if necessary.
 - Check the surface condition (damages and paint damages) and trailing edge of the elevator.
 - Check the elevator attachment (nuts, bolts, bell-crank attachment and safety wires). Check the elevator control rods.
 - Check the surface condition of the electric trim tab and check the trailing edge.



Figure 5-51

2. Drain Hole: use a flashlight if necessary.

- Check each elevator's drain hole for obstruction. Lower the elevator and check the hole located in each elevator's inner part.



Figure 5-52

3. Operation: use a flashlight and a ladder support if necessary.

- Check free operation and looseness. Move the elevator up and down and check for full free movement and sufficient space between the horizontal stabilizer and the elevator.



Figure 5-53

- Check the attachment of the elevator electric trim tab (hinges, pins, and rod). Turn on the battery master switch and check the correct operation on the instrument panel and trim tab.



Figure 5-54

5.3.5.1.4 Joysticks and Pedals

1. Check the joysticks for free operation. Remove foreign objects and contamination.
2. Check the pedals for movement strength, joints safety, general condition and cables attachment.

5.3.5.2 Control Surfaces Repair and Alterations

Repairs or alterations in the internal control surfaces structure that are not described in the section 7 of this Manual are not authorized in this time. To obtain engineering approvals, please contact Scoda Aeronáutica at engineering@scodaero.com.br.

5.4 Engine

5.4.1 Description

Description	912 ULS	914 UL	912 iS Sport
4 strokes, 4 cylinder horizontally opposed, spark ignition engine, one central camshaft – push-rods – OHV	✓	✓	✓
Liquid cooled cylinder heads	✓	✓	✓
Ram air cooled cylinders	✓	✓	✓
Dry sump forced lubrication	✓	✓	✓
Dual breakerless capacitor discharge ignition	✓	✓	X
2 constant depression carburetors	✓	✓	X

Mechanical fuel pump	✓	X	X
2 electric fuel pumps	X	✓	X
Electric starter	✓	✓	✓
Integrated AC generator with external rectifier-regulator	✓	✓	X
Incorporated reduction gearbox	✓	✓	X
Fully redundant electronic engine management (EMS) includes fuel injection, characteristic ignition, etc.	X	X	✓
Propeller drive via gearbox with integrated mechanical shock absorber and overload clutch	X	X	✓
Oil tank	✓	✓	✓
Fuel Pump Assy	X	X	✓

Because of engine's complexity and importance to the flight safety, it is necessary the operator be conscious that a very rigorous inspection/maintenance program must be adhered to.

Consult the manufacturer's manuals, service bulletins and instruction books regarding the repair and overhaul, inspection, installation and maintenance of the engine.

For inspection and maintenance of the engine or its systems listed below, refer to the latest edition of Maintenance Manual (Line Maintenance) for ROTAX Engine Type 912i Series, 912 and 914 Series supplied by the manufacturer.

- Cooling System
- Fuel System
- Lubrication System
- Electric System
- Propeller Gearbox

CAUTION

ROTAX engines must receive any heavy maintenance at an authorized ROTAX service center.

5.4.2 Engine Inspection

Required Tools:	Socket Wrench 17 mm (1 pcs)
	Allen Wrench 6 mm (1 pcs)
	Slotted Screwdriver
	Phillips Screwdriver
	Flashlight
	Ladder Support
Parts and Materials Required:	Liquid Grease
	Refer to Illustrated Parts Catalogue
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

To avoid any future problems, the instructions listed below should be accurately followed to ensure that all parts of the engine and components are in within condition. These should be carried out after 25 flight hours, 100 flight hours or annually.

All the inspections must be visually made. It is not necessary to disassemble, just check the attachment condition.

NOTE

Remove or open all cowlings, inspection windows, access doors and baggage compartment before starting the inspection.

The following instructions are in order to inspect aircraft structural parts, which make up the powerplant system such as engine cowling, engine mount, exhaust and carburetor heater **(only for 912 ULS)**.

5.4.2.1 Engine Cowlings

1. Cowlings removing: use a ladder support if necessary.

- First remove the upper cowling with a slotted screwdriver
- Then remove the lower cowling with a Phillips screwdriver

2. Cowlings Inspection: use a flashlight if necessary. Remove the cowlings.

- Check the upper and lower cowlings for general condition (cracks, burns, damaged protections, rubbers and general condition of fasteners).
- Check the condition of asbestos, detachment and general condition in the lower cowling.
- Check the supports of oil and water cooler for looseness and general condition in the lower cowling.
- Check the rubbers of the upper and lower cowlings for general condition and detachment.
- Check the protection grille for attachment and general condition in the lower cowling.




Figure 5-55

5.4.2.2 Engine Suspension Frame

The inspection of the engine suspension frame is only performed in the first 25 hours inspection, as explained below:

1. Firewall Bolts (Engine Suspension Frame bolts with the Fuselage) **(912 iS Sport and 912 ULS)**:
 - Torque the firewall bolts using one (1) socket wrench 17 mm and then using the torque wrench, check the torque. **Tightening torque: 350 lb.in (40 N.m).**



Figure 5-56

2. Firewall Bolts (Engine Suspension Frame bolts with the Fuselage) (**914 UL**):

- Torque the firewall bolts using one (1) Allen wrench 6 mm and then using the torque wrench, check the torque. **Tightening torque: 180 lb.in (20 N.m).**




Figure 5-57

3. Engine Suspension Frame Bolts (**912 iS Sport, 914UL and 912 ULS**):

- Torque the engine suspension frame bolts using one (1) socket wrench 17 mm and then using the torque wrench, check the torque. **Tightening torque: 350 lb.in (40 N.m).**




Figure 5-58

4. Engine Mounts:

- **912 ULS / 912 iS Sport**

NOTE

Engine Mounts for Super Petrel LS equipped with Rotax Engines 912 Series should be replaced on condition, however, it is recommended to replace them every 500 hours.

- **914 UL**

NOTE

Engine Mounts for Super Petrel LS equipped with Rotax Engines 914 Series should be replaced on condition, however, it is recommended to replace them every 300 hours.

NOTE

All rubber parts including engine mounts, hoses and lines which are part of the Powerplant must be replaced every 5 years as per Rotax recommendation.

5.4.2.3 Cooling System

The cooling system hose clamps should be re-tightened in the first 25 hours inspection and each 100 hours / annually inspection. Hoses should be inspected for leakage, cracks, kinks, and security of mounting. Ensure that hoses do not interfere with adjacent equipment or lines. Make sure that they are not kinked, and not in contact with hot, moving parts or sharp edges.

CAUTION

Clamps too tight may damage the hoses.

5.4.2.3.1 Ventilation Electrical System Inspection (Only for 912 iS Sport)

DESCRIPTION	TECHNICAL SPECIFICATION	QUANTITY	PART NUMBER
Electrical Fans	SANYO DENKI DC FAN 92X38MM 12VDC	3	9WL0912P1H001
Temperature Sensor (From s/n S0365 up to S0374 inclusive)	Thermoswitch MTE-THOMSON MTE837 (100/95°C)	1	MTE-837
Relay (From s/n S0375)	Power Relay (4P) – 10AMP	1	39794-S0K-A01

The ventilation electrical system contains 3 electrical fans which are fixed on the cooling radiator. **From serial number S0365 up to S0374 inclusive**, the system is automatically activated through a temperature sensor when the cooling temperature reaches 212°F (100°C).

(From serial number S0375) the system is automatically activated when the cooling temperature reaches the yellow arch.

- Check the condition and attachment of the electrical fans and brackets.



Figure 5-59

- Check the ventilation electrical system for friction with the cooling radiator.
- Check the condition and attachment of the temperature sensor **(from serial number S0365 up to S0374 inclusive)**.



Figure 5-60

- Check the fuses of the ventilation electrical system which is located in fuselage pylon for general condition and attachment. Check the condition of the connectors.
- Check the relay of the ventilation electrical system which is located in fuselage pylon for general condition and attachment. Check the condition of the connectors **(from serial number S0375)**.



Figure 5-61

- Make an operational test of the ventilation electrical system. A run-up engine will be necessary up to reach the yellow arch (or 212°F/100°C when sensor installed) of the cooling temperature. Shut the engine off without turning off the Master switch and check if the fans are working.

CAUTION

The engine instruments indications are set during the manufacturing of the aircraft according to the parameters specified in the Engine Parameters Section of the applicable Pilot's Operating Handbook. The alteration of the indications and limits previously established can compromise the engine operation and aircraft systems.

WARNING

EXTRA CAREFUL MUST BE TAKEN WHEN INSPECT THE FANS. MAKE SURE THAT ENGINE IS SHUT OFF.

5.4.2.4 Exhaust System

1. General Condition: use a flashlight if necessary.
 - Check the general condition of the exhaust system (cracks, deformations, damages).
2. Exhaust System Pipes: use a flashlight if necessary.
 - Check the pipes of the exhaust system for attachment and general condition.
3. Muffler: use a flashlight if necessary.
 - Check the muffler for general condition (cracks, damages, and attachment). Repair with weld if necessary.
 - Remove the muffler every 200 hours for performing a detailed inspection **(See Section 6.2.3.17 Exhaust Muffler Inspection and Replacement)**.
4. Tension Springs (only for 912 iS Sport and 912 ULS): remove the engine cowlings.
 - Check the condition and attachment of the tension springs.
 - Check the condition of the high temperature silicone (it should cover the point between the tension spring and muffler hook) in order to prevent unusual wear caused by the spring vibration.

CAUTION

The correct use of the high temperature silicone is crucial for the life time of the tension spring and muffler's hook.



Figure 5-62

- Replace the tension springs **(See 6.2.3.16.1 Tension Springs Replacement)**.

NOTE

Tension springs should be replaced every 100 hours.

5.4.2.5 Carburetor Heater (If Installed) – Only for 912 ULS

1. Check visually the general condition and attachment of the thermo straps located in the carburetors. Use a Ladder Support.




Figure 5-63

2. Make an operational check of the carburetor heater. First turn on the battery master switch and then turn on the carb heater switch. Check if the carb heater LED is on and check the correct operation (touch over the carburetor and verify if it is heating).

5.4.2.6 Engine Controls

NOTE

For throttle and choke cables setting please refer to Engine Manufacturer Maintenance Manuals

1. Throttle: Check for correct operation and free movement.
2. Choke: Check for correct operation and lock (**912 ULS and 914 UL**)

5.4.3 Engine Maintenance, Repair and Overhaul

Maintenance, Repair and Overhaul of the engine requires a Rotax training. Before performing any inspection or maintenance task on the engine, check manuals for available updates through Rotax website.

5.4.3.1 Spark Plugs Replacement

- As per Rotax recommendations, operation with leaded fuels (e.g. AV GAS 100LL) can result in increased wear of the spark plugs. Reduce renewal intervals accordingly.
- Aircraft manufacturer recommends to replacement the spark plugs each 100 hours inspection when using either MOGAS or AVGAS. This should be applied to the three engine types.
- Spark plugs replacement should be made according to the latest revision of the Rotax Line Maintenance Manual.

5.4.3.2 Air Filter Replacement

Required Tools:	Twisting Pliers
	Ear Clamp Plier
Parts and Materials Required:	Refer to the section 5.1.3 List of Disposable Replacement Parts
	Safety Wire
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

Refer to the latest edition of Maintenance Manual (Line Maintenance) for ROTAX Engine Type 912i Series, 912 and 914 Series supplied by the manufacturer.

FOR SUPER PETREL LS EQUIPPED WITH ROTAX 912 ULS / 912 iS Sport

1. Remove the engine cowlings.
2. Remove the old air filter.
3. Install the new air filter.

CAUTION

Air filter and throttle body must be free of oil.

4. Secured the air filter by clamp attachment.
5. Check the installation for general condition and fixation.
6. Install the engine cowlings.

FOR SUPER PETREL LS EQUIPPED WITH ROTAX 914 UL

1. Drill a 2mm hole in the top and bottom of the air filter in order to pass the safety wire (see picture below).




Figure 5-64

2. After drilled, make sure the filter is clean and free of rubber residues.
3. Clean filter and turbocharger nozzle. Make sure those are free of oil, dirty, residues, etc.
4. Prepare the air filter with the safety wire before installing.
5. Secure the air filter by clamp attachment. Make sure the clamp be tight.

CAUTION

The fixation of the clamp must be checked after run-up test and periodically, as necessary.

6. Air filter should be wired in three points as follows:

NOTE

SCODA AERONAUTICA cannot accept any responsibility for the quality of work performed.
Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices
Aircraft Inspection and Repair – SECTION 7. SAFETYING

NOTE

Use heat shrink tube where the safety wire may contact with the turbo housing.

A) TOP PART OF THE AIR FILTER – TURBOCHARGER OUTPUT DUCT

Figure 5-65

CAUTION

Safety wire must be tight enough in order to not allow the filter to disengage from the turbocharger nozzle.

A) BOTTOM PART OF THE AIR FILTER – BOWDEN CABLE SUPPORT



Figure 5-66

CAUTION

Safety wire must be tight enough in order to not allow the filter to disengage from the turbocharger nozzle.

A) FIXATION CLAMP – BOWDEN CABLE SUPPORT



Figure 5-67

7. Check the installation for general condition and fixation.

5.4.3.3 Fine Fuel Filter Replacement (Rotax P/N: 874060) – Applied for Rotax 912 iS Sport

NOTE

SCODAAERONAUTICA cannot accept any responsibility for the quality of work performed.
Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

NOTE

Refer to the section 5.1.3 List of Disposable Replacement Parts.

NOTE

Refer to the latest revision of the Rotax Service Instruction SI-912-009i for maintenance related information.

The fine fuel filter is located in the engine compartment. According to the last revision of the Rotax Service Instruction SI-912i-009 the filter should be replaced after the first 100h, then every 200h or maximum after 2 years (whichever occurs first).

5.5 Fuel System

5.5.1 Description

The fuel system is fed by two wing tanks built of fiberglass inside the lower wings leading edges and a header tank located behind the passenger's seat (right side of the aircraft).

These two wing tanks, each having a capacity of 10.3 US gallons – 39 liters (10 US gallons usable – 38 liters), are not interconnected but are connected to a fuel selector valve which has three positions (right wing, left wing or closed) which feeds the header tank with a capacity of 4.5 US gallons – 17 liters (4 US gallons usable – 15 liters).

The fuel system also contains a shut-off valve, which avoids the engine being fed by usable fuel during emergency procedures. The shut-off valve is located next to the header tank behind the passenger's seat.

The fuel drain system contains an electric drain pump located inside the aircraft fuselage and a drain valve located below the right wing root of the aircraft outside part (**See 5.5.1.5 Draining Process**).

The full capacity of the system is 25 US gallons – 95 liters (24 US gallons usable – 91 liters).

The fuel quantity instrument, located on the instruments panel, will indicate the amount of fuel existent inside the selected wing tank, **IT WILL NOT INDICATE THE TOTAL AMOUNT OF FUEL EXISTENT IN THE WHOLE SYSTEM**. Therefore, in order to know the amount of fuel existent in the whole system, it is necessary to achieve the readings of both left and right wing position of the fuel valve, and then add the header tank amount.

NOTE

After wing tank selection, wait for 60 seconds until you can do a consistent reading.

In case of unbalanced load or passengers it is recommended that the fuel valve is set to the heavier tank or to the heavier side of the aircraft, in order to level it. It is also recommended the switch between the tanks in intervals of about 30 minutes of flight time. Such procedure will also help to maintain the aircraft's lateral balance.

NOTE

The aircraft is able to use fuel which contains up to 10% of ethanol. In case this type of fuel is needed, use high-octane fuel.

NOTE

For more details about the fuel's correct selection, refer to the engine manufacturer's original manuals.

WARNING

ALWAYS BE AWARE OF FUEL CONTAMINATION OR DETERIORATION CAUSED BY IMPURITIES OR LONG PERIODS OF INACTIVITY AND STORAGE. ALWAYS DRAIN THE SYSTEM AND CHECK FUEL CONTAMINATION BEFORE FLIGHT.

The following diagrams (next pages) describe the Super Petrel LS fuel system for each engine type.

5.5.1.1 SPLS Fuel System Diagram for 912 ULS




Figure 5-68

5.5.1.2 SPLS Fuel System Diagram for 914 UL




Figure 5-69

5.5.1.3 SPLS Fuel System Diagram for 912 iS Sport




Figure 5-70

5.5.1.4 Refueling: Safety Precautions

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 00-34 A – AIRCRAFT GROUND HANDLING AND SERVICING, Section 8. Aircraft Fueling.

In servicing the fuel system, the following precautions should be taken:

- Aircraft being serviced or having the fuel system repaired must be properly grounded;
- No electrical or radio equipment in the aircraft is energized or being maintained while fuel is being dispensed into the aircraft;
- Fueling personnel should not carry objects in the breast pockets of their clothing when servicing aircraft because loose objects can fall into the fuel tanks;
- Matches or lighters should never be carried during fueling operations;
- In event of fuel spillage, discontinue the fueling operations until the spill can be removed, using proper safety precautions. Remove or neutralize the spilled fuel as quickly as possible;
- Fire-extinguishing equipment must always be available.

WARNING

IN SERVICING THE FUEL SYSTEM, REMEMBER THAT FUEL IS FLAMMABLE AND THAT THE DANGER OF FIRE OR EXPLOSION ALWAYS EXISTS.

5.5.1.5 Draining Process

In order to begin the draining process to draining process, the aircraft must be in a static condition. Use protection gloves.

1. Turn on the battery master switch.
2. Open the drain valve located in the right lower wing bottom part.



Figure 5-71

3. Press the drain button located in the instrument panel.
4. Use a clear container in order to collect fuel sample.

5.5.2 Fuel System Inspection

Required Tools:	Flashlight
	Ladder Support
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

In this section, the fuel system will be completely inspected. Check for leakage before every flight as described in the pre-flight checklist. Do not take off if you suspect any kind of abnormal behavior.

To eliminate any (future) problems, the instructions listed below should be accurately followed to ensure that all parts of the fuel system are in within condition. These should be carried out after 25 flight hours, 100 flight hours or annually.

All the inspections must be visually made. It is not necessary to disassemble any wing's surface or components, just check the attachment condition.

NOTE

Remove or open all cowlings, inspection windows, access doors and baggage compartment before starting the inspection.

CAUTION

Connections located in the wings, header tank and vents should not be retightened in order to preserve the integrity of sealing components, fittings and lines of the fuel system.

- Fuel and Vent Hoses: use a flashlight if necessary.
 - Check the fuel hoses condition (integrity, attachment, security, excessive bending) in the baggage compartment, header tank, lower wings and inside of the engine compartment.
 - Check the vent hoses condition (integrity, attachment, security) in the header tank, the inner struts connection and pylon of the fuselage.

NOTE

EARLS Inline Fuel Filter 3/8" 85 Micron – P/N 230206ERL was discontinued.

- Inline Fuel Filter (Andair FX375-M or FX375-MK) – For Rotax 912 iS Sport:

NOTE

For installation of the fuel filter model FX375-MK should be used an adapter 6AN Male to 1/4 NPT Female in the filter output.

- Close the Fuel Shut Off Valve and Fuel Selector Valve.
- Remove the fuel filter.

NOTE

Use a tray in order to collect the small quantity of residue fuel.

- Open the fuel filter.



Figure 5-72

- Inspect and clean the filter screen. If necessary replace the fuel filter assembly. (See 6.2.3.2 Fuel Filter Replacement).

NOTE

Replace the O-Ring of the fuel filter as necessary.

- Close the fuel filter. Re-safety the filter housing.
 - Install new ear clamps.
 - Open the Fuel Shut Off Valve and Fuel Selector Valve and check for leakage.
 - Check the fuel filter for general condition (leakage and attachment).
- Inline Fuel Filter (Holley 162-551) - For Rotax 912 ULS / 914 UL:
 - Close the Fuel Shut Off Valve and Fuel Selector Valve.
 - Remove the fuel filter.

NOTE

Use a tray in order to collect the small quantity of residue fuel.

- Open the fuel filter



Figure 5-73

- Inspect and clean the filter element. If necessary replace filter elements kit. (See 6.2.3.2 Fuel Filter Replacement).

- Close the fuel filter.
- Install new ear clamps.
- Open the Fuel Shut Off Valve and Fuel Selector Valve and check for leakage.
- Check the fuel filter for general condition (leakage and attachment).
- Fuel System: check all fuel system for leakage (blue spots in the connections). Use a flashlight if necessary.
 - Check the header tank (hose connection).
 - Check electrical terminals (connectors) for corrosion and general condition of the sensor and ground located on the top of the header tank sensor. Replace them if necessary.
 - Check the fuel indication. If necessary replace the fuel sensor unit (**See 6.2.3.3 Fuel Sensor Unit Replacement**).
 - Check the lower wing (hose connection inside the fuselage).
 - Check the wing tanks (cracks, denting, and damages) and the condition of the fuel cap (rubber, operation, sealing).
 - Check the drain valve (attachment and hose connection). Test it for correct operation.
 - Check the drain pump for leakage and general condition.
 - Check electrical terminals (connectors) for corrosion and general condition of the drain pump. Replace them if necessary.
- Shut Off Valve:
 - Check the shut off valve for correct operation, opening and closing the valve.
 - Check the connections.
- Selector Valve:
 - Check the selector valve for correct operation; turn the valve (change the valve position).
 - Check the connections.
- Placards:
 - Assure that required placards are complete and according to the Pilot's Operating Handbook. Replace those are missing or cannot be read easily.

5.5.2.1 Electrical Fuel Pumps Inspection

NOTE

In order to comply with 5 year rubber parts replacement requirements, ROTAX has released a fuel pump service kit. Please refer to the latest version of the SI-912i-015.

NOTE

Refer to the latest edition of FAA ADVISORY CIRCULAR AC 43-4B, CORROSION CONTROL FOR AIRCRAFT for a more in-depth study on the detection and treatment of corrosion.

NOTE

Apply a corrosion inhibitor (Ardrox AV8, CorrosionX or similar) as necessary in order to mitigate general corrosion

1. Remove the baggage compartment (upper and lower).
2. Close the shut off and selector fuel valve.
3. Remove the fuel pump assembly's cover without removing the FPA from the aircraft (only for Rotax 912 iS Sport).
4. Inspect the electric fuel pumps for corrosion, leakage, general condition, lines and connectors.
5. Clean the housing, pumps, and connections as necessary.
6. Apply CorrosionX Aviation or similar as necessary.
7. Install the Fuel Pump Assembly's cover (only for Rotax 912 iS Sport).
8. Make an operational check of the electric fuel pumps.
9. Install the baggage compartment (upper and lower).

CAUTION

Aircraft in operation on salt-water environment must have a recurrent corrosion inspection, cleaning and lubricating of the electric fuel pumps every 25 hours.

WARNING

IF THE ALUMINUM FUEL PUMP'S BODY PRESENTS CORROSION (SEE PICTURE BELOW), REPLACE THE FUEL PUMP IMMEDIATELY.



Figure 5-74

5.5.3 Fuel System Repair and Alterations

Repairs or alterations in the Fuel System of the Super Petrel LS that are not described in the section 7 of this Manual are not authorized in this time. To obtain engineering approvals, please contact Scoda Aeronáutica at engineering@scodaero.com.br.

5.6 Propeller

5.6.1 Description

Super Petrel LS is equipped with three-blade propeller with ground adjustable pitch:

- POWERFIN PROPELLERS Model F 65"
- DUC Three-Blade Inconel FLASH – 2 propeller

CAUTION

Always remember that composite blades do not resist certain impacts.

WARNING

BE SURE THAT NOTHING TOUCHES THE PROPELLER WHILE THE ENGINE IS RUNNING.

5.6.2 Propeller Inspection

Required Tools:	Combined Wrench 13 mm (1 pcs)
	Combined Wrench 10 mm (1 pcs)
	Allen Wrench 5 mm (1 pcs)
	Torque Wrench
	Phillips Screwdriver
	Flashlight
	Ladder Support
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

In this section, the propeller will be completely inspected. Check for general condition of propeller before every flight as described in the pre-flight checklist. Do not take off if you suspect any kind of abnormal behavior.

To avoid any future problems the instructions listed below should be accurately followed to ensure that all parts of the propeller are in within condition. These should be carried out after 25 flight hours, 100 flight hours or annually.

All the inspections must be visually made. It is not necessary to disassemble some surface of wing or components, just check the attachment condition.

NOTE

Remove or open all cowlings, inspection windows, access doors and baggage compartment before starting the inspection.

1. Propeller Hub: use a flashlight if necessary.

- Remove the spinner using a Phillips Screwdriver.
- Remove the bolts safety wire of the propeller.
- Torque the M8 bolts attachment using one (1) combined wrench 13 mm and check the condition of the safety wire. **Tightening torque: 220 lb.in (25 N.m).**
- Reinstall the safety wire of the propeller bolts.

NOTE

Marking Paint of all the bolts/washer/hub after tightening can be done in order to help make a visual check outside of the general maintenance.

NOTE

For Safetying, refer to the latest edition of the FAA ADVISORY CIRCULAR 43-13B, CHAPTER 7. SAFETYING

2. Blades: use a flashlight if necessary.

- Check the fixation of the blades by shaking the blade tip firmly.
- Check the blades for general condition (abrasions, cracks, nicks, scratches, paint damages, leading edges and tips).
- Check for corrosion in the blades root.
- Check the Inconel leading edge for general condition and detachment (applied for **FLASH – 2**).

3. Spinner: use a flashlight if necessary.

- Remove the spinner using a Phillips Screwdriver.
- Check the spinner for general condition (cracks, denting).
- Reinstall the spinner and check the attachment after finishing the propeller's inspection.

NOTE

For more details about the other propeller's inspection, maintenance, repair, removal or installation, refer to the propeller manufacturer website for downloading the applicable documents.

NOTE

For more details about the DUC FLASH-2 propeller's inspection, maintenance, repair, removal or installation, refer to the last revision of the Instruction Manual FLASH propeller range.

NOTE

For more details about TBO (Time Between Overhaul) and Special Inspections Intervals of the DUC FLASH-2 propeller, refer to the last revision of the Instruction Manual FLASH propeller range.

5.6.3 Propeller Maintenance, Repair and Overhaul

Repairs or alterations in the Propeller are not authorized in this time. To obtain engineering approvals for any repairs or alterations, please contact Scoda Aeronáutica at engineering@scodaero.com.br.

5.6.4 Propeller Installation

Required Tools:	Combined Wrench 13 mm (1 pcs)
	Combined Wrench 10 mm (1 pcs)
	Allen Wrench 6 mm (1 pcs)
	Allen Wrench 5 mm (1 pcs)
	Torque Wrench
	Digital Level (Goniometer)
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

1. Install the blades in the hub. The pitch angle should be set on the blade tip as follows:

912 ULS / 912 iS Sport	914 UL
16.5°	18.0°

2. Install the propeller in the aircraft (see picture below).




Figure 5-75

3. Torque the hub and blades according to the table below:

HUB	BLADES
25 N.m	25 N.m

4. Make a static engine run test in order to get the following RPM:

912 ULS / 912 iS Sport	914 UL
5300 RPM +/- 100 RPM	5500 RPM +/- 100 RPM

NOTE

If necessary make a fine pitch adjustment in order to reach the engine RPM.

5. After getting the specified static RPM, check again the hub and blades torque value.
6. Install the safety wire on the hub bolts.
7. Install the Spinner.

NOTE

Please refer to the section below (**GENERAL RECOMMENDATIONS FOR PROPELLER BALANCING**), for positioning of the aircraft when is performing the RPM check after propeller installation.

5.6.5 Propeller Balancing

- Propeller balancing should be made each **100 hours inspection**. This procedure should be a dynamic balancing method.
- For balancing procedures, use the Balancer OEM manuals.

NOTE

For Propeller Balancing Best Practices, refer to the latest edition of the FAA ADVISORY CIRCULAR AC 20-37E, CHAPTER 3. ACCESSORIES AND BALANCING.

GENERAL RECOMMENDATIONS FOR PROPELLER BALANCING

- The vibration sensor should be fixed to the engine gearbox.
- The sensor should be placed vertically, centralized on the engine with the cable pointing upwards.
- Place the photo sensor on the engine or cowling between 30-45 centimeters behind of the propeller at the 12-o'clock position. The fixation should be properly in order to avoid vibrations in the sensor.
- The cables of the photo sensor should be far from the engine's heated and moving parts.
- Place the reflective tape on the spinner mounting plate in vertical position.
- Do not exceed the aircraft and engine limitations.
- Pay particular attention in the engine water temperature.
- The vibration levels should not exceed 1.20 inches per second (1.20 IPS). If this value is exceeded, the

propeller should be balancing statically.

- The maximum weight is 30 grams per bolt.
- Chock the aircraft and perform the engine starting on a clean and hard surface.
- Fixed pitch propellers should be turned to a low cruise RPM. Constant speed propeller should be turned to a low cruise RPM using minimum power torque.
- Wind speed should be limited to 20 mph with a gust-limited factor between 5 – 7 mph. An attempt of performing the balancing with winds, will make the process more difficult or impossible to complete.
- Do not place the aircraft near any obstacles when the wind is more than 5 mph. Turbulent air around of the obstacle, would cause air loads on the propeller and the balancing will became difficult to complete.
- ALWAYS place the aircraft in the opposite direction of the Wind.
NEVER attempt to balance with crosswinds or tailwinds.

5.6.5.1 Propeller Balancing Parameters

- Propeller specification: DUC FLASH - 2
- Run engine test: at 5000 Static RPM.
- The IPS final (inches per second): less than 0,1 IPS as per Rotax instructions.

5.7 Utility Systems

5.7.1 Cabin Heater System

Super Petrel LS cabin heater system uses the engine coolant as a heat source. The coolant is bled from the engine and taken to the heater radiator inside the cabin. A fan, coupled to the radiator, blows hot air through the cabin. Cabin heater system is protected with a fuse in order to avoid any damage or overvoltage on the electrical fan. This fuse is located inside the aircraft nose above the electrical fan.




Figure 5-76

5.7.2 Cabin Heater Inspection

Required Tools:	Flashlight
	Ladder Support
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

The inspection of cabin heater system must be made visually. It is not necessary to remove the parts or components of system.

NOTE

Remove or open all cowlings, inspection windows, access doors and baggage compartment, before starting the inspection. Use a flashlight.

5.7.2.1 Under Cowling Inspection (Engine)

1. Insure hoses are not rubbing on anything and are not showing signs of any leakage.
2. Check condition of hose clamps and security.
3. Follow hoses toward firewall to insure they have not been rubbing on anything or showing signs of cracking or stiffness.
4. Check hoses and grommets where they go through the firewall for cracks or wear.

NOTE

All rubber parts including engine mounts, hoses and lines which are part of the Powerplant must be replaced every 5 years as per Rotax recommendation.

5.7.2.2 In Cockpit Inspection

1. Inspect grommets and hoses where they enter through the firewall into the cockpit for the same issues as inspected under the cowling.
2. Check both red (+) and black (-) wire connections at sources, toggle switch and fan. Replace them if necessary.
3. Insure there is no sign of corrosion at connections and that wires are clean and have no missing / worn off insulation.
4. Check the amp draw on heater fan. If more than 4 amps are recorded, the fan should be replaced.
5. Check for any evidence of the heater core leaking coolant. If any evidence is noted, change heater core.
6. Check to insure the unit is secure in its mounts, tight and not rubbing on anything.
7. Check the correct operation of the hydraulic valve located in the pilot seat bottom part.
8. Check that the hoses are still hooked to the heater unit and are not cracking.

9. Check that hose clamps are still tight.
10. Make an operational check of the cabin heater. First, turn the master switch on and then turn on the cabin heater switch.

NOTE

Cabin Heater hoses and lines should be replaced on condition, however, it is recommended to replace them every 10 years.

CAUTION

It is not recommended to operate the cabin heater system with the valve open and the switch turned OFF.

5.7.3 Cabin Heater Maintenance, Repair and Overhaul

Repairs or alterations in the Cabin Heater System are not authorized at this time. To obtain engineering approvals for any repairs or alterations, please contact Scoda Aeronáutica at engineering@scodaero.com.br.

5.8 Instruments and Avionics

5.8.1 Description

Super Petrel LS is equipped with two version of instrument panel: ANALOG and FULL DIGITAL.

Typical instrument panels contain all flight, navigation and engine instruments that are required for day and night operations. Switches are located as follows:

- **Engine Panel:** Located on the left side of the instrument panel.
- **Lights Panel:** Located in the middle of the instrument panel below the GPS.
- **Miscellaneous Panel:** Located on the center console.
- **Circuit Breaker Panel:** Located on the right side of the instrument panel.
- **ELT Remote Control:** Located on the right side of the instrument panel above the Display.

NOTE

The configuration of the instrument panel for each Super Petrel LS is detailed on the Instrument Panel and Flight Instruments Supplement of the POH.

5.8.1.1 Instrument Panel and Flight Instruments

The instrument panel of each Super Petrel LS is detailed on the Instrument Panel and Flight Instruments Supplement of this Manual.

5.8.2 Instruments and Avionics Inspection

Required Tools:	Flashlight
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

The inspection of the instruments and avionics must be made visually. It is not necessary to remove the parts or components of system.

NOTE

Remove or open all cowlings, inspection windows, access doors and baggage compartment before starting the inspection.

CAUTION

Magnetic tools must not be used during this procedure.

1. Instrument Panel: use a flashlight if necessary.
 - Check visually the instrument panel for attachment and general condition.
 - Check the readability and condition of the placards, which are located on the instrument panel. Replace them as necessary.
2. Instruments and Avionics: Follow the OEM (Original Equipment Manufacturer) manuals for maintenance and inspection instructions as applicable.
 - Check the correct operation of the instruments. Make an operational test on the instruments as applicable.
3. ELT (Emergency Locator Transmitter): the transmitter assembly and lithium battery pack is located behind the baggage compartment in the pilot side. Remote control is located on the instrument panel and the audio alert is located behind the instrument panel. Whip antenna is located in the external rear part of the fuselage close to the propeller.
 - For maintenance, inspection and operational test of the ELT, components replacement as well as batteries replacement intervals, consult the last revision of the OEM installation and operation manual.

CAUTION

After performing the operational test on the instruments, avionics and ELT, turn off the Battery Master and Avionics Master Switch.

5.8.3 Instruments and Avionics Maintenance, Repair and Overhaul

Repairs or alterations on the Instruments and Avionics are not authorized in this time. To obtain engineering approvals for any repairs or alterations, please contact Scoda Aeronáutica at engineering@scodaero.com.br.

CAUTION

Replace defective instruments and avionics, only with approved instruments.

5.9 Electrical System

5.9.1 Description

The electrical system of the Super Petrel LS consists of a 12-volt DC system. This contains the following electrical components and equipment:

- 12-Volt / 18A Sealed Lead Acid or Gel Battery
- Bilge Pump / Automatic
- Fuel Sensor Quantity
- Fuel Drain Pump
- External Lights (Nav / Strobe Lights, Landing Lights)
- Elevator Electric Trim
- Headphones Plugs
- Cabin Heater
- Carburetor Heater (**Applied only for 912 ULS**)
- ELT
- Instrument Panel (Switches, Indicator Lights and Instruments)
- Instrument Panel Light (**Applied for Night VFR**)
- Cabin Light (**Applied for Night VFR**)
- Aileron Electric Trim (**From aircraft serial number S0380**)

5.9.1.1 Engine

Rotax 912 ULS

- Internal Generator 250 W DC
- Dual Ignition
- Electrical Starter (12 V 0.9 kW)
- Rectifier-Regulator
- Internal Generator 250 W DC
- Electric Fuel Pump (12 V DC)

Rotax 914 UL

- Electronic Control of Boost Pressure (TCU = Turbo Control Unit)
- Dual Ignition
- 2 Electric Fuel Pumps (12 V DC)
- Electric Starter (12 V 0.7 kW)
- Rectifier-Regulator

Rotax 912 iS Sport

- Fully redundant EMS (Electronic Engine Management)
- Electric Starter (12 V 0.8 kW)
- Fuel Pump Assy.
- Rectifier-Regulator A
- Rectifier-Regulator B
- Generator A 220 W
- Generator B 420 W

5.9.1.2 Circuit Breakers

The Super Petrel LS electrical system is protected with Circuit Breakers in order to avoid any damage or overvoltage.

CIRCUIT BREAKERS	AMPERAGE (A)
GYRO	5
TC	5
TCAS	3
GPS	3
VHF	5
XPNDR Dynon	5
SCREEN 1 LEFT	5
SCREEN 2 RIGHT	5
TRIM	3
EMS	5
AUTOPILOT	5
STROBE	5
ALTERNATOR	5
MAIN FUEL PUMP	5
AUX. FUEL PUMP	5
LANDING LIGHT	5
BILGE PUMP	5
AUX. 12 V	5
DRAIN	3
ADSB Dynon	3
PANEL LIGHTS	3
ELT	1
TCU	5
BACKUP	25
POWER	25
ADAHRS Dynon	3
ADAHRS Garmin	2
BACKUP BATTERY	5
CABIN HEATER	5
XPNDR/ADSB Garmin	3

NOTE

Circuit Breakers are installed according to the engine configuration.

5.9.1.3 Schematic Diagrams




Figure 5-77. Panel Electrical Diagram 912 ULS





Figure 5-78. Feeding Electrical Diagram 912 ULS



P3-A	AWG 22	MIC 1 WHITE CABLE
P3-B	AWG 22	PTT MIC 1 WH/ORANGE CABLE
P3-C	AWG 22	GND MIC 1 WH/BLUE CABLE
P3-D	AWG 22	PHONE 1
P3-E	AWG 22	MIC 2
P3-F	AWG 22	PTT MIC 2 WH/ORANGE CABLE
P3-G	AWG 22	GND MIC 2 WH/BLUE CABLE
P3-H	AWG 22	PHONE 2
P3-J	AWG 22	GND PHONE 2
P3-K	-	-
P3-L	-	-
P3-M	AWG 24	LANDING GEAR UP BLUE LED
P3-N	AWG 24	LANDING GEAR DOWN GREEN LED
P3-P	AWG 22	GND SHIELD MIC 1
P3-R	AWG 22	GND PHONE 1
P3-S	AWG 22	GND SHIELD MIC 2
P3-T	AWG 22	GND SENSOR TREM DE POUSO
P3-U	AWG 20	GND DRAIN PUMP
P3-V	AWG 20	DRAIN PUMP

Notes:

ED_ELE_003

⏏ GND BATTERY

Page 3 of 4 ⏏ GND ENGINE

Super Petrel LS Jacks, Drain and
Landing Sensor Electrical Diagram

Engine:	ROTAX 912 ULS	Aircraft:	Super Petrel LS
Revision Number:	01	Revision Date:	03/26/2015
Approved:	Fernando Abbud	Description:	Electrical Design
		Issue date:	05/06/13
		Draftsman:	Ednelson Alberto de Mello

Figure 5-79. Jacks, Drain and Landing Gear Sensor 912 ULS





Figure 5-80. Engine Sensor Electrical Diagram 912 ULS





P2-A	AWG 22	NAV LIGHT
P2-B	AWG 18	FUEL PUMP
P2-C	AWG 22	STROBE LIGHT
P2-D	AWG 16	LANDING LIGHT
P2-E	AWG 24	GND ALTERNATOR LED
P2-F	AWG 24	TRIM WH/GREEN
P2-G	AWG 24	TRIM WH/ORANGE
P2-H	AWG 24	TRIM WH/BLUE
P2-J	AWG 20	+12V SERVO ROLL
P2-K	AWG 20	GND SERVO ROLL
P2-L	AWG 20	DISCONNECT SERVO ROLL
P2-M	AWG 20	BILGE PUMP AUTOMATIC
P2-N	AWG 18	BILGE PUMP
P2-P	AWG 18	START SWITCH
P2-R	AWG 24	TRIM ELEVATOR
P2-S	AWG 24	TRIM ELEVATOR
P2-T	AWG 18	MASTER SWITCH
P2-U	AWG 16	GND BILGE PUMP AND FUEL PUMP
P2-V	AWG 18	KEEP ALIVE (BATTERY)
P4-1	AWG 20	+12v GRIP STICK
P4-2	AWG 20	DISCONNECT P.A.
P4-3	AWG 20	GND GRIP STICK
P4-4	AWG 20	GND GRIP STICK
P5-1	AWG 20	PRESS TO TALK I
P5-2	AWG 20	PRESS TO TALK II
P5-3	AWG 20	TRIM ELEVATOR
P5-4	AWG 20	TRIM ELEVATOR

Notes:

ED_ELE_006


⚡ GND BATTERY

Page 2 of 5 ⚡ GND ENGINE

Super Petrel LS Feeding Electrical Diagram

Engine:	ROTAX 914 UL	Aircraft:	Super Petrel LS
Revision Number:	01	Description:	Electrical Design
Approved:		Issue date:	05/06/13
	Fernando Abbud	Draftsman:	Ednelson Alberto de Mello

Figure 5-82. Feeding Electrical Diagram 914 UL



P3-A	AWG 22	MIC 1 WHITE CABLE
P3-B	AWG 22	PTT MIC 1 WH/ORANGE CABLE
P3-C	AWG 22	GND MIC 1 WH/BLUE CABLE
P3-D	AWG 22	PHONE 1
P3-E	AWG 22	MIC 2
P3-F	AWG 22	PTT MIC 2 WH/ORANGE CABLE
P3-G	AWG 22	GND MIC 2 WH/BLUE CABLE
P3-H	AWG 22	PHONE 2
P3-J	AWG 22	GND PHONE 2
P3-K	-	-
P3-L	-	-
P3-M	AWG 24	LANDING GEAR UP BLUE LED
P3-N	AWG 24	LANDING GEAR DOWN GREEN LED
P3-P	AWG 22	GND SHIELD MIC 1
P3-R	AWG 22	GND PHONE 1
P3-S	AWG 22	GND SHIELD MIC 2
P3-T	AWG 22	GND SENSOR TREM DE POUSO
P3-U	AWG 20	GND DRAIN PUMP
P3-V	AWG 20	DRAIN PUMP

Notes:

ED_ELE_007

⌚ GND BATTERY

Page 3 of 5 ⌚ GND ENGINE

Super Petrel LS Jacks, Drain and
Landing Sensor Electrical Diagram

Engine: ROTAX 914 UL
Revision Number: 01 03/26/2015
Approved: Fernando Abbud

Aircraft: Super Petrel LS
Description: Electrical Design
Issue date: 05/06/13
Draftsman: Ednelson Alberto de Mello



Figure 5-83. Jacks, Drain and Landing Sensor 914 UL




Figure 5-84. Engine Sensor Electrical Diagram 914 UL







Figure 5-85. TCU and Fuel Pumps 914 UL












Figure 5-89. Super Petrel LS Panel Night VFR and Landing Lights Electrical System









5.9.1.4 Acceptable Methods, Techniques and Practices for Electrical System Maintenance

The satisfactory performance of an aircraft is dependent upon the continued reliability of the electrical system. Damaged wiring or equipment in an aircraft, regardless of how minor it may appear to be, cannot be tolerated. Reliability of the system is proportional to the amount of maintenance received and the knowledge of those who perform such maintenance. It is, therefore, important that maintenance be accomplished using the best techniques and practices to minimize the possibility of failure.

Inspect equipment, electrical assemblies and wiring installations for damages, general condition and proper functioning to ensure the continued satisfactory operation of the electrical system. Replace components of the electrical system that are damaged or defective with identical parts.

Annual cleaning of electrical equipment to remove dust, dirt and grime is recommended. Suitable solvents or fine abrasives that will not score the surface or remove the plating may be used to clean the terminals and mating surfaces if they are corroded or dirty. Only cleaning agents that do not leave any type of residue must be used. Avoid using emery cloth to polish commutators or slip rings because particles may cause shorting and burning. Be sure that protective finishes are not scored or damaged when cleaning.

Annually check bus bars for general condition, cleanliness, and security of all attachments and terminals. Grease, corrosion, or dirt on any electrical junction may cause the connections to overheat and eventually fail. Bus bars that present corrosion, even in limited amounts, should be disassembled, cleaned, brightened and reinstalled.

NOTE

Apply a corrosion inhibitor (Ardrox AV8, CorrosionX or similar) as necessary in order to mitigate general corrosion

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices, Chapter 11. Aircraft Electrical Systems.

WARNING

TURN THE POWER OFF BEFORE CLEANING.

5.9.2 Electrical System Inspection

Required Tools:	Flashlight
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

The inspection of the electrical system must be visually made. It is not necessary to remove the parts or components of system. Do not take off if you suspect any kind of abnormal behavior.

NOTE

Remove or open all cowlings, inspection windows, access doors and baggage compartment, before starting the inspection.

5.9.2.1 Battery Inspection

Open the inspection window located on the fuselage's nose and inspects the battery as follows:

1. Cables Condition: use a flashlight if necessary.
 - a) Check the cables for general condition and attachment. Replace them if necessary.
2. Battery Condition: use a flashlight if necessary.
 - Check the battery for security and attachment.
 - Replace the battery if necessary.

CAUTION

Battery should be replace on condition, however, it is recommended to replace it every 2 years.

5.9.2.2 Wiring Harness Inspection

1. Check the condition, integrity, connection and security of the wiring harness (loose, damaged, burned) as follows:
 - Open the inspection window located on the fuselage's nose and check the instrument panel wiring harness.
 - Inside the fuselage, check the wiring harness that goes to the engine (Fuselage and Pylon).
 - Inside the engine compartment, check the wiring harness condition.

5.9.2.3 Bilge Pump Inspection

1. General Condition: use a flashlight if necessary.
 - Check the cover (fabric) of the bilge pump. Remove the bilge pump body from its support if necessary and inspect for presence of dirty and correct operation of rotor (free rotation). Reinstall correctly after the inspection (bilge pump and cover).
2. Operational Condition: use a flashlight if necessary.

NOTE

Battery Master Switch must be OFF to complete this inspection.

- Check the correct operation of the bilge pump electrical system. Ensure the full functional of the ON/OFF switch on the instruments panel (flashing light).
- Pour water (approx. 5 liters) through the inspection window and make an operational check of the bilge pump.
- When the inspection is finished, clean the hull internally with water and remove all dirt and material loose which could obstruct the bilge pump. Drain the water from the washing using the bilge pump and clean the protection cover if necessary.

5.9.2.4 Fuses and Fuses Holders

Inspect as follows:

- Check the security of the fuse holder connections
- Inspect for presence of corrosion and evidence of overheating on fuses and fuse holders. Replace corroded fuses and clean fuse holders. If evidence of overheating is found, check for correct rating of fuse
- Check the security of fuse holder mounts
- Replace previously used spare fuses with appropriate rating fuses.

5.9.2.5 Warning Lights Inspection (Lane A, Lane B, TCU and Alternator)

Inspect as follows:

- Check the security of the bulb holder.
- Make an operational test of the lights.
- If necessary replace the damaged lights. **(See 6.2.3.15 Warning Lights Replacement).**

5.9.2.6 Other Components

Inspection of the components such as Elevator Electric Trim, Aileron Electric Trim, Instrument Panel Light, Dome Light, Nav / Strobe Lights, Landing Lights, Headphones Plugs, etc., should be performed as follows:

- Check for general condition and attachment.
- Check electrical terminals (connectors) for corrosion and general condition. Replace them if necessary.

5.9.3 Electrical System Maintenance, Repair and Overhaul

Repairs or alterations in the Electrical System are not authorized at this time. To obtain engineering approvals for any repairs or alterations, please contact Scoda Aeronáutica at engineering@scodaero.com.br.

5.10 Structural Repair

Aircraft structural components are designed to perform a specific function or to serve a definite purpose. The main objective of the aircraft repair is to restore damaged parts to their original condition. Very often, replacement is the only way in which this can be done effectively.

Repairs or alterations on Structural Parts are not authorized at this time. To obtain engineering approvals for any repairs or alterations, please contact Scoda Aeronáutica at engineering@scodaero.com.br

5.11 Painting and Coatings

Super Petrel LS uses Polyurethane UHS paint as topcoat on flying surfaces as well as composite parts. Fabric is used for Wings and Rudder covering.

NOTE

Please refer to the latest edition of the FAA-H8083-31 A – Aircraft Maintenance Technician Handbook, Chapter 8. Aircraft Painting and Finishing.

Paint is more than aesthetics; it affects the weight of the aircraft and protects the integrity of the airframe. The topcoat finish is applied to protect the exposed surfaces from corrosion and deterioration. In addition, a properly painted aircraft is easier to clean and maintain. The exposed surfaces are more resistant to corrosion and dirt, oil does not adhere as readily to the surface.

5.11.1 Paint Code and Specification

Manufacturer: PPG

Description: Bco UHS White SPLS AIR

Composition:

Code	Quantity
Deltron D525	1.1
Deltron D528	3.9
Deltron D503	7.1
Deltron D500	1234.0

5.11.2 Painting Repairs

NOTE

It is recommended that all the following procedures be performed in a well-ventilated area, at temperatures between 68°F and 100°F (20°C - 37°C).

NOTE

Please refer to the latest edition of the FAA-H8083-31 A – Aircraft Maintenance Technician Handbook, Chapter 8. Aircraft Painting and Finishing

CAUTION

Before starting the repair, cover the windshield and doors.

Required Tools:	N/A
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

SAFETY RULES

When working with paints, thinners and solvents follow the following safety rules:

1. It is necessary to follow safety rules for working with flammable and volatile substances.
2. Working area should be properly ventilated.
3. Smoking and open flames are prohibited in the work area.
4. Use protective equipment such as goggles, gloves, respirator, etc.

CAUTION

By applying permanent protective coating, aircraft weight and balance are affected. The increases in weight depend on the type of coating and its thickness.

5.11.2.1 *Puttying*

- Preparing the surface for repair, sand it with 180-grit sandpaper as applicable in order to remove the brightness/gloss.
- Apply finishing pastes (Epoxy Filler, Polyester Paste with Catalyst and Gray Paste) in order to fill the cavities and interstices between the fibers of the fabric. Attempt to minimize the thickness of the repair by skimming the paste.
- Remove the excess finishing paste with a 120 – 220 grit sandpaper.
- Remove the dust with a wet cotton fabric.
- Inspect the surface being repaired thoroughly for cavities needed to be corrected. If no defects found, the surface can be primed.

5.11.2.2 *Priming*

- Place the part being repaired into a paint room.
- Apply one layer of Primer.
- Place the part into a compartment with a temperature at least 68 °F (20 °C) for 1 hour.
- Smooth down the surface with a 320 grit sandpaper.
- Remove the dust with a wet cotton fabric.

5.11.2.3 *Painting*

- Apply one layer of paint onto the surface being repaired so that it just covers the primer.
- Place the part into a compartment with a temperature at least 68 °F (20 °C) for 1 hour.
- As soon as the first layer of paint gets dry, apply the second layer of paint minimally needed to cover the first one.
- Place the part into a compartment with a temperature at least 68 °F (20 °C) for 12 hours.

5.11.2.4 Polishing

- Sand the surface that needs to be polished with 1500-grit Water Sandpaper.
- Apply Polishing Paste onto the surface and rub with smooth circular hand motions, applying light pressure.
- Continue polishing with a right-angle orbital polisher for a minimum of 2-3 passes.
- Clean the polished surface with a piece of cotton fabric in order to remove excess polishing paste.
- Apply Polishing crème to the surface with a dry cotton fabric to bring surface to a gloss. A right-angle orbital polisher can be used.

5.11.2.5 Method of Verification

- Touch the painted surfaces the finished surface should be smooth, no dents or bumps.
- Inspect painted surface visually from various viewpoints. Paint runs and unpainted areas are unacceptable. Quality of polishing should be the same as adjacent areas.

5.11.3 Corrosion, Inspection and Protection

Required Tools:	N/A
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

The information supplied here is as a general guideline only. It is by no means intended to be exhaustive, complete or authoritative.

It is important to keep the aircraft clean and to remove any collection of corrosive causing agents such as water, anti-freeze, oil, grease, dregs and other foreign matter.

To avoid damage to the finish, do not use polishing detergents. Original or equivalent corrosion prevention, if used, should be re-applied after any alteration or repair. If any trace of corrosion is detected it should be removed as soon as possible and the applicable part should be treated immediately to prevent further corrosion. Treatment consists of mechanically removing as much as possible of any corrosion by-products, applying corrosion inhibitor and replacing any original finish.

For more information in order prevent, control, identify, and treat various types of corrosion, refer to the latest edition of FAA ADVISORY CIRCULAR AC 43-13-1B, Chapter 6. Corrosion, Inspection and Protection.

NOTE

Apply a corrosion inhibitor (Ardrox AV8, CorrosionX or similar) as necessary in order to mitigate general corrosion

NOTE

Refer to the latest edition of FAA ADVISORY CIRCULAR AC 43-4B, CORROSION CONTROL FOR AIRCRAFT for a more in-depth study on the detection and treatment of corrosion.

5.12 Revisions

Revisions to this maintenance manual can be located in the revision control page and the list of effective pages section.

5.13 Feedback Form

Reports, comments or difficulties in relation with the use of this manual are welcome by completing the FORM_SPLS_002_Continued Operational Safety Reporting Form. This form is located in the Appendix Section of this Manual or Scoda Aeronáutica's website (www.scodaeronautica.com.br). This form should be completed and sent to: engineering@scodaero.com.br

6 Line Maintenance, Repairs, and Alterations

6.1 Authorization to Perform Line Maintenance, Repairs and Alterations

Any inspection, repair, and alteration outlined in this Section should be performed if the organization or individual holds the following maintenance rating:

- LSA Repairman Maintenance Certificate
- A&P Certificate
- iRMT Training (at least Service ROTAX® Aircraft Engines Rating)
- Super Petrel LS Maintenance Training (at least Line Maintenance Super Petrel LS Rating)

Typical Tasks Considered as Line Maintenance for LSA's Include:

1. 100-h inspection / Annual Condition Inspection,
2. Servicing of Fluids,
3. Removal and replacement of components for which instructions are provided in the maintenance manual,
4. Repair of components and structure for which instructions are provided in the maintenance manual and which do not require specialized training.

Guidance for accomplishing such maintenance, repairs, alterations, and inspections is contained in this manual and should be accomplished in accordance with the practices described in the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – ACCEPTABLE METHODS, TECHNIQUES, AND PRACTICES – AIRCRAFT INSPECTION AND REPAIR.

6.2 Line Maintenance Tasks

6.2.1 100-h Inspection / Annual Condition Inspection

Refer to Inspection's Section 1.1 of this manual for 100-hour / Annual Inspection requirements

6.2.2 Servicing of Fluids

This information gives the general servicing procedures and maintenance practices that are to be used when servicing the aircraft.

For additional detailed information concerning the unit servicing of the engine, refer to the applicable chapters of the Manufacturer's Engine Manual.

For tire pressure information, please refer to Tire Inflation Pressures Section of this Manual.

The intervals specified in this section are considered adequate to meet average requirements under normal operating conditions. It is advisable to shorten the service and maintenance intervals when operating under abnormal environmental conditions, such as high humidity and moisture, salt-water environments, dusty atmospheric conditions and extreme temperature ranges. In salt-water areas, special care should be taken to keep the engine, accessories, and airframe clean to help prevent oxidation and corrosion.

6.2.2.1 Oil Check and Replenish

1. Remove the upper engine cowling.
2. Follow the instructions described in the last revision of the Rotax Line Maintenance Manual, Oil Level check / Replenish Section.
3. Reinstall the upper engine cowling.

CAUTION

If engine runs mainly on AVGAS, more frequently oil changes will be required. See the latest edition of engine manufacturer's Service Information SI-912i-001.

6.2.2.2 Oil Change

NOTE

According to the last revision of the Rotax Line Maintenance Manual oil change should be carry out every 50 hours.

1. Remove the upper and lower engine cowling.
2. Before removing the oil tank, make a mark on the oil tank and upper wings rectangular support. This mark will help to reinstall the oil tank in the same position which was installed originally.



Figure 6-1

3. Follow the instructions described in the last revision of the Rotax Line Maintenance Manual, Oil Change Section.
4. After carrying out the oil change reinstall the oil tank in the aircraft.

CAUTION

The oil tank should be installed following the mark which was made in the step above.

CAUTION

Do not tighten the oil hose's nut to the maximum.

CAUTION

Oil system lines should be properly reinstalled in the oil tank and not rubbing against the structure. Also it should be avoided dents, bulges and signs of damages in the oil lines that might restrict the oil flow or cause a leak.

5. Reinstall the upper and lower engine cowling.

6.2.2.3 Coolant Replacement

NOTE

This procedure should be accomplished every 5 years.

NOTE

Coolant replacement should be performed according to the Rotax original manuals.

Types of coolant	As per Rotax 912 iS Sport Engine original manuals.
-------------------------	--

- (Recommended: Conventional Coolant 50 / 50) **Honda Genuine Coolant Type 2 – All season antifreeze.**
- **Coolant replacing procedure should be performed as per Rotax Instructions**
- **Recommended Coolant Level:** it should be in the middle of the overflow bottle.




6.2.2.4 Lubrication Table (Line Maintenance)


SECTION	LUBRICATION AREA	VIEW	NUMBER OF SERVICE POINTS	INTERVAL	LUBRICANT
ENGINE	Oil Reservoir	---	1	Every 50h (As per Rotax Maintenance Manual)	AeroShell Sport Pus 4
	Throttle Cable	A	2	Every 100h	Chain Lube
	Choke Cable	B	2	Every 100h	Chain Lube
FUSELAGE	Elevator Control Push-Pull Tube	C	1	Every 100h	Chain Lube
	Aileron Control (Inside Pylon)	D	3	Every 100h	Chain Lube
	Joystick Assembly (Movable Joints)	E	8	Every 100h	Chain Lube
	Pedals (Movable Joints)	F	4	Every 100h	Chain Lube
	Rudder Cables and Movable Joints	G	4	Every 100h	Chain Lube
	Landing Gear Retraction System	H	10	Every 100h	Chain Lube
	Door Hinges	I	4	Every 100h	Chain Lube
	Door Lock System	J	4	Every 100h	Nautical Grease
EMPENNAGE	Elevator (Movable Joints)	K	4	Every 100h	Chain Lube
	Electric Trim Tab Hinges	L	3	Every 100h	Chain Lube
	Rudder Cables and Movable Joints	M	4	Every 100h	Chain Lube
WINGS	Aileron Rod End	N	2	Every 100h	Chain Lube
	Aileron Hinges	O	8	Every 100h	Chain Lube
	Electric Trim Tab Hinges	O	2	Every 100h	Chain Lube
NOSE LANDING GEAR	Axle	P	1	Every 100h	Graphite or Nautical Grease
	Articulated Joints	S	7	Every 100h	Chain Lube
MAIN LANDING GEAR	Axle	Q	2	Every 100h	Graphite or Nautical Grease
SHOCK ABSORBERS	Rod Ends	R	4	Every 100h	Chain Lube or Nautical Grease


NOTE

Apply a corrosion inhibitor (Ardrox AV8, CorrosionX or similar) as necessary in order to mitigate general corrosion

6.2.2.5 Lubrication View







6.2.3 Removal and Replacement of Components

NOTE

Check the List of Disposable Replacement Parts for consulting Part Number and Supplier of the Items.

NOTE

SCODAAERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

6.2.3.1 Windshield and Doors Replacement

Required Tools:	As applicable
Parts and Materials Required:	Bidirectional Fiberglass 160 g/m ²
	Peel Ply 85 g/m ²
	Epoxy resin – HTR-212 LAMINATING RESIN (Aircraft Spruce P/N: 01-00430) or similar
	Structural Adhesive – Hysol or similar
	Flocked Cotton Fiber or Microballoon (glass bubbles)
	Sand Paper #80
	Sand Paper #180
	Masking tape
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

Instructions for windshield and doors replacement are the same, just should be considered the quantity of material.

1. Remove the old Plexiglass.
2. Clean all the residual material from the structure (door or fuselage) sand with Sand Paper #80.

NOTE

It is recommended to cover the new Plexiglass with paper or a plastic film in order to avoid damages during handling and installation.

3. Make a dry installation of the Plexiglass on the structure.
4. Prepare the Plexiglass by sanding the area where will be glued. Use a Sand Paper #180.
5. Apply structural adhesive on the Plexiglass and structure.
6. Install the Plexiglass and remove the excess of structural adhesive.
7. Cover the junction Plexiglass-Structure with masking tape.
8. Leave to cure for 24hr.
9. Remove the masking tape and prepare the surface for laminating.
10. Laminate one layer of Bidirectional Fiberglass 160 g/m² over the junction.
11. Apply one layer of Peel Ply 85 g/m².
12. Leave to cure for 24hr.
13. Perform finishing and painting. Refer to the Section 5.11 Painting and Coatings of this Manual.

6.2.3.2 Fuel Filter Replacement

Required Tools:	Ear Clamp Plier (1 pc)
	Combined Wrench 17 mm (1 pc)
	Combined Wrench 1 inch (1 pc))
	Torque Wrench (1 pc)
	Tray
Parts and Materials Required:	HOLLEY Inline Fuel Filter 3/8" 100 Micron P/N HLY-162-551 (912 ULS / 914 UL)
	HOLLEY Fuel Filter Elements Kit P/N HLY-162-557 (912 ULS / 914 UL)
	ANDAIR Inline Fuel Filter 3/8" Fuel Lines 62 Micron P/N FX375-M (912 iS Sport)
	ANDAIR Inline Fuel Filter 3/8" Fuel Lines 62 Micron P/N FX375-MK (NPT MALE OUTPUT) (912 iS Sport) (an adapter 6AN Male to 1/4 NPT Female should be use)
	ANDAIR Spare O-ring for FX375 Filters P/N ORO30x15
	Ear Clamps for 3/8" lines

Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

EARLS Inline Fuel Filter 3/8" 85 Micron – P/N 230206ERL was discontinued.

ANDAIR FX375-M or FX375-MK

NOTE

For installation of the fuel filter model FX375-MK should be used an adapter 6AN Male to 1/4 NPT Female in the filter output.

1. Remove the lower baggage compartment.
2. Close the Fuel Shut Off Valve and Fuel Selector Valve.
3. Remove the old fuel filter.

NOTE

Use a tray in order to collect the small quantity of residue fuel.



Figure 6-2

4. Install the hose fittings onto the new fuel filter. Apply a torque between **75 - 125 in-lb (8.5 - 14 N.m)**.

NOTE

Torque recommended for hoses with outside diameter of 3/8 inches and Fittings - 6. Reference: FAA-H-8083-30A – Aviation Maintenance Technicians Handbook.

5. Install the new fuel filter in the fuel lines.

NOTE

Check for the flow direction that is indicated on the fuel filter housing.

NOTE

Replace the O-Ring of the fuel filter as necessary.

6. Install new ear clamps.
7. Open the Fuel Shut Off Valve and Fuel Selector Valve and check for leakage.
8. Engine running test recommended prior to flight.
9. Install the lower baggage compartment.

HOLLEY HLY-162-557 (Fuel Filter Elements Kit)

1. Remove the lower baggage compartment.
2. Close the Fuel Shut Off Valve and Fuel Selector Valve.
3. Remove the fuel filter.

NOTE

Use a tray in order to collect the small quantity of residue fuel.



Figure 6-3

4. Open the fuel filter.




Figure 6-4

5. Replace the fuel filter elements (filter and O-rings).



Figure 6-5

6. Install the fuel filter.

NOTE

Check for the flow direction that is indicated on the fuel filter housing.

7. Install new ear clamps.
8. Open the Fuel Shut Off Valve and Fuel Selector Valve and check for leakage.
9. Engine running test recommended prior to flight.
10. Install the lower baggage compartment.

6.2.3.3 Fuel Sensor Unit Replacement

Refer to the last revision of the Service Instruction SI_SPLS_002 Fuel Sensor Unit Replacement.

NOTE

SCODA AERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

6.2.3.4 Battery Replacement

Required Tools:	Combined Wrench 8 mm
Parts and Materials Required:	N/A
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

Super Petrel LS uses a 12-volt, 18 AMP Hour sealed lead acid or gel battery, which is located in front of the rudder pedals.

To remove and/or replace the battery, follow the steps:

1. Open the inspection door.
2. Disconnect the two battery connector leads, negative side first.
3. Remove the attachment ribbon.
4. Remove the Battery.

The battery installation follows the same steps in a reverse sequence.

WARNING

DO NOT REPLACE THE SEALED LEAD ACID BATTERY BY A WET LEAD ACID BATTERY.

6.2.3.5 Instruments

Required Tools:	As Applicable
Parts and Materials Required:	As Applicable
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

Replacement should be made according to the Original Equipment Manufacturers Installation Manual as applicable.

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices, Chapter 12. Aircraft Avionics Systems.

6.2.3.6 Filling Brake System

Required Tools:	As Applicable
Parts and Materials Required:	Reservoir
	Hose
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

This procedure should be accomplished every 5 years or every 1000 hours.

Two individuals are required to perform this inspection. Before starting, visually check the brake system for integrity and tightness.

To fill the brake system, follow the procedure described below:

1. Disconnect the oil reservoir from its support and with assistance, hold it in a position higher than the master cylinders;
2. Attach the oil-can to a brake assembly lower valve, open it and pump oil through the line (As shown below). Notice that as you are pumping oil through the brake line, bubbles of air will flow to the master reservoir. Soon the oil will reach and fill the reservoir;




Figure 6-6

3. Close the valve, disconnect the filling tube and repeat with the other brake assembly. Ask your assistant to fill the oil reservoir with brake fluid;
4. After closing the valve, disconnect the filling tube from the oil can and leave it in an empty can;
5. Ask your assistant to pump the respective brake pedal several times and then keep it pressed while you open the valve allowing the oil and bubbles to spill out;
6. Close the valve and repeat the process. Notice that each time you repeat the process, the pedals will get harder, because the amount of air bubbles is diminishing;
7. Fill the oil reservoir, because it tends to empty;
8. Do the same process to the other brake line and when noticing that the lines are free of air bubbles, fill the reservoir as required and reinstall.

CAUTION

Be careful to avoid spilling oil, in particular, on painted parts, because the oil is corrosive and can cause damages.

6.2.3.7 Brake Pads Replacement

Required Tools:	Combined Wrench 24 mm (1 pcs)
	Combined Wrench 8 mm (1 pcs)
	Pliers
Parts and Materials Required:	Brake Pads (SE-520.022)
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

1. Lift the aircraft
2. Remove the cotter pin with the pliers and remove the castle nut. Then remove the wheel.



Figure 6-7

3. Remove the brake disc.



Figure 6-8

4. Remove the five bolts using one (1) combined wrench 8 mm and replace the brake pads.



Figure 6-9

5. Reinstall the brake disc.
6. Reinstall the wheel. Tighten the castle nut using one (1) combined wrench 24 mm until the bearing and axis are fitted. Then install the cotter pin.

CAUTION

Do not leave the castle nut tightened to the maximum in order to avoid applying force the bearing. The wheel must have free rotation.



Figure 6-10

6.2.3.8 Brake Discs Replacement

Required Tools:	Combined Wrench 24 mm (1 pcs)
	Combined Wrench 8 mm (1 pcs)
	Pliers
Parts and Materials Required:	Brake Discs
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

- For the brake discs replacement, you should follow the first three items of the procedure above. Replace the brake disc and then reinstall the wheel as explained on the sixth item of the procedure above.



Figure 6-11

6.2.3.9 Bearing Replacement

6.2.3.9.1 Main Wheels

Required Tools:	Combined Wrench 24 mm (1 pcs)
	Combined Wrench 8 mm (1 pcs)
	Pliers
	Punch Pin
	Nylon Hammer
	Steel Hammer
Parts and Materials Required:	Bearing for Main Wheels (See Section 5.1.3 List of Disposable Replacement Parts)
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

- Lift the aircraft
- Remove the cotter pin with the pliers and remove the castle nut. Then remove the wheel.



Figure 6-12

3. Remove the old bearing. Use a punch pin and nylon hammer as shown below.



Figure 6-13

4. Install the new bearing. Use the old bearing over the new and with a steel hammer fit it in the wheel as shown below.

CAUTION

Be careful to not deform the new bearing



Figure 6-14

5. Reinstall the wheel.

6.2.3.9.2 Nose Wheel

Required Tools:	Allen Wrench 6 mm (1 pcs)
	Combined Wrench 13 mm (1 pcs)
	Slotted Screwdriver
	Pliers
Parts and Materials Required:	Bearing for Nose Gear (See Section 5.1.3 List of Disposable Replacement Parts)
	Thread Lock
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

1. Lift the nose of the aircraft up.



Figure 6-15

2. Remove the nose wheel cowling located on the left side, using a slotted screwdriver.



Figure 6-16

3. Remove the cotter pin. Before removing the wheel, make a mark over the nut to the cotter pin direction in order to facilitate its installation.



Figure 6-17

4. Remove the wheel using one (1) Allen Wrench 6 mm and one (1) Combined Wrench 13 mm. Then remove the nylon bushing.



Figure 6-18

5. Replace the bearing following steps 3 and 4 from the Main Wheel bearing replacement.
6. Reinstall the nose wheel. Execute this process in reverse of the removing process.



Figure 6-19

6.2.3.10 Nose Gear Doors Replacement

Required Tools:	As Applicable
Parts and Materials Required:	As Applicable
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

SCODAAERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

1. Lift the nose of the aircraft up.
2. Remove the old nose gear doors.
3. The hinge which is inserted in the fuselage should not be removed.
4. Place the new nose gear doors without installing the pin and adjust with the fuselage structure.

NOTE

It is possible to make a fine adjustment by sanding the new doors structure.

5. Install the pins.
6. Perform the finishing and painting of the component if necessary.

6.2.3.11 Landing Gear Cable Inspection and Replacement

Required Tools:	As Applicable
Parts and Materials Required:	As Applicable
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices, Chapter 7. Aircraft Hardware, Control Cables and Turnbuckles, Section 8. Inspection and Repair of Control Cables and Turnbuckles.

Cables are generally fabricated from carbon steel or corrosion-resistant steel wire of either flexible or non-flexible-type construction. Cables are subject to a variety of environmental conditions and deterioration. Wire or strand breakage is easy to visually recognize.

6.2.3.11.1 Cable Inspection

To assure the continued landing gear cable integrity, it is recommended to accomplish an inspection each 100 hours or annually.

Landing gear cables should be inspected for wear, corrosion, and/or distortion. Any cable assembly that has one broken wire strand located in a critical fatigue area must be replaced.

A critical fatigue area is defined as the working length of a cable where the cable runs over, under, or around a pulley, sleeve, or through a fair lead; or any section where the cable is flexed or rubbed.

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices, Chapter 7. Aircraft Hardware, Control Cables and Turnbuckles, Section 8. Inspection and Repair of Control Cables and Turnbuckles.

6.2.3.11.2 Cable Replacement

NOTE

Landing Gear Cables should be replaced on condition, however, it is recommended to replace every 10 years.

Replace landing gear cables when they become worn, distorted, corroded, or otherwise damaged. Use materials of the same size and quality as the original. Standard swaged cable terminals develop full cable strength and may be substituted for the original terminals wherever practical.

LANDING GEAR CABLES REPLACEMENT TIPS (CABLES POSITION):

1. There are two cables: **Cable 1 and Cable 2.**

NOSE GEAR (Cable Length: 10.5 feet – 3.2 meters)

Cable 1 which has 5.25 feet (1.6 meters). This comes from the upper part of the nose gear pulley, goes to pilot side of the double pulley, passes through the single pulley (located in the aircraft floor) and goes to the upper part of the retraction lever pulley.

Cable 2 which has 5.25 (1.6 meters) comes from the lower part of the nose gear pulley, goes to the copilot side of the double pulley and goes directly to the lower part of the retraction lever pulley.




Figure 6-20

MAIN GEAR (Cable Length 145 feet (4.4 meters))

Cable 1 has 72 feet (2.2 meters). 36 feet (1.1 meters) comes from the upper part of the retraction lever pulley and passes through the single pulley (located behind the seats) and goes to the turnbuckle of the pilot side. The other 36 feet (1.1 meters) comes from the turnbuckle of the pilot side, passes through the pilot side single pulley (located in the bulkhead) and goes up to pilot side of the main pulley.

Cable 2 has 72 feet (2.2 meters). 36 feet (1.1 meters) comes from the lower part of the retraction lever pulley goes directly to the turnbuckle of the copilot side. The other 36 feet (1.1 meters) comes from the turnbuckle of the copilot side, passes through the copilot side single pulley (located in the bulkhead) and goes up to copilot side of the main pulley.




Figure 6-21

2. Lift the aircraft.
3. Lower the landing gear (DOWN position).
4. Press the nose leg linkage back against the rubber stop.

NOTE

Lock the nose gear assembly. This should be resting on a chock, simulating that it is on the ground. See picture below.




Figure 6-22

5. Loosen the screws of the clamp which is fixing the nose gear cables, without removing.
6. Cable 2 should be pulled first applying good tension. Then tighten the screw.
7. In sequence make the same process with Cable 1.
8. Lastly tighten the screw of the middle.

NOTE

Two people is recommended to perform this procedure.

NOTE

Careful should be taken with the Installation of the cables inside the clamp. The cables should be between the stainless steel and brass clamp (see picture below).




Figure 6-23

9. Retract and lower the landing gear system several times, checking for correct operation.
10. Check the correct position of the Nose Gear Pulley when cycling the landing gear system (see pictures below).



LANDING GEAR LOWERED



LANDING GEAR RETRACTED

Figure 6-24

11. It is very important to check if the cable runs properly through all the pulleys of the landing gear retraction system.

CAUTION

Crossing cables should be avoided in order to keep the correct functionality of the system.

NOTE

SCODA AERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

6.2.3.11.3 Cables Specification

DESCRIPTION	TECHNICAL SPECIFICATION	QUANTITY	SCODA PART NUMBER
Nose Gear Cable	Stainless Steel 316 Cable 3/32"	105 feet (3.2 meters)	SE-324.004
	Nicopress Oval Sleeve 3/32"	2 pieces	
Main Gear Cable	Stainless Steel 316 Cable 3/32"	145 feet (4.4 meters)	SE-323.004
	Nicopress Oval Sleeve 3/32"	4 pieces	

6.2.3.12 Shock Absorber Calibration and Replacement

Required Tools:	As Applicable
Parts and Materials Required:	As Applicable
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices, Chapter 9. Aircraft Systems and Components, Section 1. Inspection and Maintenance of Landing Gear.

NOTE

Please refer to the latest edition of the FAA-H-8083-31-AMT-Airframe-Vol-2 – Aviation Maintenance Technician Handbook Airframe, Vol. 2 Chapter 13. Aircraft Landing Gear Systems.

The shock absorber of the Super Petrel LS is constructed of two telescoping cylinders or tubes that are closed on the external end. The upper cylinder is fixed to the aircraft landing gear retraction system and is free to slide in and out of the lower cylinder. The lower cylinder is fixed to the main landing gear leg.

6.2.3.12.1 Shock Absorber Inspection

Shock absorber should be inspected for evidence of leaks, cracks, and possible bottoming out of the piston, as the condition causes overloading of landing gear components and contributes to fatigue cracks. Check all bolts, bolts holes, pins, and bushings for condition, lubrication and proper tightening.

- **Calibration** of the shock absorber should be made while the aircraft is on the ground, presents symptoms of bend/sagging outward of the landing gear legs (**See Section 6.2.3.12.2 Shock Absorber Calibration**).
- **Replacement** of the shock absorber should be made when the component presents evidence of leakage (**See Section 6.2.3.12.3 Shock Absorber Replacement**).

6.2.3.12.2 Shock Absorber Calibration

Insufficient fluid or air in the shock absorber, will cause the compression stroke to not be properly limiting. The shock absorber could bottom out, resulting in impact forces to be transferred directly to the airframe through the shock absorber structure.

WARNING

THE TECHNICIAN MUST BE THOROUGHLY FAMILIAR WITH THE OPERATION OF THE HIGH-PRESSURE SERVICE VALVE FOUND AT THE TOP OF THE SHOCK ABSORBER UPPER CYLINDER.

1. Lift the aircraft. Shock absorber must be expanded, there should be zero load (weight) on it.
2. Remove the cap from the servicing valve located on the upper cylinder.
3. Using a sharp object activate the servicing valve for 1/100 seconds. This step is to make sure the valve is operating freely.
4. A threaded fitting from a controlled source of nitrogen should be screwed onto the servicing valve.

5. Inflate the shock absorber. The servicing of nitrogen pressure is:

Standard Shock Absorber: 700 psi (50 bar).

40mm Shock Absorber: 480 psi (33 bar)

CAUTION

Shock absorber should always be inflated slowly to avoid excess heating and over inflation.

6. Once inflated, it is recommended to wait for 10 seconds.
7. Remove the controlled source of nitrogen from the servicing valve.
8. Install the cap onto the servicing valve.

NOTE

SCODAAERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the FAA-H-8083-31-AMT-Airframe-Vol-2 – Aviation Maintenance Technician Handbook Airframe, Vol. 2 Chapter 13. Aircraft Landing Gear Systems.

6.2.3.12.3 Shock Absorber Replacement

NOTE

SCODAAERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

1. Lift the aircraft.
2. The landing gear should be lowered.
3. Loosen the bolt or pin of the lower cylinder.
4. Loosen the bolt or pin of the upper cylinder.
5. Remove the shock absorber.
6. Install the shock absorber. Execute this process in reverse of the removing process.

CAUTION

Do not forget to install the bushing in the shock absorber ends.

CAUTION

When installing the nuts, these should be tightened until they are secure and then back one thread. The bolt should be able to move freely in order to not restrict the mechanism.

6.2.3.12.4 Shock Absorber Specification

DESCRIPTION	QUANTITY	SCODA PART NUMBER
Standard Shock Absorber	2	SE-323.120
40mm Shock Absorber	2	SE-323.120-1

6.2.3.13 Gas Spring Test and Replacement

Required Tools:	As Applicable
Parts and Materials Required:	Spring Compressor Device (SEE APPENDIX 12.8)
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

The gas spring is a pressurized device; where the piston is permanently subjected to a pressure imposed by an existing gas inside the pressure tube. The gas spring helps the landing gear retraction system to maintain its operating load and balancing.

6.2.3.13.1 Gas Spring Test

1. Lift the aircraft.
2. The landing gear should be retracted.
3. Place a weighing scale at the bottom of the landing gear grip (see picture below).



Figure 6-25

4. Pulling up the weighing scale should require minimum load of **26 lbs (12 kg)** before unlocking the system.
5. If the retraction landing gear system unlocks with less than **26 lbs (12 kg)** replace gas spring (See **Section 6.2.3.13.2 Gas Spring Replacement**).

6.2.3.13.2 Gas Spring Replacement

NOTE

Two people is recommended to perform this procedure.

NOTE

Considering a load of 420 Newton is require to contract the gas spring, it is recommended to use a Spring Compressor Device to help spring compression.

1. Retract the landing gear.
2. One person should fit the spring compressor device onto the upper end of the gas spring.



Figure 6-26

3. Loosen the bolts so that the spring compressor device fits on the gas spring lower end.





Figure 6-27

4. The other person should be handling the landing gear lever. It will be necessary to move the lever until fitting the spring compressor device on the gas spring.

*Figure 6-28*

5. As soon as the lower end of the gas spring is fitted with the spring compressor device, loosen the bolts completely. Place a tie wrap on the spring compressor device body in order to avoid inadvertent expansion.

*Figure 6-29***CAUTION**

Be careful! After removing the gas spring the landing gear will lower abruptly. It is necessary to place a support below the landing gear leg in order to avoid falling down.

6. Take out the gas spring from the spring compressor device. Use a cloth and press down one end of the gas spring until out from the spring compressor device.



Figure 6-30

7. Place the new gas spring on the spring compressor device. Fit one end of the gas spring and press down in order to fit the other end of the gas spring.



Figure 6-31

8. Place a tie wrap on the spring compressor device body.



Figure 6-32

9. Install the gas spring. Execute this process in reverse of the removing process.

NOTE

SCODA AERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

6.2.3.13.3 Gas Spring Specification

DESCRIPTION	QUANTITY	SCODA PART NUMBER
Gas Spring	1	SE-323.050

6.2.3.14 Wiring and Connectors Replacement

Required Tools:	As Applicable
Parts and Materials Required:	As Applicable
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices, Chapter 11. Aircraft Electrical Systems.

Wiring must be replaced with equivalent wire when found to have any of the following defects:

- Wiring that has been subjected to chafing or fraying, that has been severely damaged, or that primary insulation is suspected of being penetrated;
- Wiring of which the outer insulation is brittle to the point that slight flexing causes it to crack;
- Wiring having weather-cracked outer insulation;
- Wiring that is known to have been exposed to electrolyte or on which the insulation appears to be, or is suspected of being, in an initial stage of deterioration due to the effects of electrolyte;
- Check wiring that shows evidence of overheating (even if only to a minor degree) for the cause of the overheating;
- Wiring of which the insulation has become saturated with engine oil, hydraulic fluid, or another lubricant;
- Wiring that bears evidence of having been crushed or severely kinked;
- Shielded wiring of which the metallic shield is frayed and/or corroded. Cleaning agents or preservatives should not be used to minimize the effects of corrosion or deterioration of wire shields;
- Wiring showing evidence of breaks, cracks, dirt, or moisture in the plastic sleeves placed over wire splices or terminal lugs;
- When replacing wiring, identify them properly at both equipment and power source ends.

6.2.3.15 Warning Lights Replacement (Lane A, Lane B, TCU and Alternator)

Required Tools:	As Applicable
Parts and Materials Required:	Lamp 12 V Maximum 120 mA Yellow (applied for Lane A and Lane B) Led 12 V 5 mm Orange (applied for TCU Caution) Led 12 V 5 mm Red (applied for TCU Caution) Led 12 V 5 mm White (applied for Alternator)
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices.

6.2.3.15.1 Lane A and Lane B Lights (for 912 iS Sport)

For replacement of the Lane A and Lane B lights, the electrical scheme should be followed:

- Super Petrel LS equipped with Garmin G3X and Warning Lights Switch Dimmer, should use as reference the scheme **Figure 5-91 Panel Electrical Diagram (Garmin G3X System – 912 iS Sport) – with Warning Lights Dimmer** ~~Figure 5-91 Panel Electrical Diagram (Garmin G3X System – 912 iS Sport) – with Warning Lights Dimmer~~ for replacement the light.
- Super Petrel LS from serial number S0388 are not equipped with Warning Lights Switch Dimmer. Those should use as reference the scheme **Figure 5-94 Panel Electrical Diagram (Garmin G3X System – 912**

~~iS Sport) – New Version without Warning Lights Dimmer~~
~~(Garmin G3X System – 912 iS Sport) – New Version without Warning Lights Dimmer~~ for replacement the light.

NOTE

The installation of low resistance lamps may lead to malfunction of the warning light system. That is the reason for the use of in series resistors on Lane A and Lane B.

6.2.3.15.2 TCU and Alternator Lights (for 914 UL)

For replacement of the TCU and Alternator lights, the electrical scheme should be followed:

- Super Petrel LS equipped with Garmin G3X and Warning Lights Switch Dimmer, should use as reference the scheme **Figure 5-93 Panel Electrical Diagram (Garmin G3X System – 914 UL) – with Warning Lights Dimmer**~~Figure 5-93 Panel Electrical Diagram (Garmin G3X System – 914 UL) – with Warning Lights Dimmer~~ for replacement the light.
- Super Petrel LS from serial number S0388 are not equipped with Warning Lights Switch Dimmer. Those should use as reference the scheme **Figure 5-95 Panel Electrical Diagram (Garmin G3X System – 914 UL) – New Version without Warning Lights Dimmer**~~Figure 5-95 Panel Electrical Diagram (Garmin G3X System – 914 UL) – New Version without Warning Lights Dimmer~~ for replacement the light.

6.2.3.16 Exhaust Tension Springs Replacement

Required Tools:	As Applicable
Parts and Materials Required:	As Applicable
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

Tension springs should be replaced every 100 hours.

CAUTION

Due to its pusher configuration, tension springs installed on Super Petrel LS's muffler system are specific. Market tension springs shall not meet requirements.

6.2.3.16.1 Tension Springs Replacement

Replace the springs as explained below:

1. Use a piece of rope to loop around one end of the spring to allow for the release of tension while removing spring hook.
2. Check the muffler hook for wear. It is possible to find hooks worn out due the friction with the spring. If necessary, repair the hook using TIG welding method and stainless-steel material.
3. Install the new tension spring reversing the process of removal.

4. After installation of each spring, apply high temperature silicone.

CAUTION

The correct use of the high temperature silicone is crucial for the life time of the tension spring and muffler's hook.



Figure 6-33

6.2.3.16.2 Tension Springs Specification

DESCRIPTION	QUANTITY	SCODA PART NUMBER
Tension Springs	12	SE-412.002-2

6.2.3.17 Exhaust Muffler Inspection and Replacement

Required Tools:	As applicable
Parts and Materials Required:	As applicable
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices.

6.2.3.18 Muffler Inspection

- Remove the engine's cowl.
- Loosen the nuts of the exhaust pipes without removing them.
- Remove the tension springs (Use as reference the Tension Spring Replacement Section).

CAUTION

As soon as the tension springs are removed, the muffler can falling.

- Remove the muffler.
- Inspect the muffler for cracks and fatigues inside the component, loosing particles, etc. If any malfunction is suspected perform an inside visual inspection using Borescope.
- If no evidence of malfunction is detected, reinstall the muffler.
- If evidence of malfunction is detected, replace the muffler. Install the new muffler following the process in reverse of the removing process **(See Section 6.2.3.19 Muffler Replacement)**.

6.2.3.19 Muffler Replacement

- Install the new exhaust muffler.

CAUTION

Be aware that locked up stresses cause cracks.

CAUTION

Careful should be taken with the free space between the muffler and hoses.

CAUTION

All ball joints have to be greased regularly with heat resistant lubricant (e.g. ANTI-SEIZE LOCTITE or PERMATEX 1315°C / 2400°F) to avoid gripping and seizing of the joints.

CAUTION

The exhaust system must be reassembled without misalignment or tension on any of the four pipes. Make sure all parts including the tension springs are in position and free to move before tightening the nuts of the exhaust pipes.

- Install the tension springs.
- After setting muffler on the correct position, tighten the nuts of the exhaust pipes.
- Apply high temperature silicone in each tension spring.

NOTE

Exhaust Muffler should be replaced on condition.

6.2.3.20 Muffler Specification

DESCRIPTION	QUANTITY	SCODA PART NUMBER
Exhaust Muffler	1	SE-412.005-3

6.2.3.21 Hoses and Lines

Required Tools:	As applicable
Parts and Materials Required:	As applicable
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices.

Generally hoses are manufactured from synthetic rubber, their limited service life depends on factors such as age, shelf life, temperature (ambient and fluid), and other environmental conditions.

6.2.3.21.1 Hose and Line Inspection

To assure the continued hose and line integrity, it is recommended to accomplish an inspection each 100 hours or annually.

Hoses and lines should be inspected for leakage, cracks, kinks, and security of mounting. Check clamps for tightness and condition. Ensure that hoses and lines do not interfere with adjacent equipment or lines. Make sure that they are not kinked, and not in contact with hot, moving parts or sharp edges.

6.2.3.21.2 Hose and Line Replacement

NOTE

Hoses and lines should be replaced on condition, however, it is recommended to replace them every 10 years.

NOTE

All rubber parts including engine mounts, hoses and lines which are part of the Powerplant must be replaced every 5 years as per Rotax recommendation.

When replacement of a flexible line is necessary, use the same type, size, part number, and length of hose as the line to be replaced. During the reinstallation of the hose assemblies, consider the following precautions:

- Ensure the hose is not twisted. High pressures applied to a twisted hose can cause failure of the hose or loosening of the fitting.
- Provide a large bend radius (as much as allowable), however, never use a bend radius less than the minimum specified by the hose manufacturer.

- Do not attempt to straighten a hose having a bend in it as this could result in damage to the hose. Rubber hoses will take a permanent set during extended service periods. Care should also be taken during removal and reinstallation of such hoses to assure that are not bent excessively and that they are returned to their original position.

NOTE

SCODA AERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

6.2.3.21.3 Hoses and Lines Specification

Hoses and lines should be replaced with lines of the same specification, material, size (inner diameter), pressure rating and length (of the line to be replaced).

AIRCRAFT SYSTEM	DESCRIPTION	ENGINE	TECHNICAL SPECIFICATION				SCODA PART NUMBER
			SAE	DIAMETER Ø	WORK PRESSURE Psi	TEMPERATURE °F (°C)	
Fuel System	Selector Valve Lines	All	30R7	3/8"	50 psi	-40 to 257 (-40 to 125)	MP-900.232
	Shut Off Valve Lines	All					
	Return Line	912 ULS		3/16"			MP-900.397
	Manifold Line	912 ULS / 914 UL		1/4"			MP-900.412
	Fuel Drain Line	All		5/16"			MP-900.431
	Return Line	914 UL 912 iS Sport					
	Flow Line	914 UL 912 iS Sport	30R2	3/8"	300 psi	-40 to 212 (-40 to 100)	2556-6
	Applicable for all lines of the fuel system	All	J30R14 TYPE 2	1/4"	225 Psi	-40 to 275 (-40 to 135)	SAEJ30R14T2 - 1/4
	Applicable for all lines of the fuel system	All	J30R14 TYPE 2	3/8"	225 Psi	-40 to 275 (-40 to 135)	SAEJ30R14T2 - 3/8
	Oil System	Input Line	All	100R6	1/2"	400 psi	-40 to 212 (-40 to 100)
Output Line		All					
Turbocharger Return Line		914 UL	5/16"		MP-900.573		
Coolant System	Expansion Tank Output Line	All	---	Clear hose 1/4"			MP-900.047
	Radiator Output Line	All	---	Molded Hose Gates 20002			PB-413.022
	Water Pump Output Line	All	---	Molded Hose Gates 21878			PB-413.005-1
	Expansion Tank Output Line	All	---	Molded Hose Gates 20259			PB-413.020-1
	Radiator Input Line	All	---	Molded Hose Gates 21872			PB-413.021-1
Bilge Pump	Drain Line	All	---	Clear hose 3/4"			MP-900.035
Cabin Heater	Radiator Input Line	All	30R7	1/4"	50 psi	-40 to 257 (-40 to 125)	MP-900.412
	Radiator Output Line	All					
Ballast Tank	Output Line	All	---	Clear hose 1/2"			MP-900.034

* **SAE J30R14 Type T2** → This hose type is a standard for high-pressure, low-permeation fuel injection hose. Can be used as an option for fuel system application (for all engines).

6.2.4 Repairs of Components

6.2.4.1 Fabric Covering Minor Damages

Required Tools:	As applicable
Parts and Materials Required:	Butyrate Dope
	Thinner
	Super Seam Fabric Cement
	Ceconite Fabric 1.8 OZ
	Cotton Braid 8 mm White
	Nylon Sewing
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

This section is intended for repairing of small holes or even minor damages in the Super Petrel LS fabric covered components.

All materials used to make repairs to the fabric covering must be of a quality at least equal to the original material and the repair methods must be made in a manner that will return the fabric covering to its original condition.

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices, Chapter 2. Fabric Covering.

NOTE

Fabric covering should be replaced on condition.

NOTE

Major Repairs or Alterations on Fabric Covering are not authorized at this time. To obtain engineering approvals for any Major Repairs or Alterations, please contact Scoda Aeronáutica at engineering@scodaero.com.br

6.2.4.2 Repair of Non-Structural Composite Components

Required Tools:	As applicable
Parts and Materials Required:	As applicable
Type of Maintenance:	Line Maintenance
Level of Certification:	LSRM, A&P

Damage to non-structural composite components may be repaired using techniques described in the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices

NOTE

For further information regarding repair of Non-Structural Composite Components please contact Scoda Aeronáutica at engineering@scodaero.com.br

6.2.4.3 Stop Drilling Cracks

Stop Drilling Cracks procedures are not authorized at this time. To obtain engineering approvals for any Stop Drilling Cracks procedures, please contact Scoda Aeronáutica at engineering@scodaero.com.br

6.2.5 Alterations

6.2.5.1 Compliance with Manufacturer's Service Directives

Service directives are issued in the form of (NOA) Notice of Corrective Actions (Safety Alert, Service Bulletin or Notifications). All NOA will be primarily published online and readily accessible on <http://www.scodaeronautica.com.br/avioes/index.php?pagina=blog>. In addition, these will be sent to the email address of the known Super Petrel LS Owner / Operators.

7 Heavy Maintenance, Repairs, and Alterations

7.1 Authorization to Perform Heavy Maintenance, Repairs and Alterations

Any inspection, repair, and alteration outlined in this Section should be performed if the organization or individual holds the following maintenance rating:

- LSA Repairman Maintenance Certificate
- A&P Certificate
- Super Petrel LS Maintenance Training (at least Heavy Maintenance Super Petrel LS Rating)

Typical Tasks Considered as Heavy Maintenance for LSA's Include:

1. Removal and Replacement of Components.
2. Repair of Components or Aircraft Structure.
3. Alterations of Components or Aircraft Structure.

7.2 Heavy Maintenance Tasks

7.2.1 5 Years / 1000 Hours Inspection

Detailed inspection accomplished every five (5) years or 1000 hours of flight. This inspection must be made by the Aircraft Manufacturer or a Mechanic / Repairman, which has received a **Heavy Maintenance Super Petrel Training** to perform this inspection.

The scope of this inspection is specified in the Appendix Section of this Manual (**Heavy Maintenance Inspection Form**).

7.2.1.1 Electric Fuel Pumps Replacement (Main and Auxiliary)

NOTE

Electric Fuel Pumps should be replaced on condition, however, it is recommended to replace it every 1000 hours.

NOTE

Refer to the latest edition of Maintenance Manual (Line Maintenance) for ROTAX Engine Type 912i Series, 912 and 914 Series supplied by the manufacturer.

7.2.1.2 Empennage Assembly Inspection

NOTE

Tail Cone of the aircraft is glued on the fuselage.

NOTE

Cracks on the paste are not considering as structural damages.

1. Remove rudder, elevators and horizontal stabilizers.
2. Inspect the Tube of the Vertical Stabilizer for general condition, cracks, alignment of the internal holes (use the M8 bolts for checking the alignment).
3. Inspect the Vertical Stabilizer and Tail Cone for general condition, bulkhead fixation, rudder supports fixation, bushings and rudder stops.
4. Inspect the articulation bearings located in the elevator control rod, elevator bellcrank and fixation plate of the horizontal stabilizer for general condition, corrosion and fixation.
5. Inspect the Vertical Stabilizer and Tail Cone for general condition, impact damages, corrosion, stains, dents.
6. Inspect the Tubular and "C" spar of the Horizontal Stabilizers for general condition and fixation.
7. Inspect the hinges and bushings of the Horizontal Stabilizers for general condition and fixation.
8. Inspect the Horizontal Stabilizers for general condition, impact damages, corrosion, stains, dents.
9. Inspect the Tubular spar of the Elevators for general condition and fixation.
10. Inspect the hinges and pins of the Elevators for general condition and fixation.
11. Inspect the fixation bolts of the Elevators for fixation and corrosion.
12. Inspect the Elevators for general condition, impact damages, corrosion, stains, dents.
13. Inspect the Electric Trim Tab for general condition, impact damages, corrosion, stains, dents.
14. Inspect the hinges, pins, control rod of the Electric Trim Tab for general condition, corrosion and fixation.
15. Inspect the electrical installation of the Electric Trim Tab for general condition, corrosion of the connectors, routing, and friction with structure.
16. Perform a test of the Electric Trim Tab and check the proper operation.
17. Inspect the Bellcrank and Fixation Bolt of the Rudder for general condition, corrosion and fixation.
18. Inspect the Fabric of the Rudder for general condition.
19. Inspect the Rudder for general condition, impact damages, corrosion, stains, dents.
20. Inspect the elevator and primary pushrod for any wear, bent, scratches, dents, corrosion and general condition. Remove them following the instructions described in the section **7.2.1.3 Elevator and primary pushrod inspection**.
21. Install the horizontal stabilizers, elevators and rudder. Re-Torque the empennage fixation bolts. **(See the Recommended Fastener Torque Values Section of this Manual 5.1.8)**

NOTE

Abnormal looseness in the horizontal stabilizers attachment can be reduced by using oversized M8 fixation bolts part number SE-123.069.

7.2.1.3 Elevator and primary pushrod inspection


ELEVATOR PUSHROD

1. Remove the elevator pushrod. To gain access to the pushrod, the horizontal stabilizers, elevators and rudder need to be removed.
2. Disconnect the elevator pushrod (located inside the empennage) from the primary pushrod (located inside the aircraft floor) by removing the bolt from the rod end.
3. Loose the Allen bolt located in the right side of the empennage. This bolt secures the elevator control horn located inside the empennage.

NOTE

Care should be taken with the bushings of the control horn to not fall inside the empennage.

4. This process need to be completed with two people. While one person is supporting the bellcrank upward inside the empennage, the other person inside the aircraft push the elevator pushrod aft.
5. The control horn is accessed through the small round access hole at the aft end of the empennage. Disconnect the elevator pushrod from the control horn by removing the bolt.
6. Slide the elevator pushrod aft through the hole and remove it from the empennage.



Elevator pushrod


7. Visually inspect the elevator pushrod for any wear, bending, scratches, dents, corrosion and general condition. Replace it if necessary.

PRIMARY PUSHROD

1. Remove the primary pushrod. To gain access to the pushrod, remove the circular inspection window located below the seat cushions.
2. Disconnect the primary pushrod from the joystick control (located inside the aircraft floor) by removing the circular cotter pin and bolt from the rod end.
3. Slide the primary pushrod aft through the hole of the aircraft floor.
4. Visually inspect the primary pushrod for any wear, bending, scratches, dents, corrosion and general condition. Replace it if necessary.

NOTE

Any minor nicks, dents or scratches found (less than .010 inch deep) may be smoothed and primed with zinc chromate primer.



Joystick control - Primary pushrod

REINSTALLATION OF ELEVATOR AND PRIMARY PUSHROD

NOTE

Before reinstallation of the pushrod, remove dirt, grime and old coatings. Apply a corrosion inhibitor (Ardrox AV8 or similar) over the pushrod ends.

- a) Reinstall the elevator and primary pushrod. Execute this process in reverse of the removing process, paying close attention to the following:
- Inspect all bolts, nuts and washer for damage. Replace if necessary.
 - Do not reuse lock-nuts. Use new ones.
 - Tighten the lock-nuts sufficiently and observe the correct placement of washers.
 - Apply torque seal or similar to mark bolts / nuts.
 - Verify for elevator alignment and correct travel.

NOTE

Apply nautical grease or similar in the rod ends.

7.2.2 10 Years Inspection

Detailed inspection accomplished every ten (10) years. This inspection must be made by the Aircraft Manufacturer or a Mechanic / Repairman, which has received a **Heavy Maintenance Super Petrel Training** to perform this inspection.

The scope of this inspection is specified in the Appendix Section of this Manual (**Heavy Maintenance Inspection Form**).

7.2.3 Teleflex Cable Inspection

NOTE

Teleflex Cable should be replaced on condition, however, it is recommended to replace every 10 years.

1. Inspect the Teleflex Cable for looseness. Check looseness between joysticks.
2. Check the smoothness of the control command (pitch and roll).
3. Inspect the rod ends of Teleflex Cable for general condition, corrosion and fixation.
4. Replace the Teleflex Cable if necessary.

7.2.4 Throttle Cable Inspection

NOTE

Throttle Cables should be replaced on condition, however, it is recommended to replace every 10 years.

1. Inspect the throttle cable and its housing for wear, damage, proper security, and general condition.

2. Check the smoothness of the throttle cable.
3. Check the cable for general condition where it passes through the firewall and into engine compartment.
4. Check the cable for any snagging or broken wires using a cloth.
5. Check for corrosion, which may appear as rust on the exterior.
6. Verify that the cable is securely fastened at the carburetor throttle arm and that the throttle clamp is properly secured (**912 ULS and 914 UL**).
7. If significant wear or suspected internal damage is found, the cable need to be removed and an detailed inspection need to be performed.
8. Replace the cable if necessary.

7.2.5 Rudder Cables Inspection

NOTE

Rudder Cables should be replaced on condition, however, it is recommended to replace every 10 years.

1. Inspect the Rudder Cables for general condition, fixation and corrosion.

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B Acceptable Methods, Techniques and Practices - Aircraft Inspection and Repairs - Chapter 7. AIRCRAFT HARDWARE, CONTROL CABLES, AND TURNBUCKLES

2. Inspect the Rudder cables for friction with the aircraft structure.
3. Inspect the guidance of the rudder cable which is located inside the fuselage floor for general condition, fixation and position.
4. Replace the Rudder cables if necessary.

7.2.6 Wings Assembly Inspection

NOTE

For this inspection should be necessary to remove the wings and struts. Please refer to the Section 12.7 Assembly Quick Guide of this manual for guidance.

NOTE

Cracks on the paste are not considering as structural damages.

1. Remove the lower wings. Disconnect vent and fuel lines.
2. Remove the N-Struts.
3. Remove the upper wings. Disconnect the electrical cables and vent lines.

7.2.6.1 Lower Wings Inspection

1. Inspect the wing root for general condition, forward and rear fixation part for corrosion.
2. Inspect the N-Struts support for corrosion.
3. Inspect the fuel output point for general condition and fixation.
4. Inspect the fuel tank for leakage.

7.2.6.2 Upper Wings Inspection

1. Inspect the wing root for general condition and rear part for corrosion.
2. Inspect the main spar for general condition and bushing fixation.
3. Inspect the Main Strut, N-Strut and Jury Strut support for corrosion.

7.2.6.3 Struts Inspection

1. Inspect the Main Struts for general condition, corrosion, dents, stains and impact damages.
2. Inspect the fixation main struts terminals and general condition of the rivets.
3. Inspect the Teflon bushing of the terminal for general condition and fixation.
4. Inspect the N-Strut for general condition, corrosion, dents, stains and impact damages.
5. Inspect the rivets of the N-Strut for general condition.
6. Inspect the Jury Strut for general condition, corrosion, dents, stains and impact damages.

7.2.6.4 Wings Assembly Installation

1. After inspection of the wings assembly, install all the components following the steps described in the **Section 12.7 Assembly Quick Guide of this Manual**.

7.2.7 Fabric Covering Inspection

1. Inspect the fabric covering of the wings and rudder for general condition, loose finishing tape and reinforcing patches, cracking, peeling or deteriorated coatings, fabric tears and impact damages.
2. Perform a mechanical test on the fabric.

NOTE

Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B Acceptable Methods, Techniques and Practices - Aircraft Inspection and Repairs - Chapter 2. FABRIC COVERING.

7.2.8 Composite Structure Inspection

1. Inspect the composite structures for general condition, impact damages, corrosion, stains, and dents.
2. If the inspection made in the step 1 is considered by the mechanic as not satisfactory, it should be performed a special inspection on the composite structures according to the Service Instruction SI_SPLS_003_Composite Structure Inspection. In this case the aircraft manufacturer should be consulted for further assessment.

NOTE

The Service Instruction SI_SPLS_003_Composite Structure Inspection is a Scoda's internal document.

7.2.9 Structural Repairs – Standard and Practices

This section contains information and procedures applicable to all composite repairs. The basic elements of successful repair are; preparation of the laminate and repair material, proper mixing of resin, technique, and complete cure cycle. If any element is not properly executed the repair will be substandard.

7.2.9.1 General Safety Information

In the production of composite parts all used types of resins, hardeners, separators, paints, solvents are hazardous when direct contact with skin and mucous membranes. When perform structural repairs, it is recommended to follow this safety information:

- Use protective clothing, respiratory protective equipment and googles.
- When laminating use undamaged latex gloves, which go for wristbands. Damaged gloves immediately replace with new ones.
- Avoid eating, drinking, smoking and manipulating with fire during the repair process.

7.2.9.2 Level of Certification

The person carrying out the repairs must be trained in composite repair techniques. The instructions specified in this section are not sufficient guidance to allow an otherwise un-trained person to successfully complete the repair.

NOTE

SCODAAERONÁUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

Type of Maintenance:	Heavy Maintenance
Level of Certification:	Task Specific

Task Specific: Items that can be expected to be completed by a responsible individual who holds either a mechanic certificate or a repairman certificate and has received task specific training provided by the manufacturer of the aircraft to perform the task.

7.2.9.3 Repair Classification

The described procedures concern only to relatively minor damage. Large-scale repairs may be performed only by the manufacturer or authorized repair station. Every materials used for repairs must be suitable for the appropriate repair. Before repairs provide needed fabrics reserve in sufficient quantity. Fabrics are sensitive to moisture: therefore, they need to be properly stored in a cool, dry, dark place. For proper storage of resin and fabric, it is necessary to follow the manufacturer's recommendations.

Composite structures cannot be laminated with relative atmospheric humidity above of 60%. It is not recommended to mix epoxy materials with temperature below of 18°C (64.4 °F).

The repairs are divided in classes according to the influence of the aircraft airworthiness:

A. REPAIR CLASS 1

Large damages which require a partial replacement of the airframe or large repairs of main structure can be carried out only by the aircraft manufacturer itself or a repair workshop approved by the manufacturer. The repair procedure is not provided and must be prepared individually after damage examination.

B. REPAIR CLASS 2

Destruction of the whole shell (also the inner laminate is destroyed), however small size only.

C. REPAIR CLASS 3

Simple surface damage (only the outer laminate is damaged)) and small damage of the foam filling.

D. REPAIR CLASS 4

The damages caused by the scores and the scrapes without the outer laminate damage and without the breakage of the element.

7.2.9.4 Materials

A. EPOXY SYSTEM

- Resin
- Hardener

NOTE

The mixing proportion must be observed as exactly as possible. Mixture of a resin and a hardener must be stirred thoroughly until there are no cloudiness and no bubbles in a vessel.

B. FABRICS

- Unidirectional Fiberglass Cloth
- Bidirectional Fiberglass Cloth
- Unidirectional Carbon Fiber Cloth
- Bidirectional Carbon Fiber Cloth
- Carbon / Kevlar Cloth
- Peel Ply (Optional)

C. FILLERS

- Quartz Powder (anti abrasive load)
- Flocked Cotton Fiber
- Microballoon (glass bubbles)

7.2.9.5 Repair Preparation

- Repair extend size should be extend minimum 1 inch (25mm) in all directions around the damaged area. The surface must be prepared beyond this limit to provide proper bonding of the new material.
- Sand off surface coatings including paint and gel-coat to expose the structure. Some residual paint may remain, however the visible surface must be minimum of 80% bare composite.
- 100 Grit sandpaper (or similar) may be used.
- Wipe the surface down using a clean rag moistened with Acetone or similar. This is to remove any residual oils or other surface contaminants. Once this step has been completed care must be taken to not introduce any new contaminants – i.e. gloves must be worn to prevent skin oils reaching the surface.
- Lightly sand the surface to present a fresh face to the repair materials. Blow off dust using clean, dry air.

7.2.9.6 Typical Lay-Up Procedure

The plies are usually placed using the smallest ply first taper layup sequence, therefore the last layer of reinforcing fabric should covers the work area.

General Recommendations:

- Ensure atmospheric conditions are appropriate for the materials being used – many epoxy resin systems have maximum humidity limits and must not be used outside these limits.
- Apply a light coat of Epoxy resin to the surface before applying the first layer of cloth. In some cases, it may also be necessary to mix a structural filler material (such as flocked cotton fiber or microballoon) to level the surface.
- Apply the first layer of cloth and wet with Epoxy resin.

- Apply subsequent layer of cloth and wet with Epoxy resin.

7.2.9.7 Fillers Mixing

NOTE

Resin-hardener should be prepared and mixed first before add any filler type.

For gluing, the resin-hardener mix should be thickened with the filler type which will be worked (add enough so that the resin no longer flows). The surfaces to be glued should be wetted with non-thickened resin & hardener before. To glue foam pieces into place when repairing sandwich sections and to fill in irregularities and gaps etc. around the repair.

Filler Types: Flocked Cotton Fiber, Microballoon and Quartz Powder.

NOTE

Quartz Powder is used in order to conform the original shape of the hull when damaged.

7.2.9.8 Repair Tolerances

Only the damages listed below can be considered to be performed using the procedures specified in the Repair Procedures Section:

- Any damage limited to gelcoat or filler.
- Holes, cracks and tears, bubbles, etc. in the fuselage and wings where the average diameter does not exceed: 50mm (2 inches)
- Holes, cracks and tears, bubbles, etc. in the horizontal stabilizer and control surfaces skins where the average diameter does not exceed: 20mm (0.75 inches)

NOTE

The parts described above should not be damaged in the spar area.

NOTE

Fabric covering are not considered structural. Fabric repairs should be performed according to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices, Chapter 2. Fabric Covering.

NOTE

Damages on metal fittings should not be repaired. Metal fittings should be replaced.

WARNING

REPAIRS ON THE TAIL CONE AND VERTICAL STABILIZER ARE PROHIBITED.

7.2.9.9 Repair Procedures

NOTE

SCODAAERONÁUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

A. REPAIR CLASS 4


Damages caused by scores and the scrapes without the outer laminate damage require finishing and painting works only. In case of first cloth layer damage, it will be necessary to clean the damaged area and sands smoothly with a sandpaper. Follow the typical lay-up procedure as necessary. When the resin is cured, the repair area can be finished and repainted.

B. REPAIR CLASS 3

On the damaged area of the outer shell cut a circular or rounded hole with sufficiently size. Make sure that all delaminated parts of the shell have been removed. If the foam is also damaged, remove it too, eventually to the internal shell layer. Tap the surroundings of the damage area to determine the extent of delamination from the foam. Sand the edge of the cut hole at least 40mm with a sandpaper.

Around the edge of the damaged area where the shell is still firmly bonded, chamfer the shell. For top thin cloth layer the chamfer about 15mm is necessary.

After chamfering the shell, blow out thoroughly the whole repair area including the pores of the foam. Now fill the hole in the foam with microballoon and simultaneously fill the pores of the exposed foam. Then apply layers as necessary with diagonal weave direction (45° cloth) over the damaged area following the typical lay-up procedure. After cured (approximately 24 hours at 20-25 °C) the damaged area should be finished




C. REPAIR CLASS 2

If there is a through hole in the sandwich shell, then remove all delaminated parts and sand the edge of the hole. Enlarge the hole until good bonding to foam is evidenced. Then remove the foam next 20mm around the hole while the inner fabric remains undamaged. On thus exposed inner fabric make chamfer around the


circumference. Outer fabric layer chamfer about 20mm.



If the hole is not greater than 100mm, then glue a thin laminate plate from bottom of the hole. Glue laminate can be supported by means of the nail or wire. Then lay inner layer of patches. Allow the inner layer to harden before doing further work. Prepare the foam plug that will be inserted according to the hole. If necessary, warm the foam with a hair dryer and bend. Scratch the previous layered patches with sandpaper 80 to ensure good glued contact. Glue the foam plug in the hole with thickened resin (microballon) to close the pores. Make sure no air bubbles occur especially in inner corners. If necessary, add weight to ensure better contact. Let the repair cure (approximately 24 hours at 20-25 °C).



Once the epoxy is cured, it can be smoothed, puttied with epoxy thickened with microballoon to close the pores and the outer laminate layers applied.



D. REPAIR CLASS 1

Repairs Class 1 are not authorized at this time. To obtain engineering approvals for any repairs procedure, please contact Scoda Aeronáutica at engineering@scodaero.com.br

7.2.9.10 Fuselage Repair

CAUTION

Instructions specified in this section are not sufficient guidance to allow an otherwise un-trained person to successfully complete the repair. The person carrying out the repairs must be trained in composite repair techniques and have completed of the Scoda Aeronáutica's Task Specific Training.

WARNING

DAMAGES WHICH ARE BEYOND TO THE REPAIR CLASSIFICATION AND TOLERANCES SPECIFIED IN THE SECTION 7.2.8 OF THIS MANUAL, NEED TO OBTAIN APPROVAL FROM THE MANUFACTURER

Required Tools:	As applicable	
Parts and Materials Required:	#ID	Description
	1	Fiberglass 160 g/m ²
	2	Carbon fiber 160 g/m ²
	3	Carbon fiber 45° 200 g/m ²
	4	Carbon fiber Kevlar 160 g/m ²
	5	Peel Ply 85 g/m ²
	Epoxy resin – HTR-212 LAMINATING RESIN (Aircraft Spruce P/N: 01-00430) or similar Flocked Cotton Fiber	
Type of Maintenance:	Heavy Maintenance	
Level of Certification:	Task Specific	

- REPAIR PLAN**

NOTE

Use as reference the Section 7.2.8 Structural Repairs – Standard Practices of this Manual.

NOTE

SCODAAERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

- FUSELAGE INTERNAL PART**

- Prepare the surface to be repaired according to the section 7.2.8.5 of this Manual.
- Using the process Typical Lay-Up Procedure specified in the section 7.2.8.6 of this Manual:
 - Apply 1 layer of cloth #2
 - Apply 1 layer of cloth #3
 - Apply 1 layer of cloth #4
 - Apply 1 layer of cloth #1
 - Apply 1 layer of cloth #5

****LEAVE TO CURE FOR 24 HOURS****

- **FUSELAGE EXTERNAL PART**

- Prepare the surface to be repaired according to the section 7.2.8.5 of this Manual.
- Using the process Typical Lay-Up Procedure specified in the section 7.2.8.6 of this Manual:
 - Apply 2 layers of cloth #1
 - Apply 1 layer of cloth #5

****LEAVE TO CURE FOR 24 HOURS****

- **FINISHING AND PAINTING**

- Refer to the Section 5.11 Painting and Coatings of this Manual.

7.2.9.11 Hull Repair

CAUTION

Instructions specified in this section are not sufficient guidance to allow an otherwise un-trained person to successfully complete the repair. The person carrying out the repairs must be trained in composite repair techniques and have completed of the Scoda Aeronáutica's Task Specific Training.

WARNING

DAMAGES WHICH ARE BEYOND TO THE REPAIR CLASSIFICATION AND TOLERANCES SPECIFIED IN THE SECTION 7.2.8 OF THIS MANUAL, NEED TO OBTAIN APPROVAL FROM THE MANUFACTURER

Required Tools:	As applicable	
Parts and Materials Required:	#ID	Description
	1	Carbon fiber Kevlar 210 g/m ²
	2	Fiberglass 160 g/m ²
	3	Peel Ply 85 g/m ²
	Epoxy resin – HTR-212 LAMINATING RESIN (Aircraft Spruce P/N: 01-00430) or similar	
	Quartz Powder (anti abrasive resin load)	
	Flocked Cotton Fiber or Microballoon (glass bubbles)	
Type of Maintenance:	Heavy Maintenance	
Level of Certification:	Task Specific	

- **REPAIR PLAN**

NOTE

Use as reference the Section 7.2.8 Structural Repairs – Standard Practices of this Manual.

NOTE

SCODA AERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

- Prepare the surface to be repaired according to the section 7.2.8.5 of this Manual.
- Apply a first layer Quartz Powder mixed with resin over the area to be repaired.
- Apply a second layer of Cotton Powder or Microballoon mixed with resin.
- After cured, sand the surface in order to conform to the original shape of the hull.
- Using the process Typical Lay-Up Procedure specified in the section 7.2.8.6 of this Manual:
 - 4 layers of cloth #1
 - 1 layer of cloth #2
 - 1 layer of cloth #3

****LEAVE TO CURE FOR 24 HOURS****

- **FINISHING AND PAINTING**

- Refer to the Section 5.11 Painting and Coatings of this Manual.

7.2.9.12 Leading Edge Repair

CAUTION

Instructions specified in this section are not sufficient guidance to allow an otherwise un-trained person to successfully complete the repair. The person carrying out the repairs must be trained in composite repair techniques and have completed of the Scoda Aeronáutica's Task Specific Training.

WARNING

DAMAGES WHICH ARE BEYOND TO THE REPAIR CLASSIFICATION AND TOLERANCES SPECIFIED IN THE SECTION 7.2.8 OF THIS MANUAL, NEED TO OBTAIN APPROVAL FROM THE MANUFACTURER

Required Tools:	As applicable	
Parts and Materials Required:	#ID	Description
	1	Carbon fiber 200 g/m ²
	2	Fiberglass 100 g/m ²
	3	Peel Ply 85 g/m ²
	Epoxy resin – HTR-212 LAMINATING RESIN (Aircraft Spruce P/N: 01-00430) or similar	
	Structural Adhesive – Hysol or similar	
Type of Maintenance:	Heavy Maintenance	
Level of Certification:	Task Specific	

- **REPAIR PLAN**

NOTE

Use as reference the Section 7.2.8 Structural Repairs – Standard Practices of this Manual.

NOTE

SCODA AERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

- **LEADING EDGE (EXTERNAL PART)**


- Prepare the surface to be repaired according to the section 7.2.8.5 of this Manual.

- Using the process Typical Lay-Up Procedure specified in the section 7.2.8.6 of this Manual:
 - Apply 3 layer of cloth #1
 - Apply 1 layer of cloth #2
 - Apply 1 layer of cloth #3
- Cover with masking tape the leading edge in order to press the repair onto the structure.

****LEAVE TO CURE FOR 24 HOURS****

- **LEADING EDGE (INTERNAL PART)**

- The access point should be through the tank nozzle.
- With a borescope, locate the impact point and inspect for cracks and general condition.
- Wipe the surface down using a clean rag moistened with Cleaner-Degreaser or similar. This is to remove any residual oils or other surface contaminants. Once this step has been completed care must be taken to not introduce any new contaminants.
- Lightly sand with 600 grit paper (or similar) in order to remove the brightness of the surface.
- Place the wing vertically as shown below.



- Apply structural adhesive over the affected area.

****LEAVE TO CURE FOR 24 HOURS****

- **LEAKING TEST**

- Perform a leaking test of the fuel tank.
- Once leaking is not observed, make sure the fuel tank is completely cleaned and free of contaminants.

- **FINISHING AND PAINTING**

- Refer to the Section 5.11 Painting and Coatings of this Manual.

7.2.9.13 Trailing Edge Repair

CAUTION

Instructions specified in this section are not sufficient guidance to allow an otherwise un-trained person to successfully complete the repair. The person carrying out the repairs must be trained in composite repair techniques and have completed of the Scoda Aeronáutica's Task Specific Training.

WARNING

DAMAGES WHICH ARE BEYOND TO THE REPAIR CLASSIFICATION AND TOLERANCES SPECIFIED IN THE SECTION 7.2.8 OF THIS MANUAL, NEED TO OBTAIN APPROVAL FROM THE MANUFACTURER

Required Tools:	As applicable	
Parts and Materials Required:	#ID	Description
	1	Bidirectional Carbon fiber 200 g/m ²
	2	Balsa or similar
	3	Peel Ply 85 g/m ²
	4	Flocked Cotton Fiber
	Epoxy resin – HTR-212 LAMINATING RESIN (Aircraft Spruce P/N: 01-00430) or similar	
Type of Maintenance:	Heavy Maintenance	
Level of Certification:	Task Specific	

- **REPAIR PLAN**

NOTE

Use as reference the Section 7.2.8 Structural Repairs – Standard Practices of this Manual.

NOTE

These repairs need to be performed without the wing fabric covering. Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices, Chapter 2. Fabric Covering.


NOTE

SCODAAERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

- Make a beveled cut in the trailing edge internal part. This cut should be extend 3 inches from the damaged point (crack).



Trailind Edge



- Place a new piece of balsa cut to the same shape (beveled cut). Fill with flocked cotton fiber mixed with epoxy resin and leave to cure.
- Using the process Typical Lay-Up Procedure specified in the section 7.2.8.6 of this Manual:
 - Apply 2 layer of cloth #1
 - Apply 1 layer of cloth #3

NOTE

The cloths should be applied over the carbon surface of the trailing edge for reinforcement.

****LEAVE TO CURE FOR 24 HOURS****

7.2.9.14 Wing Ribs Repair

CAUTION

Instructions specified in this section are not sufficient guidance to allow an otherwise un-trained person to successfully complete the repair. The person carrying out the repairs must be trained in composite repair techniques and have completed of the Scoda Aeronáutica's Task Specific Training.

WARNING

DAMAGES WHICH ARE BEYOND TO THE REPAIR CLASSIFICATION AND TOLERANCES SPECIFIED IN THE SECTION 7.2.8 OF THIS MANUAL, NEED TO OBTAIN APPROVAL FROM THE MANUFACTURER

Required Tools:	As applicable	
Parts and Materials Required:	#ID	Description
	1	Unidirectional fiberglass 220 g/m ²
	2	Microballoon
	Epoxy resin – HTR-212 LAMINATING RESIN (Aircraft Spruce P/N: 01-00430) or similar	
Type of Maintenance:	Heavy Maintenance	
Level of Certification:	Task Specific	

- **REPAIR PLAN**

NOTE

Use as reference the Section 7.2.8 Structural Repairs – Standard Practices of this Manual.

NOTE

These repairs need to be performed without the wing fabric covering. Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices, Chapter 2. Fabric Covering.


NOTE

SCODAAERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.


➤ **Broken PVC Rib Repair**



- Apply microballoon mixed with epoxy resin for gluing the rib (PVC Foam).



- Prepare the surface of the cap strip extending approximately 3 inches for each side from the broken point for laminating.



- Using the process Typical Lay-Up Procedure specified in the section 7.2.8.6 of this Manual:
 - Apply 3 layer of cloth #1 over intrados
 - Apply 3 layer of cloth #1 over extrados

NOTE

The layers of clothes over the cap strip need to be sized in a “tape” format in order to follow the shape of the cap strip.

****LEAVE TO CURE FOR 24 HOURS****

➤ Cracked PVC Rib Repair

- Remove some material from PVC Rib around the damage area (crack).
- Fill with Microballoon mixed with resin over the area which is being repaired.



****LEAVE TO CURE FOR 24 HOURS****

7.2.9.15 Rib Cap Strip Repair

CAUTION

Instructions specified in this section are not sufficient guidance to allow an otherwise un-trained person to successfully complete the repair. The person carrying out the repairs must be trained in composite repair techniques and have completed of the Scoda Aeronáutica's Task Specific Training.

Required Tools:	As applicable
Parts and Materials Required:	Epoxy resin – HTR-212 LAMINATING RESIN (Aircraft Spruce P/N: 01-00430) or similar
	Structural Adhesive – Hysol or similar
	Syringe
	Weight
Type of Maintenance:	Heavy Maintenance
Level of Certification:	Task Specific

- **REPAIR PLAN**

Rib cap strip damage happens when the skin (composite cap strip) pulls off the rib. For that a repair plan should be followed as described below:


NOTE

These repairs need to be performed without the wing fabric covering. Please refer to the latest edition of the FAA ADVISORY CIRCULAR AC 43.13-1B – Acceptable Methods, Techniques and Practices, Chapter 2. Fabric Covering.


NOTE

SCODAAERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

- Locate where the cap strip pulled off from the rib.
- Remove the fabric reinforcement tapes.
- Displace the cord.
- Prepare the surface of the cap strip extending approximately (1 3/16 inches) ~3 cm for each side from the damage point.



- Drill 1/8 inches holes (~3 mm) over the cap strip every 1/2 inches (~1.3 cm).



- Place masking tape on both side of the repair area in order to avoid dirty the fabric covering with structural adhesive.
- Using a syringe inject a small quantity of structural adhesive in each hole.
- Remove the excess of structural adhesive.
- Place a weight over all repaired area of the cap strip and leave structural adhesive to cure.

****LEAVE TO CURE FOR 24 HOURS****

- Put the cord back to the position aligned over the rib.
- Reinstall the fabric reinforcement tapes.

➤ FINISHING AND PAINTING

- Refer to the Section 5.11 Painting and Coatings of this Manual.

7.2.9.16 Cabin Floor Repair

CAUTION

Instructions specified in this section are not sufficient guidance to allow an otherwise un-trained person to successfully complete the repair. The person carrying out the repairs must be trained in composite repair techniques and have completed of the Scoda Aeronautica's Task Specific Training.

WARNING

DAMAGES WHICH ARE BEYOND TO THE REPAIR CLASSIFICATION AND TOLERANCES SPECIFIED IN THE SECTION 7.2.8 OF THIS MANUAL, NEED TO OBTAIN APPROVAL FROM THE MANUFACTURER

Required Tools:	As applicable	
Parts and Materials Required:	#ID	Description
	1	Fiberglass Cloth 200 g/m ²
	2	Peel Ply 85 g/m ²
	Epoxy resin – HTR-212 LAMINATING RESIN (Aircraft Spruce P/N: 01-00430) or similar	
	Structural Adhesive – Hysol or similar	
Type of Maintenance:	Heavy Maintenance	
Level of Certification:	Task Specific	

- **REPAIR PLAN**



Figure 7-1 (Example of a crack in the cabin floor)

NOTE

Use as reference the Section 7.2.8 Structural Repairs – Standard Practices of this Manual.

NOTE

SCODA AERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

- Remove the seat cushion.
- Remove the inspection window (circular cover).
- Prepare the cabin floor underneath and top.
- Apply 5 layers of Fiberglass cloth 200 g/m² underneath the cabin floor (Use the typical lay-up procedure specified in this manual).
- Apply 5 layers of Fiberglass cloth 200 g/m² on the top of the cabin floor (Use the typical lay-up procedure specified in this manual).
- Apply Peel Ply.

****LEAVE TO CURE FOR 24 HOURS****

- **FINISHING AND PAINTING**

- Refer to the Section 5.11 Painting and Coatings of this Manual.

7.2.9.17 Seat Fitting Holes Repair

CAUTION

Instructions specified in this section are not sufficient guidance to allow an otherwise un-trained person to successfully complete the repair. The person carrying out the repairs must be trained in composite repair techniques and have completed of the Scoda Aeronáutica's Task Specific Training.

WARNING

DAMAGES WHICH ARE BEYOND TO THE REPAIR CLASSIFICATION AND TOLERANCES SPECIFIED IN THE SECTION 7.2.8 OF THIS MANUAL, NEED TO OBTAIN APPROVAL FROM THE MANUFACTURER

Required Tools:	As applicable	
Parts and Materials Required:	#ID	Description
	1	SE-113.106 – Fitting Holes Plate
	2	Stainless Steel Pop Rivet 1/8" x 3/8"
	3	Stainless Steel Pop Rivet 1/8" x 1/2"
	Structural Adhesive – Hysol or similar	
	Cleaner-Degreaser – Loctite SF 7063 or similar	
Type of Maintenance:	Heavy Maintenance	
Level of Certification:	Task Specific	

- **REPAIR PLAN**

NOTE

Use as reference the Section 7.2.8 Structural Repairs – Standard Practices of this Manual.

NOTE

SCODAAERONAUTICA cannot accept any responsibility for the quality of work performed. Please refer to the last revision of the Advisory Circular 43.13 – 1B Acceptable Methods, Techniques, and Practices Aircraft Inspection and Repair.

- Remove the seat.
- Remove the seat cushion.
- Make a mark and drill the rivet's holes

CAUTION

Be careful when drill the rivet's hole. Set the drill with 0.5 inch of length in order to avoid contact with the landing gear cable and control rods.

- Duck tape the area around the mark.



- Prepare the surface, sanding and cleaning.
- Use a cleaner-degreaser for preparing the fitting holes plate.
- Apply structural adhesive in the around the fitting holes over the fiber surface.
- Apply structural adhesive in the fitting holes plate.
- Install the fitting holes plate over the fiber surface.
- Rivet using three (3) Pop Rivet 1/8" x 3/8" in the lateral part of the plate and four (4) Pop Rivet 1/8" x 1/2" on the top of the plate (see picture below).



- Remove / clean the excess of the structural adhesive.

NOTE

The fitting holes need to be completely free of excess of structural adhesive for fitting the seat pins.

****LEAVE TO CURE FOR 24 HOURS****



- **FINISHING AND PAINTING**

- Refer to the Section 5.11 Painting and Coatings of this Manual.

7.2.9.18 Rudder Actuator Stop Repair

CAUTION

Instructions specified in this section are not sufficient guidance to allow an otherwise un-trained person to successfully complete the repair. The person carrying out the repairs must be trained in composite repair techniques and have completed of the Scoda Aeronáutica's Task Specific Training.

WARNING

DAMAGES WHICH ARE BEYOND TO THE REPAIR CLASSIFICATION AND TOLERANCES SPECIFIED IN THE SECTION 7.2.8 OF THIS MANUAL, NEED TO OBTAIN APPROVAL FROM THE MANUFACTURER

Required Tools:	As applicable	
Parts and Materials Required:	#ID	Description
	1	SE-123.070 – Rudder Actuator Stop
	2	Stainless Steel Pop Rivet 1/8" x 3/8"
	3	Stainless Steel Pop Rivet 1/8" x 1/2"
	Structural Adhesive – Hysol or similar	
	Cleaner-Degreaser – Loctite SF 7063 or similar	
Type of Maintenance:	Heavy Maintenance	
Level of Certification:	Task Specific	

- **REPAIR PLAN**

- The actuator stops need to be installed in the outside part of the tail cone.

- Check the rudder angles. For this the gap between the rudder and elevator (elevator should be positioned in leveled flight position) should be 25.4 mm (+/- 3.175 mm) – 1 inch (+/- 1/8"). Make a mark where will be installed the actuator stops.



- Make a mark and drill the rivet's holes
- Duck tape the area around the mark.
- Prepare the surface, sanding and cleaning.
- Use a cleaner-degreaser for preparing the fitting holes plate.
- Apply structural adhesive in the fiber surface and actuator stops.
- Install the actuator stops.
- Rivet the plates using three (3) Pop Rivet 1/8" x 3/8" or 1/8" x 1/2 if necessary". Install washers in the inside part of the rivet.
- Remove / clean the excess of the structural adhesive.

****LEAVE TO CURE FOR 24 HOURS****



- Check the gap between the rudder and elevators. If necessary make a fine adjustment.

- **FINISHING AND PAINTING**
 - Refer to the Section 5.11 Painting and Coatings of this Manual.

8 Overhaul

8.1 Authorization to Perform Overhaul

No Overhauls as outlined in ASTM F2483, FAR 23, or in this manual are authorized at this time.

NOTE

For Engine Overhaul, refer to the engine manual for a list of Rotax approved service centers.

9 Major Repairs and Alterations

Repairs or alterations that are not described in the section 7 of this Manual are not authorized at this time. To obtain engineering approvals, please contact Scoda Aeronáutica at engineering@scodaero.com.br

- 9.1** All major repairs or alterations made to aircraft subsequent to its initial design and production acceptance testing to applicable ASTM standards and sale to a consumer are evaluated relative to the requirements of the applicable ASTM design and production specification(s).
- 9.2** Scoda Aeronáutica Ltda will provide a written affidavit that the aircraft being altered will still meet the requirements of the applicable ASTM design and performance specification subsequent to the alteration through a Letter of Authorization (LOA).
- 9.3** Scoda Aeronáutica Ltda will provide written instructions and diagrams on how, who, and the level of certification needed to perform the alteration or repair through a Letter of Authorization (LOA).
- 9.4** Scoda Aeronáutica Ltda will provide information to the owner of the aircraft for the documentation of the alteration in the aircraft's records.

MAJOR REPAIRS AND ALTERATIONS PROCEDURE

- 1.** Owner/Operator will request a LOA using the FORM_SPLS_005_LSA Major Repair and Alterations MRA Form, which is located on the <http://www.scodaeronautica.com.br/avioes/index.php?pagina=blog>. This form should be sent to engineering@scodaero.com.br.
- 2.** Scoda Aeronáutica Ltda will analyze the MRA Form and issue a LOA with approval or not.
- 3.** If LOA is approved, Owner/Operator should demonstrate that the alteration or repair described in the LOA was performed correctly and the aircraft is in a condition for safe operation.

10 Task-Specific Training

10.1 Scoda Aeronáutica Ltda may require task-specific training in order to accomplish a task in either the maintenance manual or in an authorization for a major repair, maintenance, or alteration. The FAA does not give approval to these task-specific programs for SLSA. Scoda Aeronáutica Ltda may specify any task-specific training it determines is appropriate to accomplish the task.

11 Safety Directives

- 11.1** A Super Petrel LS may have a safety directive issued against an aircraft or component part. Scoda Aeronáutica Ltda issues the directive as outlined in the last revision of the ASTM F2295 – Continued Airworthiness in for of (NOA) Notice of Corrective Actions (Safety Alerts, Service Bulletins or Notifications).
- 11.2** Scoda Aeronáutica Ltda is responsible for providing the applicable instructions to comply with any NOA, which will include:
- 11.2.1** A list of the tools needed to accomplish the task.
 - 11.2.2** A list of the parts needed to perform the task.
 - 11.2.3** Type of maintenance (Line or Heavy Maintenance).
 - 11.2.4** The level of certification needed to accomplish the task (A&P, LSRM).
 - 11.2.5** Detailed instructions and diagrams as needed to perform the task.
 - 11.2.6** Method to test / inspect to verify the task was accomplished properly.
- 11.3** Notice of Corrective Actions are considered mandatory task in order to maintain a condition of safe operation and compliance with the applicable ASTM design specification.

12 Appendixes

12.1 Improvement or Corrections

In order to report any improvements or corrections in this manual, please advise to the following email address:
engineering@scodaero.com.br

12.2 Aircraft Registration Form

FORM_SPLS_001	AIRCRAFT REGISTRATION FORM		
REGISTRATION TYPE			
☐	New Aircraft (Original Owner)	☐	Change of Ownership
AIRCRAFT DETAILS			
Serial Number:	Model:	Registration Number:	
Name of Dealer or Previous Owner:			
Date of Delivery or Change of Ownership:			
The Aircraft is Used For:	☐	Training: Flight school or similar activity.	
	☐	Personal Use: Operated for recreational purposes.	
	☐	Special Use: Rentals, Aerial Works, etc.	
OWNER DETAILS			
Name:			
Full Address:			
Country:			
Contact Phone Number:			
Email Address:			

12.3 Continued Operational Safety Reporting Form

FORM_SPLS_002	CONTINUED OPERATIONAL SAFETY REPORTING FORM	
---------------	--	---

AIRCRAFT DETAILS		
Serial Number:	Model:	Registration Number:
Total Flight Time (<i>Hobbs</i>):		
OWNER DETAILS		
Name:		
Country:		
Email Address:		
DESCRIPTION OF FLIGHT SAFETY ISSUE OR SERVICE DIFFICULTY		
<i>* Attach any pictures or file that might complete or support your communication</i>		

FOR SCODA AERONÁUTICA LTDA USE ONLY	
Log Number:	Received Date:

12.4 Warranty Claim Form

FORM_SPLS_003	WARRANTY CLAIM FORM	
---------------	----------------------------	---

AIRCRAFT DETAILS

Serial Number:	Model:	Registration Number:
Total Flight Time (Hobbs):		

OWNER DETAILS

Name:	
Country:	
Email Address:	

THE AIRCRAFT, PARTS OR COMPONENTS WERE INSPECTED BY OR ARE BEING INSPECTED BY A NON-AUTHORIZED MANUFACTURE'S MAINTENANCE CENTER?	☐ YES ☐ NO
---	--

EVENT REPORT

Date:	Time:	The issue occurred: ☐ ON LAND ☐ ON WATER ☐ IN FLIGHT
-------	-------	--

DESCRIPTION OF FLIGHT SAFETY ISSUE OR SERVICE DIFFICULTY

** Attach any pictures or file that might complete or support your communication*

FOR SCODA AERONÁUTICA LTDA USE ONLY
--

Log Number:	Received Date:
-------------	----------------

12.5 Line Maintenance Inspection Form

100 HOURS / ANNUAL CONDITION INSPECTION CHECKLIST	
Owner Name:	Inspector Name (LSRM or A&P):
Aircraft Make / Model: Scoda Aeronáutica Ltda / Super Petrel LS	S/N:
Engine Make / Model: Rotax Aircraft Engines /	S/N:
Hours Flown (Hobbs):	Date:

Before Starting the inspection:	• Remove or open all cowlings, inspection windows, access doors and baggage compartment.
	• Clean the aircraft, if necessary.
	• Sign all the applicable items and N/A for non-applicable items.

NOTE

Lubrication of components and parts, please refer to the Section 6.2.2.4 Lubrication Table (Line Maintenance) of this Manual.

Item	Description	Inspection		Chapter Ref.	Initials
		Special	Annual		
1. ENGINE					
NOTE					
Refer to the Recommended Fastener Torque Values Section of this Manual					
1.1	Re-Torque and check the condition of the firewall bolts Applied for 912 iS Sport, 912 ULS (See the Recommended Fastener Torque Values Section of this Manual 5.1.8)	First 25 h	✓	5.4.2.2 Sec. 1	
1.2	Re-Torque and check the condition of the firewall bolts Applied for 914 UL (See the Recommended Fastener Torque Values Section of this Manual 5.1.8)	First 25 h	✓	5.4.2.2 Sec. 2	
1.3	Re-Torque and check the condition of the engine suspension frame bolts Applied for 912 ULS, 914UL and 912 iS Sport (See the Recommended Fastener Torque Values Section of this Manual 5.1.8)	First 25 h	✓	5.4.2.2 Sec. 3	
1.4	Inspect visually the engine cowlings for cracks, burns, damaged protections, general condition of fasteners, asbestos, support of oil and water cooler, rubbers in general, engine mounts and attachment of protection grille.		✓	5.4.2.1	
1.5	Check visually the inline fuel filter for general condition (leakage and attachment).		✓	5.5.2	
1.6	Inspect and clean the fuel filter. Replace it if necessary	Every 100 h		5.5.2	
1.7	Replace the fine fuel filter Rotax according instructions described in the last revision of the Rotax Service Instruction SI-912i-009.	As per ROTAX SI-912i-009		5.4.3.3	
1.8	Check visually the fuel system for leakage.	First 25 h	✓	5.5.2	
1.9	Check visually the shut off valve for correct operation.	First 25 h	✓	5.5.2	
1.10	Check visually the selector valve for correct operation.	First 25 h	✓	5.5.2	
1.11	Re-tighten hoses clamps of the cooling system.	First 25 h	✓	5.4.2.3	
1.12	Check the ventilation electrical system (fans, supports, sensor and relay) for general condition and attachment. Only 912 iS Sport	First 25 h	✓	5.4.2.3.1	
1.13	Make an operational check of the ventilation electrical system. Only 912 iS Sport	First 25 h	✓	5.4.2.3.1	

Item	Description	Inspection		Chapter Ref.	Initials
		Special	Annual		
1.14	Inspect the electric fuel pumps for corrosion, leakage, general condition, lines and connections.	First 25 h	✓	5.5.2.1	
1.15	Make an operational check of the electric fuel pumps.	First 25 h	✓	5.5.2.1	
1.16	Check visually the carburetor heater for correct operation (if installed). Only 912 ULS	First 25 h	✓	5.4.2.5	
1.17	Check visually the muffler and pipes for general condition and attachment.	First 25 h	✓	6.2.3.18 Sec. 3	
1.18	Remove the muffler for detailing inspection. Only 912 iS Sport, 912 ULS.	Every 200 h		6.2.3.18 Sec. 3	
1.19	Replace the tension springs of exhaust. Only 912 iS Sport, 912 ULS.	Every 100 h		6.2.3.15 Sec. 4	
1.20	Check the throttle for correct operation and free movement.	First 25 h	✓	5.4.2.6 Sec. 1	
1.21	Check the choke for correct operation and lock. (912 ULS, 914 UL).		✓	5.4.2.6 Sec. 2	
2. PROPELLER					
NOTE <i>Inspection, maintenance, repair, removal or installation of FLASH -2, refer to the latest revision of the Instruction Manual for FLASH Propeller Range from DUC.</i>					
2.1	Remove the spinner and check for cracks and general condition.	First 25 h	✓	5.6.2 Sec. 3	
2.2	Check manually the fixation of the propeller.	First 25 h	✓	5.6.2 Sec. 2	
2.3	Check visually the entire propeller without disassembly (blade root, Inconel leading edge, blade surface, hub, etc.) for general condition.	First 25 h	✓	5.6.2	
2.4	Remove the bolts safety wire of the propeller.		✓	5.6.2 Sec. 1	
2.5	Check the proper tightening of the bolts.		✓	5.6.2 Sec. 1	
2.6	Install the safety wire in the propeller bolts.		✓	5.6.2 Sec. 1	
2.7	Reinstall the spinner and check the fixation.	First 25 h	✓	5.6.2 Sec. 3	
2.8	Perform a propeller dynamic balancing: Propeller Balancing Time: _____ IPS (INITIAL) _____ IPS (FINAL) _____ Weight 1 _____ Position _____ Weight 2 _____ Position _____	Every 100 h		5.6.5	
3. LANDING GEAR SYSTEM – Before starting the inspection lift the aircraft, if necessary					
3.1	Check visually the nose gear (bolts, rubbers, tension cables, nose gear lock, looseness, bending, cracks and wear). Check if the nose gear spins freely on vertical shaft. Check the correct operation of nose gear doors.	First 25 h	✓	5.3.4.1.1 Sec. 1	
3.2	Replace the bearings of the nose and main landing gear.		✓	6.2.3.9	
3.3	Check visually the condition of nose gear doors for attachment, hinges and general condition.	First 25 h	✓	5.3.4.1.1 Sec. 2	
3.4	Check the nose gear springs for attachment, wear and looseness.	First 25 h	✓	5.3.4.1.1 Sec. 2	
3.5	Check the plates which cover nose gear fork for general condition, cracks, wear and looseness. Replace them if necessary.	First 25 h	✓	5.3.4.1.1 Sec. 1	
3.6	Check visually the main landing gear for cracks, excessive looseness, attachment, loose or damaged bolts, and general condition of wheel.	First 25 h	✓	5.3.4.1.2 Sec. 1	

Item	Description	Inspection		Chapter Ref.	Initials
		Special	Annual		
3.7	Check if the retraction system cable is tensioned.	First 25 h	✓	5.3.4.1.3	
3.8	Check the safety wires of the turnbuckles for general condition.	First 25 h	✓	5.3.4.1.3	
3.9	Inspect the landing gear retraction system (retract and lower), check it for correct operation, looseness, cracks, bend and maximum strength for retracting.	First 25 h	✓	5.3.4.1.3	
3.10	Check the gas spring for wear, looseness, leakage, corrosion and correct operation.		✓	5.3.4.1.5	
3.11	Perform a test on the gas spring. Replace if necessary.		✓	6.2.3.13	
3.12	Check the lock resistance (rubber band) of landing gear lever.	First 25 h	✓	5.3.4.1.3	
3.13	Check the position sensor of the landing gear for correct operation.	First 25 h	✓	5.3.4.1.3	
3.14	Check visually the tires for condition, cuts, excessive wear and/or uneven and slippage in the wheel – replace if necessary. Check the pressure – calibrate with recommended pressure (Check the Tire Inflation Pressure Section of the POH).	First 25 h	✓	5.3.4.1.4 Sec. 1, 2	
3.15	Check the hoses of the brake system for leakage and general condition.	First 25 h	✓	5.3.4.1.4 Sec. 3	
3.16	Check the condition of the Brakes hydraulic fluid – replace every 5 years / 1000 hours.		✓	5.3.4.1.4 Sec. 4 6.2.3.6	
3.17	Check visually the condition of the brake pads. Replace them if necessary.		✓	5.3.4.1.4 Sec. 5	
3.18	Check visually the discs for cracks and permanent deformations. Replace if necessary. Check the bearings condition, free rotation of wheel and play.		✓	5.3.4.1.4 Sec. 1 6.2.3.8	
3.19	Check visually the shock absorber for corrosion, wear, leakage and attachment. Clean the shock absorber cylinder.	First 25 h	✓	5.3.4.1.5	
3.20	Check visually the general condition of the rubber foam of the housing of main landing gear leg.	First 25 h	✓	5.3.4.1.2	
4. UPPER WINGS					
4.1	Re-Torque the front and rear fixation bolts of the upper wings. (See the Recommended Fastener Torque Values Section of this Manual 5.1.8)	First 25 h	✓	5.3.2.2.1 Sec. 1	
4.2	Check visually the wing surface for damages, denting and general condition of coating (fabric).	First 25 h	✓	5.3.2.2.2 Sec. 2	
4.3	Check visually the general condition and attachment of the main struts, inner struts (N-Struts) and jury strut.	First 25 h	✓	5.3.2.2.3 Sec. 1, 2	
4.4	Check the attachment and general condition of the pitot tube.	First 25 h	✓	5.3.2.2.3 Sec. 3	
4.5	Check visually the aileron surface for damages and paint damages.	First 25 h	✓	5.3.5.1.1 Sec. 1	
4.6	Check visually the drain holes of aileron for obstruction.	First 25 h	✓	5.3.5.1.1 Sec. 2	
4.7	Check the aileron for freedom of operation, hinges and looseness.	First 25 h	✓	5.3.5.1.1 Sec. 3	
4.8	Check visually the hinges, pins, rod of aileron electric trim tab for general condition. (From aircraft S/N: S0380)	First 25 h	✓	5.3.5.1.1 Sec. 3	
4.9	Check visually the aileron electric trim tab for attachment and correct operation. (From aircraft S/N: S0380)	First 25 h	✓	5.3.5.1.1 Sec. 3	
4.10	Check visually the bell-crank of the aileron.	First 25 h	✓	5.3.5.1.1 Sec. 3	
4.11	Check the Teleflex cable for wear, looseness and correct operation.	First 25 h	✓	5.3.5.1.1 Sec. 3	

Item	Description	Inspection		Chapter Ref.	Initials
		Special	Annual		
4.12	Check visually the winglets for attachment, cracks and dent.	First 25 h	✓	5.3.2.2.1 Sec. 4	
4.13	Check the looseness of wings suspension. Move the wings tips upward-downward, frontward-rearward.		✓	5.3.2.2.1 Sec. 1	
5. LOWER WINGS					
5.1	Re-Torque the rear fixation bolts of the lower wings. <i>(See the Recommended Fastener Torque Values Section of this Manual 5.1.8)</i>	First 25 h	✓	5.3.2.2.2 Sec. 1	
5.2	Check visually the wing surface for damages, denting and general condition of coating (fabric). Check the general condition of registration number (detachment).	First 25 h	✓	5.3.2.2.2 Sec. 2	
5.3	Check visually the fuel tanks (lower wings leading edge) for cracks, leakage and general condition.	First 25 h	✓	5.3.2.2.2 Sec. 3	
5.4	Check the general condition and correct operation of the fuel tanks filler caps.	First 25 h	✓	5.3.2.2.2 Sec. 3	
5.5	Check the header tank for leakage, connection and general condition.	First 25 h	✓	5.3.2.2.2 Sec. 3	
5.6	Check visually the output of the fuel tanks vent for obstruction.	First 25 h	✓	5.3.2.2.2 Sec. 4	
5.7	Perform an air test of the fuel vents in order to check for obstruction in the lines.		✓	5.3.2.2.2 Sec. 4	
5.8	Check visually the condition of the floaters and winglets (attachment, cracks and dents).	First 25 h	✓	5.3.2.2.2 Sec. 6	
5.9	Check visually the landing gear legs housing for general condition.	First 25 h	✓	5.3.2.2.2 Sec. 7	
6. FUSELAGE					
6.1	Check visually the fuselage surface for damages, cracks, denting and general condition.	First 25 h	✓	5.3.1.2.1 5.3.1.2.2 5.3.1.2.3	
6.2	Inspect visually for impacts or damage of the hull internal and external part, canopy structure, windshield and doors.		✓	5.3.1.2.4	
6.3	Check visually the canopy condition for cracks, scratch and other damages on the door hinges. Check the snap vents for operation condition.	First 25 h	✓	5.3.1.2.5	
6.4	Check the door locking system for operation condition.	First 25 h	✓	5.3.1.2.5 Sec. 4	
7. EMPENNAGE					
7.1	Check visually the tail cone surface for damages, cracks and denting. Check the condition of horizontal stabilizer attachment with vertical stabilizer.	First 25 h	✓	5.3.3.2 Sec. 1	
7.2	Check visually for general condition of the rudder coating (fabric).	First 25 h	✓	5.3.5.1.2 Sec. 1	
7.3	Check the elevator for free operation, hinges and looseness.	First 25 h	✓	5.3.5.1.3 Sec. 3	
7.4	Check visually the drain holes of elevator and rudder for obstruction.	First 25 h	✓	5.3.5.1.2 Sec. 2 5.3.5.1.3 Sec. 2	
7.5	Check visually the elevator electric trim tab for attachment and correct operation.	First 25 h	✓	5.3.5.1.3 Sec. 3 5.3.5.1.2 Sec. 3	
7.6	Check for looseness of elevator, rudder and trim tab.	First 25 h	✓	5.3.5.1.2 Sec. 3 5.3.5.1.3 Sec. 3	
7.7	Check visually all the nuts, tail bolts, control rods, bell-crank attachment, and safety wires.	First 25 h	✓	5.3.5.1.3 Sec. 1	
7.8	Re-Torque the empennage fixation bolts. <i>(See the Recommended Fastener Torque Values Section of this Manual 5.1.8)</i>		200 Hours	5.3.3.2 Sec. 3	

Item	Description	Inspection		Chapter Ref.	Initials
		Special	Annual		
7.9	Check visually the hinges, pins, rod of elevator electric trim tab for general condition.	First 25 h	✓	5.3.5.1.3 Sec. 3	
7.10	Check the rudder for free operation and looseness. Check clearance between the rudder and the elevator.		✓	5.3.5.1.2 Sec. 3	
7.11	Check visually the rudder control cables and the castle nut.	First 25 h	✓	5.3.5.1.2 Sec. 3	
8. COCKPIT					
8.1	Check visually the battery electrical cables for condition and attachment – replace them if necessary.	First 25 h	✓	5.9.2.1 Sec. 1	
8.2	Check visually the battery for attachment and security.	First 25 h	✓	5.9.2.1 Sec. 2 6.2.3.3	
8.3	Check visually the condition and integrity cables, connections and security of wire that compose the wiring – replace them if necessary.		✓	5.9.2.2	
8.4	Inspect visually if the panel has all necessary's placards and are readable.		✓	5.8.2 Sec. 1	
8.5	Check visually the safety belts for condition, attachment and security. Replace if necessary.		✓	5.3.1.2.7	
8.6	Check visually the upholstery condition and seats pins.		✓	5.3.1.2.6	
8.7	Check the fire extinguisher (Inspect according to the manufacturer maintenance instructions).	First 25 h	✓	5.3.1.2.8	
8.8	Check the joysticks for freedom of operation. Check for any presence of objects/FOD in the hull internal part.	First 25 h	✓	5.3.5.1.4 Sec. 1	
8.9	Check the control surfaces for deflections and looseness.	First 25 h	✓	5.3.5.1	
8.10	Check the pedals for movement strength, joints safety, general condition and cables attachment.	First 25 h	✓	5.3.5.1.4 Sec. 2	
8.11	Check the instrument panel for attachment and general condition.	First 25 h	✓	Sec. 1	
8.12	Check visually the attachment, condition and general condition of the instruments.	First 25 h	✓	Sec. 2	
8.13	Check the Lane A and Lane B lights for correct operation. Replace them if necessary. (for 912 iS Sport)	First 25 h	✓	5.9.2.5	
8.14	Check the TCU and Alternator lights for correct operation. Replace them if necessary. (for 914 UL)	First 25 h	✓	5.9.2.5	
8.15	Check the dome and instrument panel light for correct operation.	First 25 h	✓	5.9.2.6	
8.16	Check the Dimmer Lights for correct operation.	First 25 h	✓	5.9.2.6	
8.17	Check the position lights, strobe and landing light for correct operation.	First 25 h	✓	5.9.2.6	
8.18	Check the correct operation of electric trim tab of elevator.	First 25 h	✓	5.9.2.6	
8.19	Check for correct operation of the instruments, avionics and ELT.	First 25 h	✓	5.8.2 Sec. 2 Sec. 3	
8.20	Check the entire cabin heater system for general condition, security, proper installation and evidence of any leaks.		✓	5.7.2	
8.21	Check the bilge pump and the cover, if necessary remove the bilge pump body from its support and inspect for presence of dirty and the correct operation of the pump. Reinstall the pump and the protective cover correctly.		✓	5.9.2.3 Sec. 1	
8.22	Make an operational check in the electric system of bilge pump. Ensure the functional full of ON/OFF switch (flasher light) and automatic.		✓	5.9.2.3 Sec. 2	
8.23	When the inspection is finished, clean the hull internally with water and remove all dirt and material loose, which could obstruct the bilge pump. Drain the water from the washing using the bilge pump and clean the protective cover if necessary.		✓	5.9.2.3 Sec. 3	

Item	Description	Inspection		Chapter Ref.	Initials
		Special	Annual		
9. CORROSION					
NOTE Make a detailed inspection of the following components and parts of the Super Petrel LS for corrosion. Use the latest edition of the FAA ADVISORY CIRCULAR AC 43-13-1B, Chapter 6. Corrosion, Inspection and Protection.					
9.1	Engine: Throttle control lever, throttle and choke cable, engine suspension frame, exhaust springs, fixation support of the lower engine cowling.		✓	5.11.3	
9.2	Propeller: Hub, Spacer and fasteners.		✓	5.11.3	
9.3	Landing Gear System: Retraction mechanism, rods, sensors connectors, gas spring, rod end and body of the shock absorber, main gear wheel axle, main gear wheel nut, main and nose gear wheel halves, nose gear fork, nose gear springs, landing gear retraction cables, turnbuckles.		✓	5.11.3	
9.4	Struts: Main struts, N-Struts and Jury Struts, fixation rivets.		✓	5.11.3	
9.5	Brake System: Cylinder, pedal rod end, brake disc, brake caliper.		✓	5.11.3	
9.6	Aileron Controls: Rod ends of the Teleflex cable, control rods, rod ends, bell-crank, hinges, electric trim hinges, and autopilot control rods of the aileron servo.		✓	5.11.3	
9.7	Elevator Controls: Control rods, rod ends, rivets, bell-crank, electric trim hinges, autopilot control rods of the elevator servo.		✓	5.11.3	
9.8	Rudder Controls: Control cable, bell-crank.		✓	5.11.3	
9.9	Fuel System: Fuel selector valve, electrical fuel pumps housing, fixation clamp of the electrical fuel pumps, fuel sensor flange (Header Tank).		✓	5.11.3	
9.10	Electrical Fuel Pumps: A detailed inspection of the electrical fuel pumps and connections should be made for corrosion and general condition.		✓	7.2.1.1	
9.11	Autopilot (Elevator and Aileron): Servo housing, rod ends, control rod.		✓	5.11.3	
9.12	Electrical System: Battery terminals, battery relay terminals, instruments connectors, switches, instruments fixation bolts, panel fixation bolts, bilge pump connectors, electrical fuel pumps connectors and terminals, headphones connectors, electric trim connectors (elevator and aileron), antennas connectors (VHF, XPNDR, ELT, etc.).		✓	5.11.3	
9.13	Miscellaneous: Fire extinguisher fixation support, cabin heater radiator, cabin heater valve, seat belts harnesses.		✓	5.11.3	

12.6 Heavy Maintenance Inspection Form

5 YEARS / 1000 HOURS CONDITION INSPECTION CHECKLIST	
Owner Name:	Inspector Name (LSRM or A&P):
Aircraft Make / Model: Scoda Aeronáutica Ltda / Super Petrel LS	S/N:
Engine Make / Model: Rotax Aircraft Engines /	S/N:
Hours Flown (Hobbs):	Date:

Before Starting the inspection:	Remove or open all cowlings, inspection windows, access doors and baggage compartment.
	Clean the aircraft, if necessary.
	Sign all the applicable items and N/A for non-applicable items.

Item	Description	Inspection		Chapter Ref.	Initials
		Special	5 years / 1000 h		
1. ENGINE					
1.1	Inspect the electric fuel pumps (Main and Auxiliary). Replace them if necessary.		✓	7.2.1.1	
1.2	Replace coolant.		✓	6.2.2.3	
1.3	Inspect all hoses and lines installed on the airframe. Replace them if necessary.		✓	6.2.3.21.2	
2. LANDING GEAR RETRACTING SYSTEM					
2.1	Inspect and perform the test on the gas spring. Replace if necessary.		✓	6.2.3.13	
2.2	Inspect the cables of the landing gear system for general condition, corrosion, routing, fixation and friction with structure. Replace them if necessary. Use as reference the FAA AC 43.13-1B Chapter 7.		✓	6.2.3.10	
2.3	Inspect functioning of the retracting system, Jonson Bar proper positioning, sealing, etc.		✓	6.2.3.10	
3. BRAKE SYSTEM					
3.1	Inspect the brake system for leakage, air and corrosion in the lines and connections. Replace the hydraulic fluid if necessary.		✓	6.2.3.6	
4. EMPENNAGE					
4.1	Remove rudder, elevators and horizontal stabilizers.		✓	7.2.1.2	
4.2	Inspect the vertical stabilizer Carbon Cross Tube where the horizontal stabilizers are attached for general condition, cracks, internal holes (alignment).		✓	7.2.1.2	
4.3	Inspect the Vertical Stabilizer and the Tail Cone for general condition, bulkhead fixation, rudder supports fixation, bushings, rudder stops.		✓	7.2.1.2	
4.4	Inspect the articulation bearings located in the elevator control rod, elevator bellcrank and fixation plate of the horizontal stabilizer for general condition, corrosion and fixation.		✓	7.2.1.2	
4.5	Inspect the Vertical Stabilizer and the Tail Cone for general condition, impact damages, corrosion, stains, dents.		✓	7.2.1.2	
4.6	Inspect the Tubular and “C” spar of the Horizontal Stabilizers for general condition and fixation.		✓	7.2.1.2	

Item	Description	Inspection		Chapter Ref.	Initials
		Special	1000 h / 5 years		
4.7	Inspect the hinges and bushings of the Horizontal Stabilizers for general condition and fixation.		✓	7.2.1.2	
4.8	Inspect the Horizontal Stabilizers for general condition, impact damages, corrosion, stains, dents.		✓	7.2.1.2	
4.9	Inspect the Tubular spar of the Elevators for general condition and fixation.		✓	7.2.1.2	
4.10	Inspect the hinges and pins of the Elevators for general condition and fixation.		✓	7.2.1.2	
4.11	Inspect the fixation bolts of the Elevators for corrosion, fixation and general condition. Replace them if necessary.		✓	7.2.1.2	
4.12	Inspect the Elevators for general condition, impact damages, corrosion, stains, dents.		✓	7.2.1.2	
4.13	Inspect the Electric Trim Tab for general condition, impact damages, corrosion, stains, dents.		✓	7.2.1.2	
4.14	Inspect the hinges, pins, control rod of the Electric Trim Tab for general condition, corrosion and fixation.		✓	7.2.1.2	
4.15	Inspect the electrical installation of the Electric Trim Tab for general condition, corrosion of the connectors, routing, and friction with structure.		✓	7.2.1.2	
4.16	Perform a test of the Electric Trim Tab and check the proper operation.		✓	7.2.1.2	
4.17	Inspect the Bellcrank and Fixation Bolt of the Rudder for general condition, corrosion and fixation.		✓	7.2.1.2	
4.18	Inspect the Fabric of the Rudder for general condition.		✓	7.2.1.2	
4.19	Inspect the Rudder for general condition, impact damages, corrosion, stains, dents.		✓	7.2.1.2	
4.20	Install horizontal stabilizers, elevators and rudder. Re-Torque the empennage fixation bolts. <i>(See the Recommended Fastener Torque Values Section of this Manual 5.1.8)</i>		✓	7.2.1.2	
4.21	Remove the elevator pushrod and inspect for any wear, bent, scratches, dents, corrosion and general condition. Replace it if necessary.		✓	7.2.1.3	
4.22	Remove the primary pushrod (inside the aircraft floor) and inspect for any wear, bent, scratches, dents, corrosion and general condition. Replace it if necessary.		✓	7.2.1.3	
5. CABLES					
5.1	Inspect the Teleflex cable (for aileron) for looseness, corrosion and softness. Replace it if necessary.	10 Years		7.2.3	
5.2	Inspect the throttle cable and its housing for wear, damage, proper security, signals of corrosion and general condition. Replace it if necessary.	10 Years		7.2.4	
5.3	Inspect the rudder cables for general condition, corrosion, routing, fixation and friction with structure. Replace them if necessary. Use as reference the FAA AC 43.13-1B Chapter 7.	10 Years		7.2.5	
6. STRUCTURE					
6.1	Remove the lower wings, struts and upper wings.	10 Years		7.2.6	
6.2	Inspect the wings assembly for general condition, impact damages, corrosion, stains, dents.	10 Years		7.2.6	
6.3	Inspect the wings struts for general condition, corrosion, impact damages.	10 Years		7.2.6.3	
6.4	Inspect the fabric covering of the wings and rudder for general condition, loose finishing tape and reinforcing patches, cracking, peeling or deteriorated coatings, fabric tears and impact damages.	10 Years		7.2.7	

Item	Description	Inspection		Chapter Ref.	Initials
		Special	1000 h / 5 years		
6.5	Perform a mechanical test on the fabric covering. Use as reference the FAA AC 43.13-1B Chapter 2.	10 Years		7.2.7	
6.6	Inspect the composite structures for general condition, impact damages, corrosion, stains, and dents.	10 Years		7.2.8	
6.7	If the inspection made in the step 6.6 is considered by the mechanic as not satisfactory, it should be performed a special inspection on the composite main structures according to the Service Instruction SI_SPLS_003_Composite Structure Inspection. In this case the aircraft manufacturer should be consulted for further assessment.	10 Years		7.2.8	

12.7 Assembly Quick Guide

12.7.1 Wings

Required Tools:	Combined Wrench 13 mm (2 pcs)
	Combined Wrench 10 mm (2 pcs)
	Combined Wrench 8 mm (2 pcs)
	Allen Wrench 6 mm (1 pcs)
	Combined Wrench 7/16" (1 pcs)
	Safety Wire Pliers
	Clamp Pliers

NOTE

All parts and components for installation can be found in the **Illustrated Parts Catalogue**.

NOTE

All the bolts must be installed from the outside to the inside, from the top to the bottom and from forward to backward.

NOTE

Remove or open all cowlings, inspection windows, access doors and baggage compartment, before the starting the assembly.

NOTE

Remove the screws of the fuse box. The fuse box should be placed over the fuselage structure (pilot side) without disconnect any connector (see picture below). Applied for Super Petrel LS equipped with Rotax 912 iS Sport.




Figure 12-1

WARNING

BEFORE STARTING INSTALLATION, REMOVE ALL INSULATING TAPES ON THE VENTS AND FUEL TANK HOSES.

CAUTION

Connections located in the wings, header tank and vents should not be retightened in order to preserve the integrity of sealing components, fittings and lines of the fuel system.

12.7.1.1 Upper Wings

1. Place the main strut in the junction of the fuselage, install the bolt (PE-131.033) and allow the other end to be supported on the floor.


NOTE

Observe the correct direction of the main strut installed.



Figure 12-2

2. While one person holds the wing tip, the other person holds the wing root, feeding the electrical cables (light position, strobe and landing position light), the vent hose and the aileron rod through the corresponding holes.



- 1. Lights and aileron trim cables
- 2. Vent Hose
- 3. Aileron Rod

Figure 12-3

3. Fit the wing to the fuselage, installing the bolt (**SE-133.047**) and its respective washer (**DIN 9021 A2 M8**) in the front part of the upper wing junction. Procedure is completed with two people.




Figure 12-4

4. Fit the main strut in the junction with the upper wing and install the bolt (**PE-131.031**). Procedure is completed with two people.



Figure 12-5


5. Install the bolt (DIN 931 A2 M8X50) in the upper wing rear junction of the fuselage.

Rotax 912 ULS and 912 iS Sport



Figure 12-6

Rotax 914 UL: For lifting the Airbox is necessary to remove the bolts identified in the picture below. (Only for Super Petrel LS equipped with Rotax 914 UL).



6. Install the nuts, washers and tighten the bolts as explained below:

NOTE

Use the washers on the bolts and nuts as necessary.

NOTE

Before tighten the bolts and nuts, apply penetrating oil as necessary.

NOTE

After tightening, apply torque seal over the nut.

- A) Main Strut Junction of the Fuselage:** install the nut (**DIN 985 A2 M8**) with two (2) washers (**DIN 125 A2 M8**) and tighten with two (2) combined wrenches 13 mm.



Figure 12-7

- B) Main Strut Junction of the Upper Wing:** install the nut (**DIN 985 A2 M8**) with one (1) washer (**DIN 125 A2 M8**) and tighten with two (2) combined wrenches 13 mm.



Figure 12-8

- C) Front Junction of the Upper Wing:** install the nut (**DIN 985 A2 M8**) with one (1) washer (**DIN 9021 A2 M8**) and one (1) washer (**DIN 125 A2 M8**) as shown below and tighten with one (1) combined wrench 13 mm and one (1) Allen wrench 6 mm.




Figure 12-9

- D) Rear Junction of the Upper Wing:** install the nut (**DIN 985 A2 M8**) with one (1) washer (**DIN 9021 A2 M8**) and tighten with two (2) combined wrenches 13 mm.




Figure 12-10

- E) Jury Struts:** install the bolt (**SE-131.045**) and the nut (**DIN 985 A2 M5**) with one (1) washer (**DIN 125 A2 M5**) and tighten with two (2) combined wrenches 8 mm.



Figure 12-11

- F) Connection between the Aileron Bell-Crank Tie Rod with the Aileron Rod:** inside the upper part of the fuselage, install a bolt (**SE-211.034**) on both sides, tighten with one (1) combined wrench 10 mm and then install the safety wire.



Figure 12-12

- G) Vent Hoses:** Remove the insulating tape from the vent hose. Remove the nut from the T connection and connect the vent hose to the nut. Set the nut with the vent hose in the T connection and tighten with one (1) combined wrench 7/16".



Figure 12-13

- H) **Communication and Electric Cables:** Connect the communication cables, two cables connected inside of the upper part of the fuselage and the other one must be connected to the antenna's bottom. Connect the electrical cables.



Figure 12-14

12.7.1.2 N-Struts

1. **Front N-Strut:** Connect the vent hose to the upper wing. Pass the vent hose through the front N-Strut as shown below and install the bolt (PE-131.035).




Figure 12-15


2. **Rear N-Strut:** Install the bolt (**PE-131.035**) with its respective plastic washers (**PN-703.019**) as shown below.



Figure 12-16

3. **Pitot and Static:** Pass the blue hoses through the main strut and connect them inside the fuselage. (The pitot system must be installed in the left N-Strut).





Analog Instruments Panel

Digital Instruments Panel

Figure 12-17

NOTE

Install the nuts and washers of the N-Struts just after you have installed the lower wing.

12.7.1.3 Lower Wings

1. Approximate the wing to the fuselage, connect the fuel hose to the fuel tank's output. Use the clamp pliers to tighten it.




Figure 12-18

(From serial number S0390): Approximate the wing to the fuselage, insert the wing fuel hose through the fuselage hole. Connect the fuel hoses inside the fuselage. Use the clamp pliers to tighten it.



Figure 12-19

2. Fit the wing and install the L-pin (**SE-131.026**) inside the fuselage.

CAUTION

After installed the L-pin one person must hold the wing tip as shown below.



Figure 12-20

3. Connect the vent hose of the front N-Strut and install the bolt (**PE-131.032**). One person must hold the wing tip until the bolt is installed.





Figure 12-21

4. Install the bolt (**SE-132.027**) in the rear of the wing root.



Figure 12-22

5. Install the bolt (**SE-131.019**) with its respective plastic washers (**PN-703.019**) in the junction of the rear N-Strut with the lower wing as shown below.



Figure 12-23

6. Install the nuts, washers and tighten the bolts as explained below:

NOTE

Use the washers on the bolts and nuts as necessary.

NOTE

Before tightening the bolts and nuts, apply penetrating oil as necessary.

NOTE

After tightening, apply torque seal over the nut.

- A) Rear N-Strut:** Install the nut (**DIN 985 A2 M6**) with its respective washer (**DIN 125 A2 M6**) and tighten with two (2) combined wrenches 10 mm (Lower and Upper Wing)



Figure 12-24

- B) Front N-Strut:** Install the nut (**DIN 985 A2 M6**) with its respective washer (**DIN 125 A2 M6**) and tighten with two (2) combined wrenches 10 mm in the junction with the upper wing. Install the nut (**DIN 985 A2 M8**) with its respective washer (**DIN 125 A2 M8**) and tighten with two (2) combined wrenches 13 mm in the junction with the lower wing.



Figure 12-25

- C) Rear Wing Root:** Install the nut (**DIN 985 A2 M8**) with its respective washer (**DIN 125 A2 M8**) and tighten with one (1) combined wrench 13 mm and one (1) Allen wrench 6 mm.



Figure 12-26

- D) L-Pin:** Inside the fuselage install the circular pin (**PN-704.010**) with its respective washer (**DIN 125 A2 M8**).



Figure 12-27

- E) **Floaters:** Install the floaters. In the front install two bolts (**DIN 933 A2 M6X16**) with their respective washers (**DIN 934 A2 M5**) and nuts (**DIN 127B A2 M10**), tighten with two (2) combined wrenches. In the rear install the bolt (**DIN 931 A2 M6X40**) with its respective bushing (**SE-132.032-1**), washer (**DIN 125 A2 M6**) and nut (**DIN 985 A2 M6**); tighten with two (2) combined wrenches 10 mm.

NOTE

Install the floaters correctly. The floaters larger plates must be installed directed to the outer part of aircraft.



Figure 12-28

12.7.2 Empennage

12.7.2.1 Horizontal Stabilizer

Required Tools:	Allen Wrench 6 mm (1 pcs)
	Combined Wrench 10 mm (2 pcs)
	Torque Wrench
	Safety Wire Pliers
Parts and Materials Required:	Refer to Illustrated Parts Catalog

To install the horizontal stabilizer, a minimum of two people will be necessary.

NOTE

All parts and components for installation can be found in the **Illustrated Parts Catalogue**.

NOTE

Use the washers on the bolts and nuts as necessary.

1. Clean the circular spar internal part of the vertical stabilizer and the circular spar external part of the horizontal stabilizer before starting the installation as shown below.



Figure 12-29

2. First install the left horizontal stabilizer as shown below.




Figure 12-30

3. Then install the right horizontal stabilizer as shown below.



Figure 12-31

4. Install the attachment bolts (**SE-123.016**) with their respective washers (**DIN 9021 A2 M8**) and tighten with one (1) Allen wrench 6 mm. Verify the torque with a torque wrench (**8 N*m**). Install the safety wire.




Figure 12-32

5. Install the bolt (**SE-123.030**) with its respective washers (**DIN 934 A2 M5**) and nut (**DIN 985 A2 M6**); tighten with two (2) combined wrenches 10 mm.



Figure 12-33

12.7.3 Controls

12.7.3.1 Elevators

Required Tools:	Socket Wrench 10 mm (1 pcs)
Parts and Materials Required:	Refer to Illustrated Parts Catalog

To install the elevators, a minimum of two people will be necessary.

NOTE

All parts and components for installation can be found in the **Illustrated Parts Catalogue**.

NOTE

The left elevator has an electrical cable for the trim tab.

NOTE

Use the washers on the bolts and nuts as necessary.

NOTE

All the bolts must be installed from the outside to the inside, from the top to the bottom and from forward to backward.

NOTE

Before tightening the bolts and nuts, apply penetrating oil as necessary.

NOTE

After tightening, apply torque seal over nuts.

1. Install the elevator by fitting the pins with the hinges laterally.





Figure 12-34

2. Install the nut (**DIN 985 A2 M6**) and its respective washer (**DIN 125 A2 M6**) in the three points that join the elevator with the bell-crank and tighten with one (1) socket wrench 10 mm.



Figure 12-35

3. Connect the electrical cable of the trim tab.



Figure 12-36

12.7.3.2 Rudder

Required Tools:	Combined Wrench 8 mm (2 pcs)
Parts and Materials Required:	Refer to Illustrated Parts Catalog

NOTE

All parts and components for installation can be found in the **Illustrated Parts Catalogue**.

NOTE

The left elevator has an electrical cable for the trim tab.

NOTE

Use the washers on the bolts and nuts as necessary.

NOTE

All the bolts must be installed from the outside to the inside, from the top to the bottom and from forward to backward.

NOTE

Before tightening the bolts and nuts, apply penetrating oil as necessary.

NOTE

After tightening, apply torque seal over nuts.

1. Install the rudder. First, fit the bottom bolt and then fit the rudder top.



Figure 12-37


2. Install the rudder's castle nut (**DIN 935 A2 M6**) with its respective washer (**DIN 9021 A2 M6**); tighten it just enough to install the cotter pin (**DIN 94 A2 1,6X12**).



Figure 12-38

WARNING**DO NOT TIGHTEN THE RUDDER'S CASTLE NUT TO THE MAXIMUM.**


3. Install the bolts, washer and nut (**SE-122.021**); tighten with two (2) combined wrench 8 mm. Install the cotter pin.

*Figure 12-39*

12.7.4 Engine

12.7.4.1 Air Filters

Remove the plastic bags that cover the air filter.

*Figure 12-40*

12.7.4.2 Oil Hoses

Connect the oil hose as shown below. First, remove the yellow cap and then connect the oil hose with a wrench.

CAUTION

Do not tighten the oil hose's nut to the maximum.



Figure 12-41

12.7.5 Battery

- Open the inspection door located in the fuselage's front part of the aircraft.
- Remove the insulating tape from the negative cable.
- Remove the bolt and washers located on the negative point of the battery.
- Install the negative cable on the battery.





Figure 12-42

12.8 Spring Compressor Device Drawing



12.9 Exceptions

12.9.1 Maximum Takeoff Weight Change

As specified on the applicable Pilot's Operating Handbook, Super Petrel LS aircraft delivered up to serial number S0367 the Maximum Takeoff Weight is 1320 lbs (600 kg).